







SEW
EURODRIVE



MOVIAXIS[®] MX Multi-Axis Servo Inverter

Edition 07/2007

11508213 / EN

Operating Instructions





| | | |
|----------|---|-----------|
| 1 | General Information | 6 |
| 1.1 | Structure of the safety notes | 6 |
| 1.2 | Right to claim under warranty | 6 |
| 1.3 | Exclusion of liability | 6 |
| 2 | Safety Notes | 7 |
| 2.1 | General information | 7 |
| 2.2 | Target group | 7 |
| 2.3 | Designated use | 7 |
| 2.4 | Transportation, storage | 8 |
| 2.5 | Installation | 8 |
| 2.6 | Electrical connection | 9 |
| 2.7 | Safe disconnection | 9 |
| 2.8 | Operation | 9 |
| 2.9 | Unit temperature | 10 |
| 3 | Unit Design | 11 |
| 3.1 | Axis system with CAN-based system bus | 11 |
| 3.2 | Axis system with EtherCAT-based system bus | 12 |
| 3.3 | Important notes | 13 |
| 3.4 | Nameplates and unit designations | 14 |
| 3.5 | Standard accessories | 19 |
| 3.6 | Optional accessories | 21 |
| 3.7 | Overview of an axis system | 22 |
| 3.8 | Unit design of MOVIAXIS® MXP power supply module | 23 |
| 3.9 | Unit design of MOVIAXIS® MXA axis modules | 26 |
| 3.10 | System bus in EtherCAT- or CAN-based version | 32 |
| 3.11 | Unit design of the MOVIAXIS® MXM master module component | 33 |
| 3.12 | Unit design of the MOVIAXIS® MXC capacitor module component | 35 |
| 3.13 | Unit design of the MOVIAXIS® MXB buffer module component | 36 |
| 3.14 | Unit design of the MOVIAXIS® MXS 24 V switched-mode power supply module component | 37 |
| 3.15 | Unit design of the MOVIAXIS® MXZ DC link discharge module component | 38 |
| 3.16 | Option combinations on delivery | 39 |
| 3.17 | Multi-encoder card option XGH11A, XGS11A | 42 |
| 3.18 | PROFIBUS XFP11A fieldbus interface option | 51 |
| 3.19 | K-Net XFA11A fieldbus interface option | 53 |
| 3.20 | EtherCAT XFE24A fieldbus interface option | 54 |
| 3.21 | XSE24A EtherCAT-based system bus option | 55 |
| 3.22 | Terminal expansion board type XIO11A option | 56 |
| 3.23 | Terminal expansion board type XIA11A option | 59 |



Contents

| | | |
|----------|---|------------|
| 4 | Installation | 63 |
| 4.1 | Mechanical installation | 63 |
| 4.2 | Connection cable for CAN-based system bus with optional master module | 67 |
| 4.3 | System bus connection cable for several axis systems – CAN-based ... | 68 |
| 4.4 | System bus connection cable to other SEW units – CAN-based..... | 69 |
| 4.5 | Connection cable EtherCAT-based system bus – optional master module | 70 |
| 4.6 | Signal bus connection cable for several axis systems – EtherCAT-based..... | 71 |
| 4.7 | Signal bus cables to other SEW units - EtherCAT-based system bus.... | 72 |
| 4.8 | Covers and touch guards..... | 73 |
| 4.9 | Electrical Installation | 74 |
| 4.10 | Wiring diagrams | 78 |
| 4.11 | Terminal assignment..... | 89 |
| 4.12 | Connecting encoders to the basic unit..... | 95 |
| 4.13 | Notes on electromagnetic compatibility | 97 |
| 4.14 | UL compliant installation | 99 |
| 5 | Startup..... | 101 |
| 5.1 | General information | 101 |
| 5.2 | Supply module settings for a CAN-based system bus..... | 102 |
| 5.3 | CAN2 bus information and settings | 108 |
| 5.4 | Communication via CAN adapter..... | 111 |
| 5.5 | Settings for EtherCAT-based system bus..... | 112 |
| 5.6 | Description of the startup software | 113 |
| 5.7 | Communication selection..... | 114 |
| 5.8 | Sequence in case of new startup..... | 115 |
| 5.9 | MOVIAXIS® startup - Single-motor operation | 116 |
| 5.10 | MOVIAXIS® startup - Multi-motor operation | 140 |
| 5.11 | Application examples | 144 |
| 5.12 | PDO Editor..... | 152 |
| 5.13 | Parameter list..... | 156 |
| 6 | Operation | 157 |
| 6.1 | General information | 157 |
| 6.2 | Displays of the supply and axis modules | 158 |
| 6.3 | Operating displays and errors of the MXP supply module..... | 161 |
| 6.4 | Operating displays and errors of MXA axis module..... | 162 |
| 6.5 | Operating displays of MXC capacitor module component..... | 178 |
| 6.6 | Operating displays of MXB buffer module component..... | 178 |
| 6.7 | Operating displays of 24 V switched-mode power supply module..... | 178 |





| | | |
|----------|--|------------|
| 7 | Service | 179 |
| 7.1 | General information | 179 |
| 7.2 | Removing / installing a module | 180 |
| 7.3 | Extended storage | 186 |
| 7.4 | Waste disposal | 186 |
| 8 | Technical Data | 187 |
| 8.1 | CE marking and approvals | 187 |
| 8.2 | General technical data | 188 |
| 8.3 | Technical data for the supply module | 189 |
| 8.4 | Technical data for the axis module | 191 |
| 8.5 | Technical data for master module component | 194 |
| 8.6 | Technical data for capacitor module component | 195 |
| 8.7 | Technical data for buffer module component | 196 |
| 8.8 | Technical data for 24 V switched-mode power supply module component | 197 |
| 8.9 | Technical data for the DC link discharge module component | 198 |
| 8.10 | Technical data for 24 V current consumption | 199 |
| 8.11 | Technical data for the braking resistors | 199 |
| 8.12 | Technical data for line filter and line chokes | 201 |
| 8.13 | Safety technology (safe stop) | 201 |
| 9 | Appendix | 202 |
| 9.1 | Cable dimensions to AWG | 202 |
| 9.2 | List of abbreviations | 203 |
| 9.3 | Definition of terms | 204 |










1 General Information

1.1 Structure of the safety notes

The safety notes in these operating instructions are structured as follows:

| Symbol |  SIGNAL WORD |
|---|--|
|  | Nature and source of hazard. Possible consequence(s) if disregarded. • Measure(s) to avoid the hazard. |

| Symbol | Signal word | Meaning | Consequences if disregarded |
|---|--|---|---|
| Example:  General hazard |  HAZARD | Imminent hazard | Severe or fatal injuries |
|  Specific hazard, e.g. electric shock |  WARNING | Possible hazardous situation | Severe or fatal injuries |
| |  CAUTION | Possible hazardous situation | Minor injuries |
|  | STOP | Possible damage to property | Damage to the drive system or its environment |
|  | NOTE | Useful information or tip. Simplifies drive system handling. | |

1.2 Right to claim under warranty

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the operating instructions. Read the operating instructions before you start working with the unit.

Make sure that the operating instructions are available to persons responsible for the system and its operation as well as to persons who work independently on the unit. You must also ensure that the documentation is legible.

1.3 Exclusion of liability

You must comply with the information contained in these operating instructions to ensure safe operation of the MOVIAXIS® multi-axis servo inverter and to achieve the specified product characteristics and performance requirements. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.



2 Safety Notes

The following basic safety notes are intended to prevent injury to persons and damage to property. The operator must make sure that the basic safety notes are read and observed. Make sure that persons responsible for the system and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURO-DRIVE.

2.1 General information

Never install damaged products or take them into operation. Submit a complaint to the shipping company immediately in the event of damage.

During operation, multi-axis servo inverters can have live, bare and movable or rotating parts as well as hot surfaces, depending on their enclosure.

Removing covers without authorization, improper use as well as incorrect installation or operation may result in severe injuries to persons or damage to property.

Refer to the documentation for more information.

2.2 Target group

Only qualified personnel are authorized to install, startup or service the units or correct unit faults (observing IEC 60364 or CENELEC HD 384 or DIN VDE 0100 and IEC 60664 or DIN VDE 0110 as well as national accident prevention guidelines).

Qualified personnel in the context of these basic safety notes are persons familiar with installation, assembly, startup and operation of the product who possess the necessary qualifications.

All activity in the other areas of transportation, storage, operation, and disposal must be carried out by persons who are appropriately trained.

2.3 Designated use

The MOVIAXIS® MX multi-axis servo drives are units for use in industrial and commercial systems to operate permanent-field synchronous AC motors and asynchronous AC motors with encoder feedback. These motors must be suitable for operation with servo inverters. Connect other loads to the units after consultation with the manufacturer only.

The MOVIAXIS® MX multi-axis servo drives are intended for use in metal control cabinets. These metal control cabinets represent the necessary enclosure for the application as well as the grounding over a large area required for EMC purposes.

In case of installation in machines, startup of the multi-axis servo inverters (i.e. start of designated operation) is prohibited until it is determined that the machine meets the requirements stipulated in the EC Directive 98/37/EC (machine guideline). You must also observe EN 60204.



Startup (i.e. start of designated operation) is only permitted with adherence to EMC (89/336/EEC) guideline.

The multi-axis servo inverters meet the requirements stipulated in the low voltage guideline 2006/95/EC. The harmonized standards of the EN 61800-5-1 DIN VDE/T105 series in connection with EN 60439-1 VDE 0660 part 500 and EN 60146 VDE/0558 are applied to the multi-axis servo inverters.

Technical data and information on the connection requirements are provided on the nameplate and in the documentation; these must be observed under all circumstances.

Safety functions

MOVIAXIS® multi-axis servo inverters may not take on safety functions without a higher-level safety system. Use higher-level safety systems to ensure protection of equipment and personnel.

For safety applications, refer to the information in the following publications:

- Safe Disconnection for MOVIAXIS® – Conditions.
- Safe Disconnection for MOVIAXIS® – Applications.

2.4 Transportation, storage

You must observe the notes on transportation, storage and proper handling. Observe the climatic conditions as stated in sec. 9.1. "General technical data".

2.5 Installation

The units must be installed and cooled according to the regulations and specifications in the corresponding documentation.

Protect the multi-axis servo inverters from excessive strain. Especially during transportation and handling, do not allow the components to be deformed or insulation spaces altered. Avoid contact with electronic components and contacts.

Multi-axis servo inverters contain components that can be damaged by electrostatic energy and could be destroyed in case of improper handling. Prevent mechanical damage or destruction of electric components. This may pose health risks under certain circumstances.

The following applications are prohibited unless the unit is explicitly designed for such use:

- Use in potentially explosive areas.
- Use in areas exposed to harmful oils, acids, gases, vapors, dust, radiation, etc.
- Use in non-stationary applications that are subject to mechanical vibration and shock loads in excess of the requirements in EN 61800-5-1.

2.6 Electrical connection

Observe the applicable national accident prevention guidelines when working on live multi-axis servo inverters (for example, BGV A3).

Perform electrical installation according to the pertinent regulations (e.g. cable cross sections, fusing, protective conductor connection). Additional information is contained in the documentation.

You will find notes on EMC-compliant installation, such as shielding, grounding, arrangement of filters and routing of lines, in the documentation of the multi-axis servo inverters. Always observe these notes even with multi-axis servo inverters bearing the CE marking. The manufacturer of the system or machine is responsible for maintaining the limits established by EMC legislation.

Preventive measures and protection devices must correspond to the regulations in force (e.g. EN 60204 or EN 61800-5-1).

Required preventive measures: The unit must be grounded.

Cables may only be connected and switches may only be operated in a de-energized state.

2.7 Safe disconnection

The unit meets all requirements for safe disconnection of power and electronic connections in accordance with EN 61800-5-1. All connected circuits must also satisfy the requirements for safe disconnection.

2.8 Operation

Systems with integrated multi-axis servo inverters must be equipped with additional monitoring and protection devices, if necessary, according to the applicable safety guidelines, such as the law governing technical equipment, accident prevention regulations, etc. Changes to the drive inverter using the software are permitted.

Do not touch live components or power connections immediately after disconnecting the multi-axis servo inverters from the supply voltage because there may still be some charged capacitors. Note the respective reference plates on the multi-axis servo inverter.

Cables may only be connected and switches may only be operated in a de-energized state.

Keep all covers and doors closed during operation.

The fact that status LEDs and other display elements are no longer illuminated does not indicate that the unit has been disconnected from the mains and no longer carries any voltage.

Mechanical blocking or internal safety functions of the unit can cause a motor standstill. Eliminating the cause of the problem or performing a reset can result in the drive re-starting automatically. If, for safety reasons, this is not permitted for the driven machine, disconnect the unit from the mains before correcting the fault.



2.9 Unit temperature

MOVIAXIS® multi-axis servo inverters are usually operated with braking resistors. The braking resistors can also be installed in the housing of the supply modules.


The braking resistors can reach surface temperatures ranging from 70 °C to 250 °C.

Never touch the housings of the MOVIAXIS® modules or the braking resistors during operation or in the cool down phase once the unit has been switched off.



3 Unit Design

3.1 Axis system with CAN-based system bus



61523axx

Figure 1: Sample structure of a MOVIAXIS® axis system

- | | |
|--------------------------------|--|
| [1] Master module | [6] Axis module size 4 |
| [2] Capacitor or buffer module | [7] Axis module size 3 |
| [3] Supply module size 3 | [8] Axis module size 2 |
| [4] Axis module size 6 | [9] Axis module size 1 |
| [5] Axis module size 5 | [10] 24 V switched-mode power supply module, additional module |



3.2 Axis system with EtherCAT-based system bus




Figure 2: Sample structure of a MOVIAXIS® axis system

62072axx

- | | |
|---|--|
| [1] Master module | [7] Axis module size 4 |
| [2] Capacitor or buffer module | [8] Axis module size 3 |
| [3] Supply module size 3 | [9] Axis module size 2 |
| [4] Option card for EtherCAT-based system bus in all axis modules | [10] Axis module size 1 |
| [5] Axis module size 6 | [11] 24 V switched-mode power supply module, additional module |
| [6] Axis module size 5 | |



3.3 Important notes

Protective measures and **protective equipment** have to meet the respective national regulations in force.

Required preventive measures: Protective grounding (protection class I)
Required protection devices: The overcurrent protection devices have to be designed to protect the lines at the customer's site.

| | |
|--|--|
| | <p>NOTE</p> <p>Follow the specific operating instructions during installation and startup of the motor and the brake!</p> |
| | <p>⚠ WARNING</p> <p>The 'Unit design' figures displayed on page 23 ... page 38 represent the units without the provided protection cover (touch guard). The protection cover protects the area of the mains and braking resistor connections.</p> <p>Uncovered power connections.</p> <p>Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none">• Never start the unit if the protective covers are not installed.• Install the protective covers according to the regulations. |



3.4 Nameplates and unit designations

The nameplate is divided into up to three parts depending on the module.


- Part "I" of the nameplate indicates the unit designation, production number and status.
- Part "II" of the nameplate indicates the factory installed options and the version status.
- Part "III" of the nameplate (system nameplate) contains the technical data of the module.

The **system nameplate** is located on the side of the unit for the supply module and axis module.

The nameplate contains a description of the version and the scope of supply of the multi-axis servo inverter at the time of delivery.

There may be deviations if

- E. g. option cards are installed or removed at a later time
- Or if the unit firmware is updated.




57521ade

Figure 3: Location of part 1 of the nameplate

- I Part "I" of the nameplate
- II Part "II" of the nameplate
- III Part "III" of the nameplate (system nameplate)



Axis module nameplate




61847axx

Figure 4: Example: MOVIAXIS® MX axis module nameplate

- | | | | |
|-----|--|-----|--------------------------------------|
| I | Part "I" of the nameplate: Located on the upper fastening plate of the module | [1] | Unit designation, see page 17 |
| II | Part "II" of the nameplate: Located on the upper fastening plate of the module | [2] | Production number |
| III | Part "III" of the nameplate: Located at the side of the module housing | [3] | Status |
| | | [4] | Communication slots, firmware status |

Supply module nameplate



61846axx

Figure 5: Example: Nameplate of the MOVIAXIS® MXP power supply module

- | | | | |
|-----|---|-----|-------------------------------|
| I | Part "I" of the nameplate: Located on the upper fastening plate of the module | [1] | Unit designation, see page 17 |
| III | Part "III" of the nameplate: Located at the side of the module housing | [2] | Production number |
| | | [3] | Status |



Unit Design

Nameplates and unit designations

Nameplate of the 24 V switched mode power supply additional module




Figure 6: Example: Nameplate of a 24 V switched-mode power supply module

61849axx

- | | | | |
|-----|---|-----|-------------------|
| I | Part "I" of the nameplate: Located on the upper fastening plate of the module | [1] | Unit designation |
| III | Part "III" of the nameplate: Located at the side of the module housing | [2] | Production number |
| | | [3] | Status |

Nameplate of the DC link discharge additional module





Figure 7: Example: Nameplate of a MOVIAxis® MXZ DC link discharge module

61848axx

- | | | | |
|-----|---|-----|-------------------------------|
| I | Part "I" of the nameplate: Located on the upper fastening plate of the module | [1] | Unit designation, see page 17 |
| III | Part "III" of the nameplate: Located at the side of the module housing | [2] | Production number |
| | | [3] | Status |



Example: Unit designation for MOVIAXIS® basic units



Unit designation for the axis module:

MXA80A-004-503-00 = Axis module with 4 A rated current

Unit designation for the buffer module component

MXB80A-050-503-00 = Buffer module

Unit designation for the capacitor module component

MXC80A-050-503-00 = Capacitor module

Unit designation for the master module component:

MXM80A-000-000-00 = Master module



Unit Design

Nameplates and unit designations

Unit designation for the supply module:

| | | |
|-------------------|---|--|
| MXP80A-010-503-00 | = | 10 kW supply module |
| MXR80A-025-503-00 | = | 25 kW supply module with regeneration (in preparation) |


Unit designation for the 24 V switched-mode power supply module component

| | | |
|-------------------|---|--|
| MXS80A-060-503-00 | = | 24 V switched-mode power supply module |
|-------------------|---|--|

Unit designation DC link discharge module component:

| | | |
|-------------------|---|--|
| MXZ80A-050-503-00 | = | DC link discharge module with a dissipatable energy quantity of 5,000 Ws |
|-------------------|---|--|


MOVIAXIS® MX optional components





3.5 Standard accessories

Standard accessories are included with the basic unit at delivery.



61637axx

Figure 8: Standard accessories

The corresponding mating connectors for all connectors are installed at the factory. An **exception** are the D-sub connectors; they are supplied without mating connector.


Standard accessory assignment table

| No. | Dimen- sions ¹⁾ | MXM | MXZ | MXS | MXP [kW] | | | | MXA [A] | | | | | | | | | | MXC | MXB |
|--|-------------------------------|-----|-----|-----|----------|----|----|----|---------|----|----|----|----|----|----|----|----|-----|-----|-----|
| | | | | | 10 | 25 | 50 | 75 | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 100 | | |
| Touch guard | | | | | | | | | | | | | | | | | | | | |
| [1] | | | | | 2x | 2x | 2x | 2x | | | | | | | | | | | | |
| DC link connection | | | | | | | | | | | | | | | | | | | | |
| [2] | 76 mm | | | 3x | | | | | 3x | 3x | 3x | | | | | | | | | |
| [3] | 106 mm | | | | 3x | | | | | | | 3x | 3x | 3x | 3x | | | | | |
| [4] | 136 mm | | 2x | | | | | | | | | | | | | 3x | | | | |
| [5] | 160 mm | | | | | 3x | 3x | 3x | | | | | | | | | 3x | | 3x | |
| [6] | 226 mm | | | | | | | | | | | | | | | | | 3x | | |
| Electronics shield clamp | | | | | | | | | | | | | | | | | | | | |
| [7] | 60 mm | 1x | | | | | | | 1x | 1x | 1x | | | | | | | | | |
| [8] | 90 mm | | | | 1x | | | | | | | 1x | 1x | 1x | 1x | | | | | |
| [9] | 120 mm | | | | | | | | | | | | | | | 1x | | | | |
| [10] | 150 mm | | | | | 1x | 1x | 1x | | | | | | | | | 1x | | | |
| [11] | 210 mm | | | | | | | | | | | | | | | | | 1x | | |
| Power shield clamp | | | | | | | | | | | | | | | | | | | | |
| [12] | 60 mm | | | | 1x | | 1x | | 1x | 1x | 1x | 1x | 1x | 1x | | | | | | |
| [13] | 60 mm ²⁾ | | | | | 1x | | | | | | | | | | | | | | |
| [14] | 60 mm ³⁾ | | | | | | | | | | | | | | 1x | | | | | |
| [15] | 105 mm | | 1x | | | 1x | | | | | | | | | | 1x | 1x | 1x | | |
| [16] | 105 mm | | | | | | 1x | 1x | | | | | | | | | | | | |
| 24 V supply cable | | | | | | | | | | | | | | | | | | | | |
| [17] | 40 mm | 1x | | | | | | | | | | | | | | | | | | |
| [18] | 50 mm | | | 1x | | | | | 1x | 1x | 1x | | | | | | | | | |
| [19] | 80 mm | | | | 1x | 1x | | | | | | 1x | 1x | 1x | 1x | | | | | |
| [20] | 110 mm | | 1x | | | | | | | | | | | | | 1x | | | | |
| [21] | 140 mm | | | | | | 1x | 1x | | | | | | | | | 1x | | 1x | |
| [22] | 200 mm | | | | | | | | | | | | | | | | | 1x | | |
| Signal bus connection cable (suitable for CAN-/ EtherCAT-based system bus) | | | | | | | | | | | | | | | | | | | | |
| [23] | 200 mm | | | | | | | | 1x | 1x | 1x | | | | | | | | | |
| [24] | 230 mm | | | | 1x | 1x | | | | | | 1x | 1x | 1x | 1x | | | | | |
| [25] | 260 mm | | | | | | | | | | | | | | | 1x | | | | |
| [26] | 290 mm | | | | | | 1x | 1x | | | | | | | | | 1x | | | |
| [27] | 350 mm | | | | | | | | | | | | | | | | | 1x | | |
| Connection cable CAN – master module | | | | | | | | | | | | | | | | | | | | |
| [28] | 520 mm | 1x | | | | | | | | | | | | | | | | | | |
| CAN terminating resistor | | | | | | | | | | | | | | | | | | | | |
| [29] | | | | | 1x | 1x | 1x | 1x | | | | | | | | | | | | |
| Cable lugs | | | | | | | | | | | | | | | | | | | | |
| [30] | | 3x | | | | | | | | | | | | | | | | | | |


1) Length of the cables: Length of the cable without plug

2) Clamp with short support, 60 mm wide

3) Clamp with long support, 60 mm wide



3.6 Optional accessories



61638axx

Figure 9: Optional accessories


Optional accessory assignment table

| No. | Dimension / Designation / Connector type | |
|--|--|-------------------------------|
| System bus connection cable for CAN-based system bus (axis system with other SEW units) | | |
| [1] | 750 mm | RJ45 / open end |
| [2] | 3,000 mm | RJ45 / open end |
| Connection cable EtherCAT – master module | | |
| [3] | 750 mm | 2 x RJ45 |
| System bus connection cable for EtherCAT-based system bus (axis system to other SEW units) | | |
| [4] | 750 mm | 2 x RJ45 (special assignment) |
| [5] | 3,000 mm | 2 x RJ45 (special assignment) |
| System bus connection cable CAN (axis system to axis system) | | |
| [6] | 750 mm | 2 x RJ45 (special assignment) |
| [7] | 3,000 mm | 2 x RJ45 (special assignment) |
| Adapter cable master module to CAN2 | | |
| [8] | 500 mm | Weidmüller to Sub-D9 f |
| Connection cable CAN2 | | |
| [9] | 3 modules | Sub-D9 m/f |
| [10] | 4 modules | Sub-D9 m/f |
| CAN2 terminating resistor | | |
| [11] | Sub-D9 | |



3.7 Overview of an axis system

The units are displayed without cover in the following figure.



61507axx

Figure 10: Exemplary representation of the energy supply in the axis system


- [1] X4: DC link connection
- [2] X5a, X5b: 24 V voltage supply
- [3] Master module
- [4] Capacitor / buffer module
- [5] Supply module BG 3
- [6] Axis modules (size 6 ... size 1)
- [7] 24 V switched-mode power supply module



3.8 Unit design of MOVIAXIS® MXP power supply module

The following figures show the units without cover.

MOVIAXIS® MXP supply module size 1



61524axx

Figure 11: Unit design of MOVIAXIS® MXP power supply module size 1

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front

- [2] Electronics shield clamps
[3] C, E: DIP switches
- C: CAN-based system bus
- E: EtherCAT-based system bus
[4] X12: System bus CAN
[5] S1, S2: DIP switch for CAN baud rate
[6] S3, S4: Axis address switch
[7] Standby display (Power)
[8] 2 x 7-segment display
[9] X5a, X5b: 24 V voltage supply
[10] X4: DC link connection
[11] Power shield clamp
[12] Housing grounding point

C View from bottom


- [13] X3: Braking resistor connection
[14] X1: Mains connection



Unit Design

Unit design of MOVIAXIS® MXP power supply module

MOVIAXIS® MXP supply module size 2



64525axx

Figure 12: Unit design of MOVIAXIS® MXP power supply module size 2

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front


- [2] Electronics shield clamps
[3] C, E: DIP switches
- C: CAN-based system bus
- E: EtherCAT-based system bus
[4] X12: System bus CAN
[5] S1, S2: DIP switch for CAN baud rate
[6] S3, S4: Axis address switch
[7] Standby display (Power)
[8] 2 x 7-segment display
[9] X5a, X5b: 24 V voltage supply
[10] X4: DC link connection
[11] Housing grounding point
[12] Power shield clamp

C View from bottom

- [13] X3: Braking resistor connection
[14] X1: Mains connection



MOVIAXIS® MXP supply module size 3



55468AXX

Figure 13: Unit design of MOVIAXIS® MXP power supply module size 3

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front

- [2] Electronics shield clamps


[3] C, E: DIP switches
- C: CAN-based system bus
- E: EtherCAT-based system bus
[4] X12: System bus CAN
[5] S1, S2: DIP switches
[6] S3, S4: Axis address switch
[7] Standby display (Power)
[8] 2 x 7-segment display
[9] X5a, X5b: 24 V voltage supply
[10] X4: DC link connection
[11] X1: Mains connection
[12] Housing grounding point
[13] Power shield clamp
[14] X3: Braking resistor connection



3.9 Unit design of MOVIAXIS® MXA axis modules

The following figures show the units without cover.

MOVIAXIS® MXP axis module size 1



61544axx

Figure 14: Unit design of MOVIAXIS® MXA axis module size 1

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front


- [2] Electronics shield clamps
[3] X10: Binary inputs
[4] X11: Binary outputs
[5] X12: CAN2 bus
[6] 2 x 7-segment display
[7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)
[8] X5a, X5b: 24 V voltage supply
[9] X4: DC link connection
[10] Power shield clamp

C View from bottom

- [11] X2: Motor connection
[12] X6: Brake control system
[13] X7: 1 Safety relay (optional design)



MOVIAXIS® MXP axis module size 2



61545axx

Figure 15: Unit design of MOVIAXIS® MXA axis module size 2

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front

- [2] Electronics shield clamps

[3] X10: Binary inputs
[4] X11: Binary outputs

[5] X12: CAN2 bus
[6] 2 x 7-segment display
[7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)

[8] X5a, X5b: 24 V voltage supply
[9] X4: DC link connection
[10] Power shield clamp

C View from bottom

- [11] X2: Motor connection


[12] X6: Brake control system
[13] X7, X8: 2 Safety relays (optional design)



Unit Design

Unit design of MOVIAXIS® MXA axis modules

MOVIAXIS® MXP axis module size 3



61546axx

Figure 16: Unit design of MOVIAXIS® MXA axis module size 3

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front


- [2] Electronics shield clamps
[3] X10: Binary inputs
[4] X11: Binary outputs
[5] X12: CAN2 bus
[6] 2 x 7-segment display
[7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)
[8] X5a, X5b: 24 V voltage supply
[9] X4: DC link connection
[10] Power shield clamp

C View from bottom

- [11] X2: Motor connection
[12] X6: Brake control system
[13] X7, X8: 2 Safety relays (optional design)



MOVIAXIS® MXP axis module size 4



61547axx

Figure 17: Unit design of MOVIAXIS® MXA axis module size 4

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front

- [2] Electronics shield clamps
[3] X10: Binary inputs
[4] X11: Binary outputs
[5] X12: CAN2 bus
[6] 2 x 7-segment display
[7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)
[8] X5a, X5b: 24 V voltage supply
[9] X4: DC link connection
[10] X2: Motor connection
[11] Power shield clamp

C View from bottom


- [12] X6: Brake control system
[13] X7, X8: 2 Safety relays (optional design)



Unit Design

Unit design of MOVIAXIS® MXA axis modules

MOVIAXIS® MXP axis module size 5



61548axx

Figure 18: Unit design of MOVIAXIS® MXA axis module size 5

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front


- [2] Electronics shield clamps
- [3] X10: Binary inputs
- [4] X11: Binary outputs
- [5] X12: CAN2 bus
- [6] 2 x 7-segment display
- [7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)
- [8] X5a, X5b: 24 V voltage supply
- [9] X4: DC link connection
- [10] X2: Motor connection
- [11] Power shield clamp

C View from bottom

- [12] X6: Brake control system
- [13] X7, X8: 2 Safety relays (optional design)



MOVIAXIS® MXP axis module size 6



61549axx

Figure 19: Unit design of MOVIAXIS® MXA axis module size 6

A View from top

- [1] Signaling bus
X9a: Input, green plug on cable
X9b: Output, red plug on cable

B View from front

- [2] Electronics shield clamps
- [3] X10: Binary inputs
- [4] X11: Binary outputs
- [5] X12: CAN2 bus
- [6] 2 x 7-segment display
- [7] X13: Connection motor encoder (resolver or Hiperface + temperature sensor)
- [8] X5a, X5b: 24 V voltage supply
- [9] X4: DC link connection
- [10] X2: Motor connection
- [11] Power shield clamp

C View from bottom

- [12] X6: Brake control system
- [13] X7, X8: 2 Safety relays (optional design)



3.10 System bus in EtherCAT- or CAN-based version

Axis modules can be equipped with different system bus versions:

- CAN-based system bus,
- EtherCAT-based system bus.

The figures displayed on page 26... page 31 show the axis modules with CAN-based system bus.




Figure 20: System bus in CAN- or EtherCAT-based version

61554axx

[A] CAN-based system bus

[B] EtherCAT-based system bus

[1] LAM switch

- Switch setting 0: All axis modules except the last one
- Switch setting 1: Last axis module in the system

Switch F1

- Switch setting 0: Delivery condition
- Switch setting 1: Reserved for added functions

[2] LED RUN; color: green / orange - Shows the operating status of the bus electronics and communication

[3] LED ERR; color: red - Shows EtherCAT error.

[4] LED link IN; color: green - EtherCAT connection to the previous unit is active

[5] LED link OUT; color: green - EtherCAT connection to the subsequent unit is active



3.11 Unit design of the MOVIAXIS® MXM master module component

The following figure shows the unit without cover.

MOVIAXIS® MXM master module in MOVI-PLC basic version

The master module shown here has the following designation:
MXM80A-000-000-00/DHP11A.





Figure 21: Unit design of the master module, MOVI-PLC® Basic version

58765axx

View from front

- [1] - [6] For terminal assignment see "MOVI-PLC® basic DHP11B Controller" manual
- [7] Housing grounding point
- [8] X5a, X5b: 24 V voltage supply

| | |
|---|---|
|  | STOP |
| | Servo inverter can possibly be damaged! The master module may only be operated when implemented in a system according to its designated purpose as shown on page 22. Remote operation will damage the master module and is not permitted. |



Unit Design

Unit design of the MOVIAXIS® MXM master module component

MOVIAXIS® MXM master module in MOVI-PLC advanced version

The master module shown here has the following designation:
MXM80A-000-000-00/DHE41B.





Figure 22: Unit design of the master module, MOVI-PLC® Advanced version

62207axx

View from front

- [1] - [7] For terminal assignment see "MOVI-PLC® advanced DH.41B Controller" manual
- [8] Housing grounding point
- [9] X5a, X5b: 24 V voltage supply

| | |
|---|--|
|  | <p>STOP</p> |
| | <p>Servo inverter can possibly be damaged!</p> <p>The master module may only be operated when implemented in a system according to its designated purpose as shown on page 22. Remote operation will damage the master module and is not permitted.</p> |



3.12 Unit design of the MOVIAXIS® MXC capacitor module component

The following figure shows the unit without protective cover.

Capacitor module MXC




Figure 23: Unit design of the MOVIAXIS® MXC capacitor module

60433AXX

- B View from front**
- [1] Standby display (Power)
 - [2] X5a, X5b: 24 V voltage supply
 - [3] X4: DC link connection



Unit Design

Unit design of the MOVIAXIS® MXB buffer module component

3.13 Unit design of the MOVIAXIS® MXB buffer module component

The following figure shows the unit without protective cover.

**Buffer module
MXB**




Figure 24: Unit design of the MOVIAXIS® MXB buffer module

60433AXX

- B View from front**
- [1] No function
 - [2] X5a, X5b: 24 V voltage supply
 - [3] X4: DC link connection



3.14 Unit design of the MOVIAXIS® MXS 24 V switched-mode power supply module component

The following figure shows the unit without protective cover.

24 V switched-mode power supply module




Figure 25: Units design of the 24 V switched-mode power supply module

57583axx

| A | View from top | B | View from front |
|-----|--------------------|-----|-------------------------------|
| [1] | X16: 24 V external | [2] | LED State |
| | | [3] | LED Load |
| | | [4] | X5a, X5b: 24 V voltage supply |
| | | [5] | X4: DC link connection |



Unit Design

Unit design of the MOVIAXIS® MXZ DC link discharge module component

3.15 Unit design of the MOVIAXIS® MXZ DC link discharge module component

The following figure shows the unit without protective cover.

DC link discharge module MOVIAXIS® MXZ




Figure 26: Unit design of MOVIAXIS® MXZ DC link discharge unit

54427BXX

View from front

- [1] X14: Control connector
- [2] X5a, X5b: 24 V voltage supply
- [3] X4: DC link connection
- [4] X15: Connection braking resistor for discharge
- [5] Power shield clamp



3.16 Option combinations on delivery

The axis modules include an expansion system for up to three options.




Figure 27: Slot combinations

56598axx

- [1 - 3] Slots 1 - 3, assignment see following table
[4] Control board - Basic unit components

EtherCAT-capable units

The following table shows the possible combinations and the fixed assignment of cards to the slots.

Combinations with EtherCAT-based system bus

The following option card combinations are possible:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|--------|--------|--------|
| 1 | XSE24A | | |
| 2 | | XIO11A | |
| 3 | | | XIA11A |
| 4 | | | XGH |
| 5 | | | XGS |
| 6 | | | XIO11A |
| 7 | | XIA11A | |
| 8 | | | XGH |
| 9 | | | XGS |
| 10 | | | XIA11A |
| 11 | | | XGH |
| 12 | | XGS | |
| 13 | | XGH | XGS |
| 14 | | | |
| 15 | | XGS | |

**CAN version of the units**

The following tables show the possible combinations and the fixed assignment of cards to the slots.

Fieldbus combinations

The fieldbus options can be plugged in the following combinations:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|-------------------------------|-------------------------------|--------|
| 1 | Fieldbus option ¹⁾ | | |
| 2 | XIO11A | Fieldbus option ¹⁾ | |
| 3 | | | XIA11A |
| 4 | | | XGH |
| 5 | | | XGS |
| 6 | | | XIO11A |
| 7 | XIA11A | | |
| 8 | | | XGH |
| 9 | | | XGS |
| 10 | | | XIA11A |
| 11 | Fieldbus option ¹⁾ | | XGH |
| 12 | XGS | Fieldbus option ¹⁾ | |
| 13 | XGH | | |
| 14 | Fieldbus option ¹⁾ | | XGS |
| 15 | XGS | Fieldbus option ¹⁾ | |

1) Fieldbus option: - XFE24A: EtherCAT or - XFP11A: PROFIBUS or - XFA11A: K-Net

Combinations with XIO

The following option card combinations are possible:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|--------|--------|--------|
| 1 | XIO11A | | |
| 2 | | XIA11A | |
| 3 | | | XGH |
| 4 | | | XGS |
| 5 | | XIA11A | XGH |
| 6 | | | XGS |
| 7 | | XGS | XGH |
| 8 | | XGH | |
| 9 | | XGS | XGS |
| 10 | | XIO11A | |
| 11 | | | XGH |
| 12 | | | XGS |



*Combinations with
XIA*

The following option card combinations are possible:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|--------|--------|--------|
| 1 | XIA11A | | |
| 2 | | | XGH |
| 3 | | | XGS |
| 4 | | XGS | XGH |
| 5 | | XGH | |
| 6 | | XGS | XGS |
| 7 | | XIA11A | |
| 8 | | | XGH |
| 9 | | | XGS |

*Combinations with
XGH, XGS only*

The following option card combinations are possible:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|--------|--------|--------|
| 1 | | | XGH |
| 2 | XGS | | |
| 3 | XGH | | |

*Combinations with
XGS only*

The following option card combinations are possible:

| Combination | Slot 1 | Slot 2 | Slot 3 |
|-------------|--------|--------|--------|
| 1 | | | XGS |
| 2 | XGS | | |



3.17 Multi-encoder card option XGH11A, XGS11A

The multi-encoder card expands the MOVIAXIS® system for evaluation of additional encoders.

Two different multi-encoder cards are available. Their selection is based on the encoder type that is to be evaluated, see table on page 44. An analog, differential input (± 10 V) is available in addition.




Figure 28: Multi-encoder card in version XGH and XGS

61820axx

Technical data

Technical data of the differential input X61:

- Tolerance: ± 10 V
- Resolution: 12 bits
- Update every 1 ms

The input can be used as

- n or M setpoint input
- General measured data input
- Torque limit value



Technical data X62:

- RS422.
- Maximum frequency: 200 kHz.
- Simulation output is based on the motor or option encoder, can be selected via unit parameters.
- PPR count can be freely selected in powers of two from 2^6 - 2^{12} [pulses / revolution].
- Encoder signals can be multiplied.
- The maximum possible speed depends on the emulation PPR count set:

| Set PPR count | Maximum possible speed [min ⁻¹] |
|---------------|---|
| 64 - 1024 | No limit |
| 2048 | 5221 |
| 4096 | 2610 |

Overview of functions

| Functions | XGH version | XGS version |
|---|-------------|-------------|
| SSI functionality | -- | x |
| Hiperface functionality: | x | x |
| EnDat 2.1 functionality | | |
| Incremental encoder / sin-cos functionality | | |
| Encoder simulation | | |
| Temperature evaluation | | |
| Analog input | | |
| Optional 24 V voltage supply | | |
| Resolver | -- | -- |

- Please contact SEW-EURODRIVE before installing HTL encoders.
- You need 15-pole SUB-D connectors for all encoders that are to be connected to the multi-encoder card.

**Suitable encoders**

The encoders listed in the following tables are evaluated by the multi-encoder card.

| SEW encoder designation | Encoder system | Manufacturer designation / manufacturer | Voltage |
|-------------------------|--|---|---------|
| AL1H | Hiperface linear encoder | L230 / SICK-Stegmann | 12 V |
| EK0H | Hiperface single-turn | SKS36 / SICK-Stegmann | |
| AS0H | Hiperface single-turn absolute encoder | SRS36 / SICK-Stegmann | |
| ES1H | Hiperface single-turn | SRS50 / SICK-Stegmann | |
| ES3H/ES4H | Hiperface single-turn absolute encoder | SRS64 / SICK-Stegmann | |
| AK0H | Hiperface multi-turn | SKM36 / SICK-Stegmann | |
| AS1H | Hiperface multi-turn | SRM50 / SICK-Stegmann | |
| AS3H/AS4H | Hiperface multi-turn absolute encoder | SRM64 / SICK-Stegmann | |
| AV1H | Hiperface absolute encoder | SRM50C3 / SICK-Stegmann | |
| EV1C | HTL | ROD436 1024 / Heidenhain | |
| EV1R | TTL | ROD466 1024 / Heidenhain | |
| EV1S | Sine | ROD486 1024 / Heidenhain | |
| EV1T | TTL | ROD426 1024 / Heidenhain | |
| EV2R | Encoder | OG71-DN 1024R / Hübner | |
| EV2T | Encoder | OG71-DN 1024TTL / Hübner | |
| AV1Y | SSI absolute encoder | ROQ424SSI / Heidenhain | |
| ES1S | Encoder | OG72S-DN1024R / Hübner | |
| ES2S | | OG72S-DN1024R / Hübner | |
| EV2S | | OG71S-DN1024R / Hübner | |
| EH1S | | HOG74-DN1024R / Hübner | |
| ES1R | | OG72-DN1024R / Hübner | |
| ES2R | | OG72-DN1024R / Hübner | |
| EH1R | | HOG74-DN1024R / Hübner | |
| ES1T | | OG72-DN1024TTL / Hübner | |
| ES2T | | OG72-DN1024TTL / Hübner | |
| EH1T | | HOG74-DN1024TTL / Hübner | |



| Encoder system | Manufacturer designation / manufacturer | Voltage |
|--|---|---------|
| Laser encoder | DME5000 / SICK-Stegmann | 24 V |
| Laser encoder | DME4000 / SICK-Stegmann | |
| Hiperface single-turn absolute encoder | SRS60 / SICK-Stegmann | 12 V |
| Hiperface multi-turn absolute encoder | SRM60 / SICK-Stegmann | |
| Single-turn absolute encoder | ECN1313 / Heidenhain | |
| Multi-turn absolute encoder | EQN1325 / Heidenhain | |
| SSI | BTL5-S112-M1500-P-S32 / Balluf | 24 V |
| | GM401 / IVO | 12 V |
| | AMS200/200 / Leuze | 24 V |
| | OMS1 / Leuze | |
| | WCS2 LS 311 / Pepperl & Fuchs | |
| | DME 3000 111 / Sick | |
| | DME 5000 -111 / Sick | |
| | AG100 MSSI / Stegmann | 12 V |
| | AG626 / Stegmann | 24 V |
| | CE58 / T&R | 12 V |
| | LE100 / T&R | 24 V |
| | EDM / Visolux | |
| | OMS2 / Leuze | 24 V |
| | WCS2A / Pepperl & Fuchs | |

Connection and terminal description of the card

PIN assignment
X61

| | Terminal | Assignment | Brief description | Type of connector |
|--|------------|------------|---------------------------------|---|
| | X61 | | | |
| | 1 | AI 0+ | Analog, differential input | Mini Combicon 3.5, 5-pole. Cable cross section max: 1.5 mm ² , min: 0.75 mm ² |
| | 2 | AI 0- | | |
| | 3 | DGND | Reference for PIN 4 | |
| | 4 | 24 V | Optional encoder voltage supply | |
| | 5 | n.c. | | |



NOTE

The 24 V supply at PIN 4 is only permitted if 24 V encoders are used. Ensure UL-compliant fusing. See sec. "UL-compliant installation" on page 99.

The supply must be connected via a diode with sufficient current carrying capacity.



Restrictions for the evaluation of inputs for axis modules equipped with I / O and multi-encoder cards

**NOTE**

If the axis module is equipped with two I / O and one multi-encoder card or with one I / O and two multi-encoder cards (see following table), the following restrictions apply for the evaluation of inputs and outputs:

Evaluation is only possible for the inputs and outputs (if applicable) of two cards.

| Variant | Plugged card | Plugged card | Plugged card |
|---------|--------------|--------------------|--------------------|
| 1 | I / O card | I / O card | Multi-encoder card |
| 2 | I / O card | Multi-encoder card | Multi-encoder card |

Wiring diagrams for encoders with external voltage supply

The wiring diagrams show the connection of one and two multi-encoder cards. For 12 V encoders, external voltage supply only becomes necessary with two multi-encoder cards if the total current of the encoders is ≥ 800 mA.





Figure 29: Wiring diagram with one multi-encoder card

62357axx

Key see Figure 30.



62358axx

Figure 30: Wiring diagram with two multi-encoder cards

- [1] Voltage source
- [2] Multi-encoder card
- [3] Encoders


PIN assignment
X62 encoder emulator signals

| | Terminal | Assignment | Brief description | Type of connector |
|--|------------|-------------------------|--------------------------|---------------------|
| | X62 | | | |
| | 1 | Signal track A (cos+) | Encoder emulator signals | Sub-D 9-pole (male) |
| | 2 | Signal track B (sin+) | | |
| | 3 | Signal track C | | |
| | 4 | n.c. ¹⁾ | | |
| | 5 | DGND | | |
| | 6 | Signal track A_N (cos-) | | |
| | 7 | Signal track B_N (sin-) | | |
| | 8 | Signal track C_N | | |
| | 9 | n.c. ¹⁾ | | |

1) Do not connect a cable




*PIN assignment
X63 XGH X64
XGS with TTL
encoder, sin/cos
encoder*

| | Terminal | Function for TTL encoder, sin/cos encoder | Type of connector |
|---|------------------|---|------------------------|
|  | X63 (XGH) | | |
| | 1 | Signal track A (cos+) | Sub-D 15-pole (female) |
| | 2 | Signal track B (sin+) | |
| | 3 | Signal track C | |
| | 4 | n.c. ¹⁾ | |
| | 5 | n.c. ¹⁾ | |
| | 6 | TF / TH / KTY - | |
| | 7 | n.c. ¹⁾ | |
| | 8 | DGND | |
| | 9 | Signal track A_N (cos-) | |
| | 10 | Signal track B_N (sin-) | |
| | 11 | Signal track C_N | |
| | 12 | n.c. ¹⁾ | |
| | 13 | n.c. ¹⁾ | |
| | 14 | TF / TH / KTY + | |
| | 15 | Us | |

1) Do not connect a cable


*PIN assignment
X63 XGH X64
XGS with Hiper-
face encoder*

| | Terminal | Function for Hiperface encoder | Type of connector |
|---|------------------|--------------------------------|------------------------|
|  | X63 (XGH) | | |
| | 1 | Signal track A (cos+) | Sub-D 15-pole (female) |
| | 2 | Signal track B (sin+) | |
| | 3 | n.c. ¹⁾ | |
| | 4 | DATA + | |
| | 5 | n.c. ¹⁾ | |
| | 6 | TF / TH / KTY - | |
| | 7 | n.c. ¹⁾ | |
| | 8 | DGND | |
| | 9 | Signal track A_N (cos-) | |
| | 10 | Signal track B_N (sin-) | |
| | 11 | n.c. ¹⁾ | |
| | 12 | DATA - | |
| | 13 | n.c. ¹⁾ | |
| | 14 | TF / TH / KTY + | |
| | 15 | Us | |

1) Do not connect a cable




PIN assignment
X63 XGH
X64 XGS with
EnDat 2.1

| | Terminal | Function for EnDat 2.1 | Type of connector |
|---|------------------|------------------------|------------------------|
|  | X63 (XGH) | | Sub-D 15-pole (female) |
| | 1 | Signal track A | |
| | 2 | Signal track B | |
| | 3 | Cycle + | |
| | 4 | DATA + | |
| | 5 | n.c. ¹⁾ | |
| | 6 | TF / TH / KTY - | |
| | 7 | n.c. ¹⁾ | |
| | 8 | DGND | |
| | 9 | Signal track A_N | |
| | 10 | Signal track B_N | |
| | 11 | Cycle- | |
| | 12 | DATA - | |
| | 13 | n.c. ¹⁾ | |
| | 14 | TF / TH / KTY + | |
| | 15 | Us | |

1) Do not connect a cable

PIN assignment
X64 XGS with SSI

| | Terminal | Function for SSI | Type of connector |
|---|------------------|--------------------|------------------------|
|  | X64 (XGS) | | Sub-D 15-pole (female) |
| | 1 | n.c. ¹⁾ | |
| | 2 | n.c. ¹⁾ | |
| | 3 | Cycle + | |
| | 4 | DATA + | |
| | 5 | n.c. ¹⁾ | |
| | 6 | TF / TH / KTY - | |
| | 7 | n.c. ¹⁾ | |
| | 8 | DGND | |
| | 9 | n.c. ¹⁾ | |
| | 10 | n.c. ¹⁾ | |
| | 11 | Cycle- | |
| | 12 | DATA - | |
| | 13 | n.c. ¹⁾ | |
| | 14 | TF / TH / KTY + | |
| | 15 | Us | |

1) Do not connect a cable



Unit Design Multi-encoder card option XGH11A, XGS11A

PIN assignment
X64 XGS with SSI
(AV1Y)


| | Terminal | Function for SSI (AV1Y) | Type of connector |
|--|------------------|-------------------------|------------------------|
| | X64 (XGS) | | Sub-D 15-pole (female) |
| | 1 | Signal track A (cos+) | |
| | 2 | Signal track B (sin+) | |
| | 3 | Cycle + | |
| | 4 | DATA + | |
| | 5 | n.c. ¹⁾ | |
| | 6 | TF / TH / KTY - | |
| | 7 | n.c. ¹⁾ | |
| | 8 | DGND | |
| | 9 | Signal track A_N (cos-) | |
| | 10 | Signal track B_N (sin-) | |
| | 11 | Cycle- | |
| | 12 | DATA - | |
| | 13 | n.c. ¹⁾ | |
| | 14 | TF / TH / KTY + | |
| | 15 | Us | |

1) Do not connect a cable



3.18 PROFIBUS XFP11A fieldbus interface option

Terminal assignment

| Front view of XFP11A | Description | DIP switches Terminal | Function |
|---|---|---|---|
|  | RUN: PROFIBUS operation LED (green) | | Indicates that the bus electronics are operating correctly. |
| | BUS FAULT: PROFIBUS error LED (red) | | Indicates PROFIBUS-DP error. |
| | Assignment | | |
| | X31: PROFIBUS connection | X31:1 N.C. X31:2 N.C. X31:3 RxD / TxD-P X31:4 CNTR-P X31:5 DGND (M5V) X31:6 VP (P5V/100 mA) X31:7 N.C. X31:8 RxD/TxD-N X31:9 DGND (M5V) | |
| | ADDRESS: DIP switch for setting the PROFIBUS station address | 2⁰ Significance: 1 2¹ Significance: 2 2² Significance: 4 2³ Significance: 8 2⁴ Significance: 16 2⁵ Significance: 32 2⁶ Significance: 64 nc Reserved | |

Pin assignment

Connection to the PROFIBUS network is established using a 9-pin sub D plug according to IEC 61158. The T-bus connection must be made using a plug with the corresponding configuration.




Figure 31: Assignment of 9-pin sub D plug to IEC 61158

06227AXX

- [1] 9-pin sub D plug
- [2] Signal line, twisted
- [3] Conductive connection over a large area between plug housing and shield

MOVIAXIS® / PROFIBUS connection

As a rule, the XFP11A option is connected to the PROFIBUS system using a shielded twisted-pair cable. Observe the maximum supported transmission rate when selecting the bus connector.

The twisted-pair cable is connected to the PROFIBUS connector using pins 3 (RxD TxD-P) and 8 (RxD / TxD-N). Communication takes place via these two contacts. The RS-485 signals RxD / TxD-P and RxD / TxD-N must be connected to the same contacts in all PROFIBUS stations.



Unit Design

PROFIBUS XFP11A fieldbus interface option

The PROFIBUS interface sends a TTL control signal for a repeater or fiber optic adapter (reference = pin 9) via pin 4 (CNTR-P).



NOTE

If long bus cables are used, the bus stations must have a "hard" common reference potential.


Baud rates larger than 1.5 MBaud

The XFP11A option with baud rates > 1.5 MBaud can only be operated with special 12 MBaud PROFIBUS connectors.

Setting the station address


The PROFIBUS station address is set using DIP switches $2^0 \dots 2^6$ on the option card. MOVIAXIS® supports the address range 0...125.

The default setting for the PROFIBUS station address is 4:



Any change made to the PROFIBUS station address during ongoing operation does not take effect immediately. The change takes effect when the servo drive is switched on again (power supply +24 V OFF/ON).

Example: Setting the PROFIBUS station address 17





3.19 K-Net XFA11A fieldbus interface option

The XFA11A (K-Net) fieldbus interface is a slave module for connection to a serial bus system for high-speed data transfer. Install no more than one XFA11A fieldbus interface per axis module.

Terminal assignment

| | | Brief description | Terminal |
|--|--|---------------------------------|-------------|
| | | K-Net connection (RJ-45 socket) | X31: |
| | | K-Net connection (RJ-45 socket) | X32: |

| | |
|--|--|
| | NOTE |
| | X31 and X32 can be used as either input or output. |

Technical data

| K-Net | |
|-----------------------|----------------|
| Electrical isolation | No |
| Bus bandwidth | max. 50 Mbit/s |
| Connection technology | 2xRJ-45 |
| Max. bus length | 50 m |
| Transmission medium | CAT7 cable |




3.20 EtherCAT XFE24A fieldbus interface option

The XFE24A fieldbus interface is a slave module for connection to EtherCAT networks. Only one XFE24A fieldbus interface can be installed per axis module. The XFE24A fieldbus interface allows MOVIAXIS® to communicate with all EtherCAT master systems. All standardizations of the ETG (EtherCAT Technology Group), such as wiring, are supported.

Technical data

| XFE24A option (MOVIAXIS®) | |
|---------------------------|---|
| Standards | IEC 61158, IEC 61784-2 |
| Baud rate | 100 Mbaud full duplex |
| Connection technology | 2 × RJ45 (8x8 modular jack) |
| Bus termination | Not integrated because bus termination is automatically activated. |
| OSI Layer | EtherNet II |
| Station address | Setting via EtherCAT master |
| Vendor ID | 0x59 (CANopenVendor ID) |
| EtherCAT services | <ul style="list-style-type: none"> • CoE (CANopen over EtherCAT) • VoE (Simple MOVILINK protocol over EtherCAT) |
| Firmware status MOVIAXIS® | Firmware status 21 or higher |
| Tools for startup | <ul style="list-style-type: none"> • PC program MOVITOOLS® MotionStudio from version 5.40 |



- [1] LAM switch
- Switch setting 0: All axis modules except the last one
 - Switch setting 1: Last axis module in the system
- Switch F1
- Switch setting 0: Delivery condition
 - Switch setting 1: Reserved for added functions
- [2] LED RUN; color: Green / orange
- [3] LED ERR; color: Red
- [4] LED link IN; color: Green
- [5] LED link OUT; color: Green
- [6] Bus input
- [7] Bus output

For more information about the EtherCAT fieldbus interface, refer to the "MOVIAXIS® MX Multi-Axis Servo Inverter XFE24A EtherCAT Fieldbus Interface" manual.



3.21 XSE24A EtherCAT-based system bus option

The EtherCAT based system bus XSE24A is an optional, axis-internal expansion module. This module realizes the functionality of an EtherCAT based high-speed system bus for MOVIAXIS®. The XSE24A option module is no fieldbus card. It cannot be used for communication with non-SEW EtherCAT masters.



Analogously to the wiring of the CAN system bus, the system is connected using the RJ-45 plug connection on the top of the unit included in the standard scope of delivery. The CAN system bus is not available when XSE24A is used.



- [1] LAM switch
 - Switch setting 0: All axis modules except the last one
 - Switch setting 1: Last axis module in the system
- [2] Switch F1
 - Switch setting 0: Delivery condition
 - Switch setting 1: Reserved for added functions
- [3] LED RUN; color: Green / orange
- [4] LED ERR; color: Red
- [5] LED link IN; color: Green
- [6] LED link OUT; color: Green



3.22 Terminal expansion board type XIO11A option

| | |
|---|--|
|  | <p>NOTE</p> <p>For information on the ground designations used in the following diagrams, refer to sec. "Terminal assignment" on page 89.</p> |
|  | <p>STOP</p> <p>There is electrical isolation between servo drive and analog inputs and outputs on the XIO card.</p> <p>Please note that there is no electrical isolation between binary inputs and outputs.</p> |

Supply

- The logic of the module is supplied by MOVIAXIS®.
- Binary inputs and outputs are supplied via the DCOM and 24 V terminals on the front. The supply voltage must be protected with a 4 A fuse, see also page 99 in section "UL compliant installation".
- The binary inputs and outputs are electrically isolated from the logic supply.

Module response

Short circuit

In the event of a short circuit of a binary output, the driver will change to pulse mode and in this way protects itself. The status of the binary output does not change.

Once the short-circuit is eliminated, the status of the binary output is that which is output by MOVIAXIS® at that point.

Switching inductive loads

- The module does not contain an internal free-wheeling diode for receiving inductive energies when inductive loads are switched off.
- The inductive load per output is 100 mJ at a frequency of 1 Hz.
- The inductive energy is converted into heat energy in the switching transistor. A voltage of -47 V is present. In this way, the energy can be reduced faster than by using a free-wheeling diode.
- The load capacity of the outputs through inductive loads can be increased by adding an external free-wheeling diode. However, switching off will take considerably longer.




Figure 32: Block diagram for using a free-wheeling diode at the binary output

58750aen

[1] Free-wheeling diode


Parallel connection of binary outputs

Connecting two binary outputs in parallel doubles the rated current.

This module has


- 8 binary inputs,
- 8 binary outputs,
- Electrical isolation between inputs and outputs as well as electronics.

Terminal assignment

| | Designation | Terminal | Connectors | Connector size |
|---|-------------|----------|------------|--|
|  | DCOM | 1 | X21 | COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² |
| | +24 V | 2 | | |
| | DO 0 | 3 | | |
| | DO 1 | 4 | | |
| | DO 2 | 5 | | |
| | DO 3 | 6 | | |
| | DO 4 | 7 | | |
| | DO 5 | 8 | | |
| | DO 6 | 9 | | |
| | DO 7 | 10 | | |
| | DI 0 | 1 | X22 | |
| | DI 1 | 2 | | |
| | DI 2 | 3 | | |
| | DI 3 | 4 | | |
| | DI 4 | 5 | | |
| | DI 5 | 6 | | |
| | DI 6 | 7 | | |
| | DI 7 | 8 | | |




Connection diagram



56935aen

Figure 33: Block diagram of a binary input



56936aen

Figure 34: Block diagram of a binary output





NOTE

It the 24 V supply for the outputs is disconnected, the inputs will not function any longer.



3.23 Terminal expansion board type XIA11A option

| | |
|---|--|
|  | <p>NOTE</p> <p>For information on the ground designations used in the following diagrams, refer to sec. "Terminal assignment" on page 89.</p> |
|  | <p>STOP</p> <p>There is no electrical isolation between servo drive and analog inputs and outputs on the XIA card.</p> |

Supply

- The logic of the module is supplied by MOVIAXIS®.
- Analog inputs and outputs are also supplied by MOVIAXIS®.
- Binary inputs and outputs are supplied via the DCOM and 24 V terminals on the front. The supply voltage must be protected with a 4 A fuse, see also page 99 in section "UL compliant installation".
- The binary inputs and outputs are electrically isolated from the logic supply.

Module response

Short circuit

In the event of a short circuit of a binary output, the driver will change to pulse mode and in this way protects itself. The status of the binary output does not change.

Once the short-circuit is eliminated, the status of the binary output is that which is output by MOVIAXIS® at that point.

Switching inductive loads

- The module does not contain an internal free-wheeling diode for receiving inductive energies when inductive loads are switched off.
- The inductive load per output is 100 mJ at a frequency of 1 Hz.
- The inductive energy is converted into heat energy in the switching transistor. A voltage of -47 V is present. In this way, the energy can be reduced faster than by using a free-wheeling diode.
- The load capacity of the outputs through inductive loads can be increased by adding an external free-wheeling diode. However, switching off will take considerably longer.



Unit Design

Terminal expansion board type XIA11A option




Figure 35: Block diagram for using a free-wheeling diode at the binary output

56942aen

[1] Free-wheeling diode


Parallel connection of binary outputs

Connecting two binary outputs in parallel doubles the rated current.

This module has


- 2 analog inputs (differential),
- 2 analog outputs,
- 4 binary inputs,
- 4 binary outputs,
- Electrical isolation between binary inputs and outputs as well as electronics.

Terminal assignment

| | Designation | Terminal | | |
|---|-------------|----------|-----|--|
|  | DCOM | 1 | X25 | COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² |
| | 24 V | 2 | | |
| | DO 0 | 3 | | |
| | DO 1 | 4 | | |
| | DO 2 | 5 | | |
| | DO 3 | 6 | | |
| | DI 0 | 7 | | |
| | DI 1 | 8 | | |
| | DI 2 | 9 | | |
| | DI 3 | 10 | | |
| | AI 0+ | 1 | X26 | |
| | AI 0- | 2 | | |
| | AI 1+ | 3 | | |
| | AI 1- | 4 | | |
| | AO 0 | 5 | | |
| | AO 1 | 6 | | |
| | DGND | 7 | | |
| | DGND | 8 | | |




Connection
diagram



58752aen

Figure 36: Block diagram of a binary input



58753aen

Figure 37: Block diagram of a binary output



NOTE

The XIA11A analog / binary hybrid module has no internal free-wheeling diodes.



Unit Design

Terminal expansion board type XIA11A option




Figure 38: Block diagram of an analog input

56937aen





Figure 39: Block diagram of an analog output

56940aen




4 Installation

4.1 Mechanical installation

| | |
|---|---|
|  | <p>⚠ CAUTION</p> <p>Do not install defective or damaged modules of the MOVIAXIS® MX multi-axis servo inverter; they can possibly result in injuries or damage parts of the production system.</p> <ul style="list-style-type: none"> Check the MOVIAXIS® MX multi-axis servo inverter modules prior to installing them for external damage and replace any damaged modules. |
|---|---|

- Check to make sure that the delivery is complete.

| | |
|---|---|
|  | <p>STOP</p> <p>The mounting plate in the control cabinet must be conductive over a large area for the mounting surface of the drive system (metallically clean, conductive). An EMC compliant installation of the MOVIAXIS® MX multi-axis servo drive can only be accomplished with a mounting plate that is conductive over a large area.</p> |
|---|---|

- Mark the four bores for the retaining threads on the mounting platform for each unit according to figure 40 and figure 41 and the table listed below. Make the bores with a tolerance according to ISO 2768-mK.
- The lateral distance between two axis systems must be at least 30 mm.
- Units within an axis system are mounted next to another without clearance.
- Cut the matching threads in the mounting platform and fasten the MOVIAXIS® MX multi-axis servo inverter with M6 screws. Screw head diameter 10 mm to 12 mm.

The following table shows the dimensions for the unit housings of the modules viewed from the back.

| MOVIAXIS® MX | Dimensions for housing - MOVIAXIS® MX back views | | | |
|--|--|-----------|-----------|-----------|
| | A [mm] | B [mm] | C [mm] | D [mm] |
| Axis module size 1 | 60 | 30 | 353 | 362.5 |
| Axis module size 2 | 90 | 60 | 353 | 362.5 |
| Axis module size 3 | 90 | 60 | 453 | 462.5 |
| Axis module size 4 | 120 | 90 | 453 | 462.5 |
| Axis module size 5 | 150 | 120 | 453 | 462.5 |
| Axis module size 6 | 210 | 180 | 453 | 462.5 |
| Supply module size 1 | 90 | 60 | 353 | 362.5 |
| Supply module size 2 | 90 | 60 | 453 | 462.5 |
| Supply module size 3 | 150 | 120 | 453 | 462.5 |
| Master module | 60 | 30 | 353 | 362.5 |
| Capacitor module | 150 | 120 | 453 | 462.5 |
| Buffer module | 150 | 120 | 453 | 462.5 |
| 24 V switched-mode power supply module | 60 | 30 | 353 | 362.5 |
| DC link discharge module | see page 65 | | | |



Rear view of MOVIAXIS® MX axis and supply module housing




Figure 40: Drilling template

1) Position of tapped hole

2) Table with dimensions, see page 63

06695AXX



Rear view of MOVIAXIS® MX DC link discharge module housing




Figure 41: Drilling template

06696AXX

1) Position of tapped hole



Installation

Mechanical installation

Minimum clearance and mounting position

- Leave **100 mm (4 in)** clearance at the **top and bottom** for optimum cooling. Make sure air circulation in the clearance is not impaired by cables or other installation equipment.
- **Ensure unobstructed cooling air supply and make sure that air heated by other units cannot be drawn in or reused.**
- Units within an axis system must be lined up without space in between.
- Only install the units **vertically**. You must not install them horizontally, tilted or upside down.




Figure 42: Minimum clearance and mounting position of the units

55481BXX



STOP


Special bending spaces are required according to EN 61800-5-1 for cables with a cross section of 10 mm² and larger. This means the clearance must be increased if required.



4.2 Connection cable for CAN-based system bus with optional master module

The following describes how the signal bus cables of the CAN system bus must be connected in the axis system.

- Insert the CAN1 signal bus plugs **[1]** as described in the following (X9a, X9b):
 - The plugs on each end of the cable are color coded. Insert them in the following order: red (b)- green (a) - red (b) - green (a) - red (b)
 - red (b): Output (RJ45), X9b
 - green (a): Input (RJ45), X9a
 - black (c): MXM output (Weidmüller)
 - black (d): MXP input (RJ45), X9a



NOTE

Important: Install a terminating resistor **[3]** in the last axis module of the axis system (included in the scope of delivery of the supply module).

Shield clamps

- Install the cables properly and screw on electronics shield clamps **[2]**.



Installation

System bus connection cable for several axis systems – CAN-based

4.3 System bus connection cable for several axis systems – CAN-based


- The individual axis systems are connected as described on page 67.
- The CAN connection cable [1] is routed from the red output (X9b) of the last axis module in one axis system to the green input (X9a) of the first axis module of the subsequent system.



NOTE

The mounting plates on which the axis systems are mounted must have a sufficiently large ground connection, e.g. a ground strap.

The lengths of the pre-fabricated system bus connection cables [1] are 0.75 m and 3 m.




NOTE

Important: Install a terminating resistor [2] in the last axis module of the axis system (included in the scope of delivery of the supply module).



4.4 System bus connection cable to other SEW units – CAN-based



NOTE

Establish a common ground potential, e.g. connection of the 24 V ground of the supply voltages.


The lengths of the pre-fabricated connection cables [1] are 0.75 m and 3 m.



4.5 Connection cable EtherCAT-based system bus – optional master module

The following describes how the signal bus cables of the EtherCAT-based system bus must be connected in the axis system.

- Insert the signal bus plugs **[1]** as described in the following (X9a, X9b):
 - The RJ-45 plugs on each end of the cable are color coded. Insert them in the following order: red (b)- green (a) - red (b) - green (a) - red (b)
 - red (b): Output (RJ45), X9b
 - green (a): Input (RJ45), X9a
 - yellow (c): MXM output (RJ45) (MOVI-PLC advanced, UFX41 gateway)
 - black (d): MXP input (RJ45), X9a



[1] Signal bus connection cable

[2] LAM switch

- Switch setting 0: All axis modules except the last one
- Switch setting 1: Last axis module in the system



STOP

The DIP switch LAM **[2]** must be set to "1" at the last axis module in a system. At all other axis modules, it must be set to "0".




4.6 Signal bus connection cable for several axis systems – EtherCAT-based

- The individual axis systems are connected as described on page 70.
- The connection cable [1] is routed from the yellow output (b) of the last axis module in one axis system to the black input (a) of the first axis module of the subsequent system.

| | |
|--|--|
| | NOTE |
| | The mounting plates on which the axis systems are mounted must have a sufficiently large ground connection, e.g. a ground strap. |

The lengths of the pre-fabricated system bus connection cables [1] are 0.75 m and 3 m.



[1] System bus connection cable


[2] LAM switch

- Switch setting 0: All axis modules except the last one
- Switch setting 1: Last axis module in the system

| | |
|--|--|
| | STOP! |
| | The DIP switch LAM [2] must be set to "12" at the last axis module in each system. At all other axis modules, it must be set to "0". |



4.7 Signal bus cables to other SEW units - EtherCAT-based system bus



- [1] System bus connection cable
- [2] Output plug yellow
- [3] Input plug green, RJ45
- [4] SEW stations with SEW EtherCAT interface
- [5] LAM switch
 - Switch setting 0: All axis modules except the last one
 - Switch setting 1: Last axis module in the system

| | |
|--|---|
| | <p>STOP</p> <p>Important: The DIP switch LAM [5] must be set to "1" at the last axis module in a system. At all other axis modules, it must be set to "0".</p> |
|--|---|

The lengths of the pre-fabricated connection cables [1] are 0.75 m and 3 m.

| | |
|--|---|
| | <p>STOP</p> <p>Use only pre-fabricated cables from SEW-EURODRIVE (special assignment) for this connection.</p> |
|--|---|



4.8 Covers and touch guards

Cover

The following units come equipped with a cover:

- Master module (not shown),
- Capacitor module (not shown),
- Buffer module (not shown),
- Supply module; all sizes,
- Axis module; all sizes.
- 24 V switched-mode power supply (not shown),
- DC link discharge module; all sizes, (not shown).




Figure 43: Covers and touch guards

- [1] Cover
[2] Touch guard

The tightening torque for the cover bolts is 0.8 Nm.

When driving in the self-tapping screw, make sure that it screws into the existing thread.

Touch guard cover



⚠ WARNING

Touch guard covers not installed.

Severe or fatal injuries from electric shock.

- The touch guard covers have to be installed on the left-hand and right-hand side of the axis system so that there is no risk of touching any electrically conductive parts.
- Two touch guard covers are included with each supply module.



4.9 Electrical Installation



HAZARD

Dangerous voltage levels may still be present inside the unit and at the terminal strips up to 10 minutes after the complete axis system has been disconnected from the mains.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- Disconnect the axis system from the mains and wait ten minutes before removing the covers.
- After maintenance work, do not operate the axis system unless you have replaced the cover because the unit only has degree of protection IP00 without the cover.



HAZARD

A leakage current $> 3.5 \text{ mA}$ can occur during operation of the MOVIAXIS® MX multi-axis servo inverter.

Severe or fatal injuries from electric shock.

To prevent electric shock:

- With a supply system lead $< 10 \text{ mm}^2$, route a second PE conductor with the same cross section as the supply system lead via separate terminals. Alternatively, you can use a PE conductor with a copper cross section $\geq 10 \text{ mm}^2$ or aluminum $\geq 16 \text{ mm}^2$.
- With a supply system lead $\geq 10 \text{ mm}^2$, it is sufficient to install a PE conductor with a copper cross section $\geq 10 \text{ mm}^2$ or aluminum $\geq 16 \text{ mm}^2$.
- If an earth leakage circuit breaker can be used for protection against direct and indirect contact, it must be universal current sensitive (RCD type B).




NOTE

Installation with reliable isolation.

The unit meets all requirements for reliable isolation between power and electronic connections according to EN 61800-5-1. The connected signal circuits have to meet the requirements according to SELV (**S**afe **E**xtremely **L**ow **V**oltage) or PELV (**P**rotective **E**xtra **L**ow **V**oltage) to ensure reliable isolation. The installation must meet the requirements for reliable isolation.




Temperature sensor in the motor

| | |
|---|---|
|  | <p>! WARNING</p> <p>Dangerous contact voltages at the unit terminals when connecting the wrong temperature sensors.</p> <p>Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> • Connect only temperature sensors with reliable isolation from the motor winding to the temperature evaluation. Otherwise, the requirements for reliable isolation are not met. Dangerous contact voltages may occur at the unit terminals via the signal electronics in case of an error. |
|---|---|

Supply system and brake contactors

- **Use contactors in utilization category AC-3 only** (IEC 158-1) as mains and brake contactors.
- Supply lead: **Cross section according to rated input current I_{mains}** at rated load.
- Motor lead: **Cross section according to rated output current I_R** .
- Electronics cables:
 - One core per terminal 0.20 ... 2.5 mm²
 - 2 conductors per terminal 0.25 ... 1 mm²

Unit output

| | |
|---|--|
|  | <p>STOP</p> <p>An axis module can suffer irreparable damage if you connect capacitive loads to it.</p> <ul style="list-style-type: none"> • Only connect ohmic/inductive loads (motors). • Never connect capacitive loads. |
|---|--|




Figure 44: Only connect ohmic / inductive loads; do not connect capacitive loads 55482AXX



Connecting braking resistors

- Protect the braking resistor with an **overload relay**, see figure 47. Set the **trip current** according to the **technical data of the braking resistor**, see page 199.
- SEW-EURODRIVE recommends to connect the braking resistor as shown in figure 46. Install switch F16 close to the unit system. If an unshielded cable is used for connecting switch F16 with the supply module, keep the length as short as possible. Preferably use a shielded line cable or drilled individual lines as connecting cable to the braking resistor. The cross section must be selected depending on the rated current of the braking resistor.

Operating braking resistors

- The connection leads to the braking resistors carry a **high DC voltage of about 900 V** during rated operation.



! WARNING

The surfaces of the braking resistors will reach temperatures of up to 250° C when the braking resistors are loaded with P_{rated} .

Risk of burns and fire.

- Choose a suitable installation location. Braking resistors are usually mounted on top of the control cabinet.
- Do not touch any braking resistor.

Binary inputs / binary outputs

- The **binary inputs** are electrically **isolated** by optocouplers.



STOP

The **binary outputs** are **short-circuit proof** but **not interference-voltage-proof**. Externally applied voltages can damage the binary outputs.

Permitted voltage supply systems

- MOVIAXIS® is intended for operation on voltage supply systems with a directly grounded star point (TN and TT power systems). Operation on voltage supply systems with a non-grounded star point (for example IT power systems) is permitted. In such a case, SEW-EURODRIVE recommends using earth-leakage monitors employing pulse-code measurement. Use of such devices prevents the earth-leakage monitor mis-tripping due to the earth capacitance of the servo drive.
- No EMC limits are specified for interference emission in voltage supply systems without a grounded star point (IT systems). The effectiveness of line filters is severely limited.



**Electrical
installation**

- Connect the supply terminals of all units in the MOVIAXIS® MX axis system according to the wiring diagrams in section "Wiring diagrams" page 78 ff.
- Check to see that the assignment of multi-axis servo drive and motor is correct according to project planning specification.
- Check to see that all grounding cables have been connected.
- Take suitable measures to prevent the motor starting up inadvertently, for example by removing the electronics terminal block X10 on the axis module. Integrate additional safety features for certain applications to prevent possible injuries and damages to machines.
- Only use closed cable lugs for connection to the screw bolt in order to prevent litz strands from escaping.



4.10 Wiring diagrams

General notes on the wiring diagrams

- You will find more information on the connection of power electronics and control electronics in section "Technical Data", page 187.
- All units within the axis group will have to be connected to each other via the DC link bus connection (PE, + U_z, - U_z), the 24 V bus (X5a, X5b) and the signaling bus (X9a, X9b).
- The supply system contactor "K11" must be installed between the supply system and the line filter.

| | |
|--|---|
| | NOTES <ul style="list-style-type: none"> • Connect the brake rectifier using a separate supply system lead. • Supply via the motor voltage is not permitted. |
| | NOTES <ul style="list-style-type: none"> • If the brake connection and the motor connection are combined in one power cable, the brake line must be shielded separately. The shielding of the power cable and the brake cable must be connected with PE on the motor and servo inverter. • Use a shielded cable as brake cable with separate installation of the brake cable. • Observe the different project specifications for determining the length of brake cable and motor cable. |

Brake rectifier in the control cabinet

Install the connection cables between the brake rectifier and the brake separately from other power cables when installing the brake rectifier in the control cabinet. Joint installation is permitted with shielded power cables only.



Connection of supply module, axis module and capacitor or buffer module

Wiring of power terminals





Figure 45: Wiring diagram MOVIAxis[®] MX, recommended wiring

62359AEN



Connection of supply module, capacitor / buffer module, axis module, brake and 24 V switched-mode power supply module




62360AEN

Figure 46: Example: Wiring diagram MOVIAxis® MX and brake, recommended wiring

- * When F16 (trip contact at overload relay) triggers, K11 must be opened and DI00 "Output stage enable" must receive a "0" signal. F16 is a signal contact, which means the resistor circuit must not be interrupted.
- ** Make sure to provide separate isolation for the brake lines when controlling the brakes with 24 V. We recommend using SEW hybrid cables that offer complete shielding with shielding supports as well as separate shielding for the brake line.
- *** Install the connection cables between the brake rectifier and the brake separately from other power cables when installing the brake rectifier in the control cabinet. Joint installation is only permitted with shielded power cables.



Brake control



62361aen

Figure 47: Brake control variants

Footnotes see page 80.



Connection of supply module

Wiring of control electronics




Figure 48: Wiring diagram control electronics MOVIAxis® MXP supply module

53664AEN

* Connection via supplied pre-fabricated cables.

X9a Signal bus input

X9b Signal bus output



Connection of axis modules

Wiring of control electronics




Figure 49: Wiring diagram control electronics MOVIAxis® MXA axis module

53659AEN

* Connection via supplied pre-fabricated cables.



Connection diagram of binary inputs and outputs




Figure 50: Block diagram of a binary input

60888axx




Figure 51: Block diagram of a binary output

60889axx



Connection of master module component

Wiring




Figure 52: Wiring diagram of MOVIAxis® MXM master module

62224AEN

* Connection via supplied pre-fabricated cables.



STOP

The housing grounding point of the master module must be connected to PE, e.g. at the control cabinet.



Connection of capacitor module component

Wiring of control electronics




Figure 53: Wiring diagram control electronics MOVIAxis® MXC capacitor module

60438AEN

* Connection via supplied pre-fabricated cables.



Connection of buffer module component

Wiring of control electronics




Figure 54: Wiring diagram control electronics MOVIAxis® MXB buffer module

60438AEN

* Connection via supplied pre-fabricated cables.



Connection of 24 V switched-mode power supply module component

Wiring




Figure 55: Wiring of the 24 V switched-mode power supply module


57165aen

* Connection via supplied pre-fabricated cables.


You can find more information on 24 V supply and control electronics in the "MOVIAXIS® Project Planning Manual".



4.11 Terminal assignment

| | |
|---|---|
|  | NOTES |
| | Reference potentials inside the unit: The designation of the reference potentials is listed in the following table: |

| Designation | Meaning |
|-------------|---|
| DGND PE | General reference potential of control electronics. There is a metallic connection to PE. |
| BGND | Reference potential for brake connection |
| RGND | Reference potential for safety relay |
| DCOM | Reference potential for binary inputs |

| | |
|---|--|
|  | NOTES |
| | Connection elements: All connection elements are represented in the following tables as viewed from top. |



Terminal assignment of the MXP supply modules (10 kW, 25 kW, 50 kW, 75 kW)



NOTES

The technical data for the connections of power electronics and control electronics are listed in section 9 "Technical Data".

| | Terminal | Assignment | Brief description |
|------------------------------|---|---|---|
| | X1 1 2 3 4 | PE L1 L2 L3 | Power supply connection (BG1 / 10 kW) |
| | X3 1 2 3 4 | +R -R n.c. PE | Braking resistor connection (BG1 / 10 kW) |
| | X1 1 2 3 4 | PE L1 L2 L3 | Power supply connection (BG2 / 25 kW) |
| | X3 1 2 3 | +R -R PE | Braking resistor connection (BG2 / 25 kW) |
| | X1:PE X1:1 X1:2 X1:3 | PE L1 L2 L3 | Power supply connection (BG3 / 50, 75 kW) |
| | X3:PE X3:1 X3:2 | PE +R -R | Braking resistor connection (BG3 / 50, 75 kW) |
| | X4:PE X4:1 X4:2 | PE +U_Z -U_Z | DC link bus connection |
| | X5a:1 X5a:2 | +24 V_E DGND | Voltage supply for electronics |
| | X5a:3 X5a:4 | +24 V_B BGND | Voltage supply for brake supply |
| | X5b:1 X5b:2 | +24 V_E DGND | Voltage supply for electronics |
| | X5b:3 X5b:4 | +24 V_B BGND | Voltage supply for brake supply |
| | X9a X9b | | a = Input: Signal bus, with green connector b = Output: Signal bus, with red connector |
| Table continued on next page | | | |



| | Terminal | Assignment | Brief description |
|--|-------------|--------------------------|---|
| | 1) X12:1 | n.c. | |
| | X12:2 | CAN_L | CAN bus low |
| | X12:3 | DGND | Reference potential CAN bus |
| | X12:4 | CAN_L | CAN bus low |
| | X12:5 | R _{termination} | Unit internal SBus terminating resistor |
| | X12:6 | DGND | Reference potential CAN bus |
| | X12:7 | CAN_H | CAN bus high |
| | X12:8 | CAN_H | CAN bus high |
| | X12:9 | R _{termination} | Unit internal SBus terminating resistor |

1) Only for CAN-based system bus. No function for EtherCAT-based system bus.

Terminal assignment of the MXA axis modules








| | Terminal | Assignment | Brief description |
|--|----------|--------------------|---------------------------------|
| | X2:PE | PE | Motor connection sizes 1, 2 |
| | X2:1 | U | |
| | X2:2 | V | |
| | X2:3 | W | |
| | X2:PE | PE | Motor connection size 3 |
| | X2:1 | U | |
| | X2:2 | V | |
| | X2:3 | W | |
| | X2:PE | PE | Motor connection sizes 4, 5, 6 |
| | X2:1 | U | |
| | X2:2 | V | |
| | X2:3 | W | |
| | X4:PE | PE | DC link bus connection |
| | X4:1 | +U _Z | |
| | X4:2 | - U _Z | |
| | X5a:1 | +24 V _E | Voltage supply for electronics |
| | X5a:2 | DGND | |
| | X5a:3 | +24 V _B | Voltage supply for brake supply |
| | X5a:4 | BGND | |
| | X5b:1 | +24 V _E | Voltage supply for electronics |
| | X5b:2 | DGND | |
| | X5b:3 | +24 V _B | Voltage supply for brake supply |
| | X5b:4 | BGND | |
| | X6:1 | DBØØ | Brake connection (switched) |
| | X6:2 | BGND | |

Table continued on next page. Footnotes on next page.



Installation

Terminal assignment

| | Terminal | Assignment | Brief description | |
|---|--|---|---|---|
|  1) 1 4 | X7:1 X7:2 X7:3 X7:4 | +24 V RGND C NC | Unit design with one safety relay, optional | |
| | | | Safety relay I (sizes 1-6) Safety relay I (size 1-6), common contact Safety relay I (sizes 1-6), NC contact The connector comes equipped with a coding nose. | |
|  1) 1 4 | X8:1 X8:2 X8:3 X8:4 | +24 V RGND C NC | Design with two safety relays, optional | |
| | | | Safety relay II (sizes 2-6) Safety relay II (sizes 2-6), common contact Safety relay II (sizes 2-6), NC contact The connector comes equipped with a coding nose. | |
|  X9a X9b | X9a X9b | | a = Input: Signal bus, with green plug b = Output: Signal bus, with red plug | |
|  1 11 | X10:1 X10:2 X10:3 X10:4 X10:5 X10:6 X10:7 X10:8 X10:9 | DIØØ DIØ1 DIØ2 DIØ3 DIØ4 DIØ5 DIØ6 DIØ7 DIØ8 | Binary input 1, with fixed assignment "Output stage enable" Binary input 2, freely programmable Binary input 3, freely programmable Binary input 4, freely programmable Binary input 5, freely programmable Binary input 6, freely programmable Binary input 7, freely programmable Binary input 8, freely programmable Binary input 9, freely programmable | Electrically isolated via opto-coupler with reference to DCOM (X10:10). |
| | X10:10 X10:11 | DCOM DGND | Reference potential for binary inputs DIØØ..DIØ8 General reference potential of control electronics | |
|  1 5 | X11:1 X11:2 X11:3 X11:4 X11:5 | DOØØ DOØ1 DOØ2 DOØ3 DGND | Binary output 1, freely programmable Binary output 2, freely programmable Binary output 3, freely programmable Binary output 4, freely programmable Reference potential for binary outputs DOØØ..DOØ3 | |
|  6 1 9 5 | X12:1 X12:2 X12:3 X12:4 X12:5 X12:6 X12:7 X12:8 X12:9 | n.c. CAN_L DGND CAN_L R _{termination} DGND CAN_H CAN_H R _{termination} | CAN2 Bus Low Reference potential CAN bus CAN2 Bus Low Unit internal SBus terminating resistor Reference potential CAN bus CAN2 Bus High CAN2 Bus High Unit internal SBus terminating resistor | |
| |  15 8 9 1 | X13:1 X13:2 X13:3 X13:4 X13:5 X13:6 X13:7 X13:8 X13:9 X13:10 X13:11 X13:12 X13:13 X13:14 X13:15 | S2 (SIN +) S1 (COS +) n.c. ²⁾ n.c. ²⁾ R1 (REF +) TF / TH / KTY - n.c. ²⁾ n.c. ²⁾ S4 (SIN -) S3 (COS -) n.c. ²⁾ n.c. ²⁾ R2 (REF -) TF / TH / KTY + n.c. ²⁾ | Motor resolver connection |
| Table continued on next page. Footnotes on next page. | | | | |



| | Terminal | Assignment | Brief description |
|--|----------|--------------------------|--|
| | X13:1 | Signal track A (COS +) | Connection of motor encoders: sin/cos encoder, TTL encoder |
| | X13:2 | Signal track B (SIN +) | |
| | X13:3 | Signal track C | |
| | X13:4 | n.c. ²⁾ | |
| | X13:5 | n.c. ²⁾ | |
| | X13:6 | TF / TH / KTY - | |
| | X13:7 | n.c. ²⁾ | |
| | X13:8 | DGND | |
| | X13:9 | Signal track A_N (COS -) | |
| | X13:10 | Signal track B_N (SIN -) | |
| | X13:11 | Signal track C_N | |
| | X13:12 | n.c. ²⁾ | |
| | X13:13 | n.c. ²⁾ | |
| | X13:14 | TF / TH / KTY + | |
| | X13:15 | U _S | |
| | X13:1 | Signal track A (COS +) | Hiperface motor encoder connection |
| | X13:2 | Signal track B (SIN +) | |
| | X13:3 | n.c. ²⁾ | |
| | X13:4 | DATA + | |
| | X13:5 | n.c. ²⁾ | |
| | X13:6 | TF / TH / KTY - | |
| | X13:7 | n.c. ²⁾ | |
| | X13:8 | DGND | |
| | X13:9 | Signal track A_N (COS -) | |
| | X13:10 | Signal track B_N (SIN -) | |
| | X13:11 | n.c. ²⁾ | |
| | X13:12 | DATA - | |
| | X13:13 | n.c. ²⁾ | |
| | X13:14 | TF / TH / KTY + | |
| | X13:15 | U _S | |

1) The pin assignment is identical for both connectors (X7 and X8) and they are interchangeable. Coding does prevent an incorrect connection.

2) Do not connect a cable.

Terminal assignment of the MXM master module

| | Terminal | Assignment | Brief description |
|--|----------|--------------------|---|
| | X5a:1 | +24 V _E | Voltage supply for electronics ¹⁾ |
| | X5a:2 | DGND | |
| | X5a:3 | +24 V _B | Voltage supply for brake supply ¹⁾ |
| | X5a:4 | BGND | |
| | X5b:1 | +24 V _E | Voltage supply for electronics ¹⁾ |
| | X5b:2 | DGND | |
| | X5b:3 | +24 V _B | Voltage supply for brake supply ¹⁾ |
| | X5b:4 | BGND | |

1) Only for through transmission

For terminal assignment of the cards see "MOVI-PLC[®] DHP11B Control Card" manual.



Terminal assignment of the MXC capacitor module

| | Terminal | Assignment | Brief description |
|--|--------------------|---|---------------------------------|
| | PE X4:1 X4:2 | PE +U _Z - U _Z | DC link bar |
| | X5a:1 X5a:2 | +24 V _E DGND | Voltage supply for electronics |
| | X5a:3 X5a:4 | +24 V _B BGND | Voltage supply for brake supply |
| | X5b:1 X5b:2 | +24 V _E DGND | Voltage supply for electronics |
| | X5b:3 X5b:4 | +24 V _B BGND | Voltage supply for brake supply |

Terminal assignment of the MXB buffer module

| | Terminal | Assignment | Brief description |
|--|--------------------|---|---|
| | PE X4:1 X4:2 | PE +U _Z - U _Z | DC link bar |
| | X5a:1 X5a:2 | +24 V _E DGND | Voltage supply for electronics ¹⁾ |
| | X5a:3 X5a:4 | +24 V _B BGND | Voltage supply for brake supply ¹⁾ |
| | X5b:1 X5b:2 | +24 V _E DGND | Voltage supply for electronics ¹⁾ |
| | X5b:3 X5b:4 | +24 V _B BGND | Voltage supply for brake supply ¹⁾ |

1) Only for through transmission

MXS 24 V switched-mode power supply module

| | Terminal | Assignment | Brief description |
|--|--------------------|--------------------------------|---------------------------------|
| | PE X4:1 X4:2 | PE n.c. - U _Z | DC link bar |
| | X5a:1 X5a:2 | +24 V _E DGND | Voltage supply for electronics |
| | X5a:3 X5a:4 | +24 V _B BGND | Voltage supply for brake supply |
| | X5b:1 X5b:2 | +24 V _E DGND | Voltage supply for electronics |
| | X5b:3 X5b:4 | +24 V _B BGND | Voltage supply for brake supply |
| | X16:1 X16:2 | +24 V -24 V | External 24 V voltage supply |



4.12 Connecting encoders to the basic unit

| | |
|--|---|
| | NOTES |
| | <p>The core colors specified in the wiring diagrams are in accordance with IEC 757 and correspond to the core colors used in the pre-fabricated cables from SEW-EURODRIVE.</p> <p>You will find detailed information in the "SEW encoder systems" manual. The manual is available from SEW-EURODRIVE.</p> |

Example

| View of the flange sockets in a servomotor | View connection motor encoder to axis module |
|--|--|
| <p style="text-align: right;">58364AXX</p> | <p style="text-align: right;">53934AXX</p> |

- [1] Power connection
[2] Encoder connection

| | |
|--|---|
| | <p>⚠ WARNING</p> |
| | <p>Dangerous contact voltages at the unit terminals when connecting the wrong temperature sensors.</p> <p>Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> Connect only temperature sensors with reliable isolation from the motor winding to the temperature evaluation. Otherwise, the requirements for reliable isolation are not met. Dangerous contact voltages may occur at the unit terminals via the signal electronics in case of an error. |

For the pin assignment, refer to sec. 4.11 "Terminal assignment", paragraph "Terminal assignment of MXA axis modules".



Installation

Connecting encoders to the basic unit

General installation notes

Encoder connection

- Max. cable length: 100 m with a capacitance per unit length ≤ 120 nF/km.
- Core cross section: 0.2 ... 0.5 mm².
- If you do not use a core of the encoder cable: Isolate the core end.
- Use shielded cables with twisted pair conductors and make sure they are grounded on both ends over a large surface area:
 - To the encoder in the cable gland or in the encoder plug,
 - To the servo drive in the housing of the D-sub connector.
- Route the encoder cable separately from the power cables.

Shielding

Connect the shield of the encoder cable over a large area.

At the servo inverter

Connect the shield on the servo drive end in the housing of the sub D connector.



Figure 56: Connect the shield in the sub D connector

01939BXX

On the encoder / resolver

Connect the shield on the encoder side only on the respective earthing clamps, not on the cable gland.

For drives with a plug connector, connect the shield on the encoder plug.

Prefabricated cables

SEW-EURODRIVE offers prefabricated cables for connecting encoders. SEW-EURODRIVE recommends to use these prefabricated cables.

You can find details on prefabricated cables in the "MOVIAXIS® MX Multi-Axis Servo Inverter" catalog.



4.13 Notes on electromagnetic compatibility

Separate cable ducts

- Route **power cables** and **electronics leads** in **separate cable ducts**.

Shielding and grounding

- Only use **shielded control cables**.
- Apply the **shield by the shortest possible route and make sure it is grounded over a wide area at both ends**. To avoid ground loops, you can ground one end of the shield via a suppression capacitor (220 nF / 50 V). If using double-shielded cables (in the case of multi-core cables in some cases with several shielded bunched cables), ground the outer shield on the servo inverter end and the inner shield on the other end.




Figure 57: Examples of correct shield connection using metal clamp (shield clamp) or metal cable gland

00755BXX

Line filter

- Shielding** can also be achieved by laying the cables in **grounded sheet metal ducts or metal pipes**. **Always install the power and signal lines separately**.
- Ground the **multi-axis servo drive** and **all additional devices to meet the high-frequency guidelines**. You achieve this, e. g. through a wide area metal-on-metal contact between the unit housing and ground, for example by means of unpainted control cabinet mounting panels.
- Install the **line filter close to the servo drive** but outside the minimum clearance for cooling.
- Do not switch between the line filter and the MOVIAXIS® multi-axis servo inverter.
- Keep the **length of the cable between the line filter and servo drive to an absolute minimum**, and never more than 600 mm. Unshielded, twisted cables are sufficient. Use also unshielded lines for the supply system lead. Shielded cables must be used for cables longer than 600 mm.
- No EMC limits are specified for interference emission in voltage supply systems without grounded star point (IT systems)**. The **effectiveness of line filters** in IT systems is **severely limited**.



Installation

Notes on electromagnetic compatibility

Interference emission

SEW-EURODRIVE recommends the following EMC measures to limit interference emission:

- **On the supply end:**
 - Select line filters according to the assignment tables of braking resistors and line filters in the MOVIAXIS® catalog. You find notes on the selection of line filters in the "MOVIAXIS® MX Multi-Axis Servo Inverter" project planning manual.
- **On the motor end:**
 - Shielded motor cables.
- **Braking resistor:**
 - You find notes on the selection of braking resistors in the "MOVIAXIS® MX Multi-Axis Servo Inverter" project planning manual.

Interference emission category

Compliance with category "C2" according to EN 61800-3 has been tested on a specified test setup. SEW-EURODRIVE can provide detailed information on request.



! WARNING

This product can cause high-frequency interferences in residential areas which can require measures for interference suppression.



4.14 UL compliant installation

Note the following points for UL-compliant installation:

- Use only copper cables with the temperature range 60 / 75 °C as connection cables.
- The permitted tightening torques for MOVIAXIS® power terminals are:

| Power supply module | Tightening torque | |
|--------------------------|---------------------------------|----------------------------|
| | Mains connection X1 | Braking resistor terminals |
| Size 1 | 0.5 - 0.6 Nm | 0.5 - 0.6 Nm |
| Size 2 | 3.0 - 4.0 Nm | 3.0 - 4.0 Nm |
| Size 3 | 6.0 - 10.0 Nm | 3.0 - 4.0 Nm |
| Axis module | Motor connection X2 | --- |
| Size 1 | 0.5 - 0.6 Nm | --- |
| Size 2 | 1.2 - 1.5 Nm | --- |
| Size 3 | 1.5 - 1.7 Nm | --- |
| Size 4 | 3.0 - 4.0 Nm | --- |
| Size 5 | 3.0 - 4.0 Nm | --- |
| Size 6 | 6.0 - 10.0 Nm | --- |
| DC link discharge module | Braking resistor connection X15 | --- |
| All sizes | 3.0 - 4.0 Nm | --- |

Permitted tightening torques

The permitted tightening torque

- of the **signal terminals** X10, X11 for all units is 0.5 - 0.6 Nm.
- for all **DC link bars** X4 is 3.0 - 4.0 Nm.
- of the **safety relay terminals** X7, X8 for all units is 0.22 - 0.25 Nm.
- of the **terminals for brake connection** X6 for the axis modules is 0.5 - 0.6 Nm.
- of the **terminals for 24 V voltage supply** is 0.5 - 0.6 Nm.
- of the **terminals X61 for multi-encoder cards XGH, XGS** is 0.22 - 0.25 Nm.
- of the **terminals X21, X22, X25, X26 of the input / output cards XIO, XIA** is 0.5 - 0.6 Nm

| | |
|--|---|
| | STOP |
| | Servo inverter can possibly be damaged! <ul style="list-style-type: none"> • Only use the stipulated connection elements and observe the prescribed tightening torques. Otherwise, excessive heat can develop which would damage the MOVIAXIS® multi-axis servo inverter. |

- MOVIAXIS® MX multi-axis servo inverters are suitable for operation in voltage networks with earthed star point (TN and TT networks), a maximum mains current of 42,000 A and a maximum mains voltage of AC 500 V.



Installation

UL compliant installation

- The maximum permitted value of the input fuse is:

| MXP power supply module | 10 kW | 25 kW | 50 kW | 75 kW |
|-------------------------|-------|-------|-------|-------|
| Input fuse | 20 A | 40 A | 80 A | 125 A |

- Only use melting fuses as input fuses.
- If you use cable cross sections that are dimensioned for a smaller current than the rated current of the unit, make sure that the fuse is dimensioned for the used cable cross section.
- For information on selecting cable cross sections, refer to the project planning manual.
- Comply with the country-specific installation regulations in addition to the above notes.
- The plug-in connections of the 24 V supply are limited to 10 A.
- Option cards that are supplied via the 0 V and 24 V terminals at the front must be protected individually or in groups by 4 A melting fuses to UL 248.




NOTES

UL certification does not apply to operation in voltage supply systems without earthed star point (IT systems).




STOP

We recommend protection of the braking resistor with a thermal overload relay to implement an UL approved application design.



5 Startup

5.1 General information


| | |
|---|---|
|  | <p>HAZARD</p> <p>Uncovered power connections. Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> • Install the covers at the modules, see page 73. • Install the touch guards according to the regulations, see page 73. • Never startup MOVIAXIS® if the protective covers and touch guards are not installed. |
|---|---|

Prerequisites


The drive must be configured correctly to ensure that startup is successful. Refer to the "MOVIAXIS® MX Multi-Axis Servo Inverter" system manual for detailed project planning notes and an explanation of the parameters.

The startup functions described in this section are used to set the multi-axis servo drive so it is optimally adapted to the connected motor and to the given boundary conditions. Startup has to take place according to the instructions in this section.


Hoist applications

| | |
|---|--|
|  | <p>HAZARD</p> <p>Risk of fatal injury if the hoist falls. Severe or fatal injuries.</p> <ul style="list-style-type: none"> • MOVIAXIS® is not designed for use as a safety device in hoist applications. Use monitoring systems or mechanical protection devices to ensure safety. |
|---|--|

Mains connection of axis system

| | |
|---|--|
|  | <p>STOP</p> <ul style="list-style-type: none"> • Observe a minimum switch-off time of 10 s for the relay K11. • Do not turn the mains supply on or off more than once per minute! <p>Irreparable damage to the unit or unpredictable malfunctions. It is essential to observe the specified times and intervals.</p> |
|---|--|

Connecting cables, operating switches

| | |
|---|---|
|  | <p>STOP</p> <p>Cables may only be connected and switches may only be operated in a de-energized state. Irreparable damage to the unit or unpredictable malfunctions. De-energize the unit.</p> |
|---|---|



5.2 Supply module settings for a CAN-based system bus

The following settings are necessary:

- The CAN baud rate is set using the two DIP switches S1 and S2 on the supply module, see sec. "Setting the CAN baud rate".
- The 4 DIP switches for setting the system bus are set to "C".
- The axis address is set using the two address switches S3 and S4 on the supply module, see sec. "Setting the CAN axis address". The next axis address will be set automatically based on the first address.




Figure 58: DIP switches and axis address switch on the supply module

61383axx

- [1] DIP switches system bus
- [2] S1, S2: DIP switch for CAN baud rate
- [3] S3: Axis address switch 10^0
- [4] S4: Axis address switch 10^1



Setting the CAN baud rate

The two DIP switches S1 and S2 have been installed in the supply module for setting the CAN baud rate, see figure 58.

| | 125 kBit/s | 250 kBit/s | 500 kBit/s | 1 MBit/s |
|----|------------|------------|------------|----------|
| S1 | | | | |
| S2 | | | | |



NOTES

The default factory setting is 500 kBit / s.

Setting the CAN axis address

The supply module is equipped with two rotary switches S3 and S4 for setting the axis address of the axis system, see Figure 58. Use these rotary switches to set a decimal address between 0 and 99.


| | | |
|------------------|--|--------------------------------|
| S3 rotary switch | | $10^0 \triangleq$ Single digit |
| S4 rotary switch | | $10^1 \triangleq$ Ten digit |

Axis address "23" serves as an example in the figure above.



NOTES

The default factory setting is "1".



Startup

Supply module settings for a CAN-based system bus

The addresses within the axis system are assigned as follows:




Figure 59: Example for address assignment in the axis system


* Terminating resistor only for CAN transmission

In the example, the address of the first axis module is "23". The other axes are assigned addresses in ascending order.

If the axis system includes less than eight axes, the "remaining" addresses will not be assigned.


The axis address set this way is used for the addresses of the CAN communication (part of the signaling bus) or the KNet fieldbus interface option. The axis addresses are assigned only once during startup of the 24V DC voltage supply of the axis system.

The basic addresses are only changed during operation when the axis module is start up again (24 V supply voltage on / off).



Connections and PC diagnostics

| | |
|--|--|
| | <p>NOTES</p> <p>CAN connections should only be implemented in the control cabinet to avoid any difference of potential.</p> |
|--|--|



59095axx

Figure 60: CAN cable length

- [1] Connection cable between PC and CAN interface on the supply module. The connection cable consists of the USB-CAN interface [2] and the cable with integrated terminating resistor [3].
- [2] USB-CAN interface [3] Cable with integrated terminating resistor (120 Ω between CAN_H and CAN_L)

The maximum permitted cable length between terminating resistor and supply module is 5 m.

| | |
|--|---|
| | <p>NOTES</p> <p>Observe the notes of the cable manufacturer on CAN suitability when selecting the cable.</p> |
|--|---|

For more information on communication between PC and the MOVIAXIS® system, refer to page 111.



Startup

Supply module settings for a CAN-based system bus

Connecting CAN cables to the supply module:

Connection assignment of connection and extension cables

The connecting and extension cables between the CAN adapter (see page 111) and the axis system comes equipped with a 9 pin D-sub socket on both ends. The pin assignment of the connection cable with the 9 pin D-sub CAN connector is shown in the following figure.




Figure 61: Connection and extension cable CAN adapter and supply module

Connection assignment of X12 (pin) on the supply module





Figure 62: Pin assignment of the built-in X12 socket at the supply module


53923AEN



Bus terminating resistors for CAN / signal bus connection:

The signal bus connection includes the CAN1 connection between supply module and axis module. The CAN bus requires a terminating resistor.

The following figures show the diagram of possible combinations for CAN communication and the respective position of the terminating resistor (supply module option).



62477aen

Figure 63: Communication via CAN on the supply module


- [1] Connection cable between PC and CAN interface on the supply module. The connection cable consists of the USB-CAN interface [2] and the cable with integrated terminating resistor [3].
- [2] USB-CAN interface [3] Cable with integrated terminating resistor (120 Ω between CAN_H and CAN_L)

For more information on communication between PC and the MOVIAXIS® system, refer to page 111.



5.3 CAN2 bus information and settings

| | NOTES |
|--|---|
| | CAN connections should only be implemented in the control cabinet to avoid any difference of potential. |



62478aen

Figure 64: CAN2 cable length

- [1] Connection cable between PC and CAN interface on the axis module. The connection cable consists of the USB-CAN interface [2] and the cable with integrated terminating resistor [3].
- [2] USB-CAN interface [3] Cable with integrated terminating resistor (120 Ω between CAN_H and CAN_L)


The maximum permitted cable length between terminating resistor and the first axis module is 5 m.

| | NOTES |
|--|---|
| | For the connection between the axis systems, please use pre-fabricated cables from SEW-EURODRIVE. |

For more information on communication between PC and the MOVIAXIS® system, refer to page 111.

Setting the CAN2 axis address


All axis modules are set to address "4" at the factory. Each axis module must be given a CAN2 axis address by means of parameter setting.



Connecting CAN2 cables to the axis modules:

Connection assignment of connection and extension cables


The connecting and extension cables between the CAN adapter (see page 111) and the axis system comes equipped with a 9 pin D-sub socket on both ends. The pin assignment of the connection cable with the 9 pin D-sub CAN connector is shown in the following figure.



62481aen

Figure 65: Connection and extension cable CAN adapter axis module

Connection assignment of X12 (pin) on the axis module



62482aen

Figure 66: Pin assignment of the built-in X12 socket at the axis module


- [1] Terminating resistor not active
- [2] Terminating resistor active



Bus terminating resistors for CAN2 bus connection:

The signal bus connection includes the CAN2 connection between supply module and axis module. The CAN2 bus requires a terminating resistor.

The following figure shows the diagram of possible combinations for CAN communication and the respective position of the terminating resistor (supply module accessory).



62483aen

Figure 67: Communication via CAN2 at an axis module

- [1] Connection cable between PC and CAN interface on the axis module. The connection cable consists of the USB-CAN interface [2] and the cable with integrated terminating resistor [3].
- [2] USB-CAN interface [3] Cable with integrated terminating resistor (120 Ω between CAN_H and CAN_L)




NOTES

Install terminating resistor.

The terminating resistor in the last axis module of the axis system must be activated, see page 109.

For more information on communication between PC and the MOVIAXIS® system, refer to page 111.




5.4 Communication via CAN adapter

For communication between a PC and a MOVIAXIS® system, we recommend using the CAN adapter from SEW-EURODRIVE, which is supplied with a pre-fabricated cable and a terminating resistor. The part no. of the CAN adapter is 18210597.

As an alternative, the CAN adapter "USB Port PCAN-USB ISO (IPEH 002022)" from Peak can be used.

- In case you design the terminals yourself, you must install a terminating resistor of 120 Ω between CAN_H and CAN_L.
- For secure data transmission, you also need a shielded cable suitable for CAN networks.
- There are two communication paths for the axes in the axis system:
 1. Via the 9-pin D-sub connector X12 on the supply module (CAN), see page 106.
 2. Via the 9-pin D-sub connector X12 on the axis module (CAN2) of the axis system, see page 108.

| | NOTES |
|--|--|
|  | <p>Cable connection and cable extension</p> <p>SEW-EURODRIVE recommends connection and extension cables with 1:1 through-connection in shielded design.</p> <p>Observe the notes of the cable manufacturer on CAN suitability when selecting the cable.</p> |



5.5 Settings for EtherCAT-based system bus

Please note the following when using an EtherCAT-based system bus:

- Set the 4 DIP switches on the supply module to setting "E", see Figure 68.
- Switches S1, S2, S3 and S4 plus X12 on the supply modules have no function in this version.
- Set the DIP switch LAM to **setting "1"** at the **last** axis module in the system. At all other axis modules, the LAM DIP switch must be set to "0", see figure 69.
- In this version, X9b does not require a terminating resistor.




Figure 68: DIP switch settings on the supply module

60660axx

- [1] Settings for EtherCAT operation: All 4 switches set to "E"
- [2] DIP switches S1, S2, S3 and S4 and X12 have no functions





Figure 69: DIP switch settings on the axis module

62070axx

- [1] Setting the LAM DIP switch on the **last** axis module of a system
- [2] Setting the LAM DIP switch of all axis modules of a system except for the last axis module



5.6 Description of the startup software


The MOVITOOLS® MotionStudio software package is the SEW engineering tool that you can use to access all SEW drive units. For the MOVIAXIS® series, you can use MOVITOOLS® MotionStudio for startup, parameter setting and diagnostics.

For information such as installation instructions and system prerequisites, refer to the "MOVITOOLS® MotionStudio" manual.

MOVITOOLS® MotionStudio startup software

Once you have installed MOVITOOLS® MotionStudio, you will find the corresponding entries in the WINDOWS start menu at the following path:

"Start\Programs\SEWMOVITOOLS MotionStudio".


|  | NOTES |
|---|--|
| | <p>For a detailed description of the following steps, please refer to the online help in MOVITOOLS® MotionStudio or to the "MOVITOOLS® MotionStudio" manual.</p> |

1. Start MOVITOOLS® MotionStudio.
2. Configure communication channels.
3. Perform an online scan.



5.7 Communication selection

The following figures show the possible access types for the system buses of the unit system.



62084axx

Figure 70: Communication access

- [1] PC-CAN to CAN
- [2] Master module with CAN- / EtherCAT-based system bus
- [3] PC-CAN to CAN2


SEW-EURODRIVE recommends the following communication paths:

- Unit system without master module: CAN
- Unit system with master module + DHP: CAN
- Unit system with master module + DHE/DHF/DHR/UFx: TCP/IP or USB

Use the following table to select the type of communication for startup depending on the unit configuration.

| Hardware configuration of the unit system | Access to | | | | | | | Access via |
|---|---------------------------------|-----|-------|--------|-------------------|-----------------|-------------------|--------------------|
| | Master module | | | | | | Supply module | Axis modules |
| | Via communication interface ... | | | | | | | |
| | PROFIBUS | CAN | RS485 | TCP/IP | USB ³⁾ | RT | CAN ¹⁾ | CAN2 ²⁾ |
| Without master module | | | | | | | x | x |
| Master module + DHP | x | x | x | | | | | x |
| Master module + DHE | | x | (x) | x | x | | | x |
| Master module + DHF/UFx41 ³⁾ | x ⁴⁾ | x | (x) | x | x | | | x |
| Master module + DHR/UFx41 ³⁾ | | x | (x) | x | x | x ⁵⁾ | | x |

- 1) CAN-based system bus
- 2) Only if CAN2 is free for engineering
- 3) In preparation
- 4) Only for operation for DP
- 5) Realtime Ethernet parameter channel via controller



5.8 Sequence in case of new startup

There are two different variants for new startup:

- New startup without master module
- New startup with master module and MOVI-PLC®

New startup without master module

1. Startup
 - Motor startup
 - Controller setting
 - User-defined units
 - System and application limits
2. Standard application
 - Technology editor for single-axis positioning (+ monitor)
3. Scope, recording of
 - Currents
 - Speeds
 - Positions
 - etc.
4. Data management
 - Loading and saving data records of individual axes

New startup with master module and MOVI-PLC®

1. Startup
 - Motor startup
 - Controller setting
 - User-defined units
 - System and application limits
2. Scope, recording of
 - Currents
 - Speeds
 - Positions
 - etc.
3. Data management
 - Loading and saving data records of individual axes



5.9 MOVIAXIS® startup - Single-motor operation

- Start the motor startup by selecting the respective unit in the hardware tree with the right mouse button.
- Double-click on the "Startup" entry.
- Click on "Next" to continue with the startup sequence.




Figure 71: Commencing startup

11796aen



NOTES

There are 3 parameter records available for startup, which can be assigned to 3 different motors.

The parameter record that is to be used for startup can be selected by clicking on it, see figure 72.

Please note that only one parameter record can be started up at one time. If you want to startup several parameter records, this can only be done one after another. This means that when the startup of the first parameter record is completed, the entire startup procedure has to be performed again for the subsequent parameter records.





Figure 72: Initial window MOVIAXIS® MX startup

11797aen



Current settings

The figure below shows the current settings.



11798aen

Figure 73: Overview of current settings


The card types of option cards inserted into the card slots are shown in this figure.

In this example:

- Slot 1: K-Net.
- Slot 2: Empty.
- Slot 3: Empty.



Encoder management of SEW encoders



11833aen


Figure 74: Encoder with electronic nameplate

When using encoders with a **SEW nameplate** (electronic nameplate), i. e. encoders which were programmed according to SEW specifications, you can select one of the following options for data transfer:

- **Accept data:**
The motor data stored in the encoder is read out from the encoder and used for startup. The read-in data cannot be altered.
- **Accept data as suggestion:**
The motor data stored in the encoder is read out from the encoder and made available as a suggestion. The read-in data can be altered.
- **Do not accept data:**
The motor data stored in the encoder is not used.



Encoder management



11799aen

Figure 75: Encoder management

Encoder management allows you to assign the yellow-marked encoders offered in the encoder pool to the individual parameter records or motors. If several motors are to be operated on one axis module, you need additional multi-encoder cards (option).

- Click on the required encoder and hold the left mouse button down to drag the encoder to the intended parameter record. In the example above, encoder 1 is assigned to parameter record 1.

Encoder selection

The encoder pool represents the maximum three physical MOVIAXIS encoder inputs. Encoder 1 is the encoder input of the basic unit. Encoders 2 and 3 can be expanded with multi-encoder cards.

- Use each encoder only once.


- **Tachometer:**

Encoders in the "Motor encoder" column are always the "Actual speed sources" and thus tachometers.

- **Position encoder:**

Encoders in the two "Distance encoder" columns can also be used as position encoders.


Only one encoder can be the "Actual position source" per parameter record. For this purpose, the "Source actual pos." checkbox must be ticked.



SEW designation of encoders

Double-click on an encoder symbol to open the "Encoder selection" submenu.

In this menu, the SEW designations of the encoders are listed. They are necessary for selecting the encoders.



11800aen

Figure 76: SEW designation of the encoders

- Click on the individual encoder designations to set the encoder type that is mounted on the motor. A requirement for this is that the function "Load data permanently" is **not** selected.



NOTES

The encoder type is specified on the nameplate of the motor.

Encoder data assignment:

- Resolver:** RH1M/ RH1L / RH3L/ RH3M
- Hiperface:** ES1H / ES2H / EV1H /AS1H / AV1H
- Sine/cosine encoder:** EH1S / ES1S / ES2S / EV1S / EV2S
- Hiperface linear encoder:** AL1H
- Non-SEW encoder**



Startup MOVIAXIS® startup - Single-motor operation

Encoder data

You can enter encoder data in this menu.

However, you cannot enter data if the encoder is defined as "motor encoder".




Figure 77: Encoder data

11801aen



Approved
encoders

You can view the list of approved encoders by selecting "Approved encoders".




Figure 78: Approved encoders

11802aen



Encoder management for non-SEW encoders

11803aen

Figure 79: Encoder management / non-SEW encoder


| Input data | Description |
|---------------------------|---|
| Mechanically | <ul style="list-style-type: none"> • Rotational • Linear |
| Electrical | <ul style="list-style-type: none"> • Hiperface • Resolver • TTL • HTL • sin/cos |
| Counting direction | There are two counting directions: <ul style="list-style-type: none"> • Normal - Standard. Encoder rotates with motor (encoder mounted on motor shaft). • Inverted - Encoder rotates in opposite direction of motor (encoder not mounted on motor shaft). |



| Input data | Description |
|--------------------------------|---|
| Numerator / denominator factor | <p>This factor determines the encoder resolution. The value that has to be entered depends on the encoder type.</p> <ul style="list-style-type: none"> • Non-SEW TTL, non-SEW sin/cos, non-SEW Hiperface $\frac{\text{Factor numerator encod.1}}{\text{Factor denominator encod.1}} = \frac{\text{Encoder resolution}}{\text{Revolution}}$ <p>Example: sin / cos encoder: Factor numerator encoder1 = 1024 Factor denominator encoder1 = 1</p> • Non-SEW resolver $\frac{\text{Factor numerator encoder1}}{\text{Factor denominator encoder1}} = \frac{\text{Number of pole pairs}}{1}$ <p>Example: Resolver, 1 pole pair: Factor numerator encoder1 = 1 Factor denominator encoder1 = 1</p> • Non-SEW linear sin/cos Signal period of the encoder Example: AL1H Lincoder, signal period 5 mm |



Selection menu



11804aen

Figure 80: Startup options

You have three options for startup in the selection menu:

- **Complete startup:**

This is the setting option for the initial startup. This part of the program stores the information for motor, speed controller as well as machine and system data.

| | NOTES |
|--|--|
| | <p>The following setting options "Optimization of the controller" and "Machine and system data" are subprograms of the MOVIAxis® MX startup. These setting options can be selected and executed following a "complete startup" only.</p> |

- **Optimization of the controller:**


Use this setting option to further optimize the speed controller if a complete startup has already been performed.

- **Machine and system data:**

This setting option is a part of the complete startup and refers to the machine system data only, such as user-defined units, machine and application limit values.



System configuration



11805aen

Figure 81: System configuration

Here, you can select whether several drives work with one load, or whether several motors are connected to one axis.

- **Single drive**

One drive works with one load without the help of other drives (slaves).

- **Several identical drives at one inverter**

The drives must be connected rigidly together in order to operate several drives at one servo drive. One drive is equipped with encoder feedback. The other motors are running in the same rotating field. When synchronous motors are used, the two rotors have to be aligned in addition. Please also refer to the SEW documentation "10509011 / EN Multi-Motor Drives" manual.


- **Number of connected slaves**

With this setting, each motor has its own servo inverter but operates on the same load. This has an effect on the controller parameters and the external load. Please note that two rigidly connected drives acting on one load means that the drives might interfere with one another in the worst case. This can lead to error messages at the servo inverter. Please contact SEW-EURODRIVE if you have any questions on this topic.



Sequence of a complete startup

Motor selection




11806aen

Figure 82: Motor selection menu

In this menu, you can set the motor to which the MOVIAXIS is connected. The motor type of SEW motors is indicated on the nameplate.

If the motor is a non-SEW motor, activate the radio button "Non-SEW motor." The next menu view will prompt you to load an XML file created by SEW-EURODRIVE.



| Motor type | Description |
|---------------|---|
| Non-SEW motor | <p>The connected motor is a non-SEW motor. You will need a file created by SEW-EURODRIVE with the motor specifications to use this option.</p> <p>If the function "Non-SEW motor" is selected, you will see the "Load motor file" button. Select the non-SEW motor from the motor database.</p> <p>If the motor is a synchronous motor, you will have to enter the following motor data:</p> <ul style="list-style-type: none">• Type designation• Pole pairs• Rated speed• Rated torque• Rated current• Rated voltage• Maximum torque• Maximum speed• Mass moment of inertia• Branch inductance• Brake yes/no <ul style="list-style-type: none">• Brake mass moment of inertia• Brake release time• Brake application time <p>For asynchronous motors, additional data is required. The motor must be measured at SEW-EURODRIVE.</p> |

Nameplate

Figure 83: Motor selection nameplate

11807aen

- Enter the motor data listed on the nameplate of the motor in the drop-down menu.

| | |
|--|---|
| | NOTES |
| | <p>In case of Hiperface encoders with electronic nameplate, the drop-down menu will be filled automatically and displayed without the user being able to make any changes. For all other types of encoders, the data listed in the following table have to be entered from the motor nameplate.</p> |



| Input data | Description |
|-----------------------------------|--|
| Motor | <p>Enter the motor type without further information, such as gear unit, encoder, brake or motor protection. For example:</p> <ul style="list-style-type: none"> Nameplate with gear unit PSF311RCM71S /BR /RH1M /SB51 → motor type CM71S; Nameplate without gear unit CFM90M /BR /RH1M /SB51 → motor type CM90M. |
| Rated voltage | The rated motor voltage is the maximum voltage that the motor winding can handle. The rated motor voltage refers to the rated mains voltage. For synchronous motors, the value is indicated as U_{max} on the nameplate. |
| Rated motor speed | The rated motor speed corresponds to the speed class on the nameplate. |
| Rated power supply voltage | Enter the rated supply voltage, e. g. 400 V |
| Temperature sensor type | <p>"Temperature sensor type" of the motor on the nameplate specifies which sensor is used for implementing the motor protection:</p> <ul style="list-style-type: none"> No sensor; TH Thermostat (bimetallic switch); TF Thermistor sensor (PTC thermistor); KTY thermistor for detection of motor temperature. <p>The KTY setting means the thermal motor model is activated in MOVIAXIS with SEW motors. The thermal motor model protects the motor thermally together with the KTY temperature sensor.</p> <p>If the motor with KTY is a non-SEW motor, an I²t model is started if the XML file of the non-SEW motor contains thermal data. The KTY only provides an initial value. Afterwards, the calculation model is responsible for motor protection.</p> <p>If the motor with KTY is a non-SEW motor and the XML file of the non-SEW motor does not contain any thermal data, then a KTY limit temperature shut-down is activated.</p> |
| Response | <p>Here you can set the shutdown response of the MOVIAXIS® MX multi-axis servo drive in case of a motor overtemperature. The following settings are available:</p> <ul style="list-style-type: none"> No response - Motor overtemperature is ignored. Display only - the error is only displayed in the 7-segment display; the axis keeps on running. Output stage inhibit / pending - The axis switches to FCB controller inhibit (motor coasts to a stop). The axis performs a "warm start" following a "reset" (see chapter Operating Mode Display in the operating instructions). The reset time is reduced to a minimum because there is no booting involved. Emergency stop / pending - The axis decelerates using the emergency stop ramp. The axis performs a "warm start" following a "reset" (see chapter Operating Mode Display in the operating instructions). The reset time is reduced to a minimum because there is no booting involved. Stop at application limits / pending - The axis decelerates using the application ramp. The axis performs a "warm start" following a "reset" (see chapter Operating Mode Display in the operating instructions). The reset time is reduced to a minimum because there is no booting involved. Stop at system limits / pending - The axis decelerates using the system ramp. The axis performs a "warm start" following a "reset" (see chapter Operating Mode Display in the operating instructions or system manual). The reset time is reduced to a minimum because there is no booting involved. |
| Forced cooling fan | Use this field to enter whether the motor is equipped with a forced cooling fan. The entered value will be used for the thermal motor model for motor protection. |
| Brake | Use this field to enter whether the motor is equipped with a brake. This will activate the brake function. |



Monitoring




Figure 84: Menu setting for monitoring

11808aen



NOTES

The value in the left column of the input menu is a recommendation, while the value in the right column is the current value of the MOVIAxis® MX multi-axis servo drive.


Click on

- "→" buttons to accept individual recommendations,
 - "Accept" button to accept all recommendations in one step.
- Enter the general MOVIAxis® MX control parameters according to the following table.

| Input data | Description |
|---|---|
| Speed monitoring and deceleration time n-monitoring | The speed required by the setpoint can only be achieved if there is sufficient torque available to meet the load requirements. Once the current limit has been reached, the MOVIAxis® MX multi-axis servo drive assumes that the torque has reached its maximum value. The desired speed cannot be attained. Speed monitoring is triggered if this situation continues throughout the duration of the specified delay n-monitoring . |
| Current limit | The current limitation refers to the apparent output current of the multi-axis servo drive. |



Speed controller setting



11809aen

Figure 85: Speed controller menu

- Enter the values for the speed controller.

| Input data | Description |
|--|---|
| Moment of inertia J_0 of the motor | Display field for the mass moment of inertia value for the motor previously selected. |
| Load inertia | Input field for maximum external moment of inertia converted for the motor shaft. In "CFC" and "SERVO" operating modes, you have the option to determine the load mass moment of inertia automatically during a travel process. Click on the "Determine moment of inertia" button to determine the load mass moment of inertia. Startup must be performed at least once in order to use this function. In addition to that, a ramp must be traveled cyclically. |
| Clearance of load | Use the slider to set the clearance of the drive train. |
| Time interval external control | Enter the time interval of the external controller. This value is required for all FCBs that generate a setpoint in an interpolated manner (external ramp generator) as well as for analog setpoint selection. Note: The input value is not relevant for internal setpoint selection, e. g. FCB09 Positioning. |
| Scanning frequency n/X control | Use this field to specify the required scanning frequency of the speed / position controller. The default setting 1 ms should only be shortened for extremely dynamic applications. |
| Stiffness | Use the slider to set the stiffness of the speed controller. The value for the stiffness depends on the power transmission (direct drive high, toothed belt low) and is a measure for the velocity of the speed control loop. The value for the standard setting is 1. You enter the stiffness of the speed control loop either with the sliding scale or the input field. <ul style="list-style-type: none"> • If you increase the stiffness value, you will also increase the control rate. SEW-EURODRIVE recommends to increase the value during startup in small increments (0.05) until the control loop starts oscillating (motor noise). You will then have to lower the value. This approach ensures an optimum setting. • If you reduce the stiffness value (< 1), the control rate is reduced and the servo lag increases. |

*Block diagram
speed controller*




Figure 86: Block diagram speed controller

11810aen

Speed control parameters

In addition, you can set the speed controller parameters to "Classic".




Figure 87: Parameter speed control menu

11811aen



NOTES

The value in the left column of the input menu is a recommendation, while the value in the right column is the current value of the MOVIAXIS® MX multi-axis servo drive.

Click on

- "→" buttons to accept individual recommendations,
- "Accept" button to accept all recommendations in one step.

| Input data | Description |
|--|---|
| P-gain speed controller | Gain factor of the P-component of the speed controller. |
| Time constant speed controller | Integration time constant of the speed controller. The I-component reacts inversely proportionate to the time constant, i.e. a large numerical value results in a small I-component, although 0 = no I-component. |
| Filter speed actual value | Filter time constant of the actual speed value filter. |
| Speed setpoint filter | Speed ramp will be filtered, graduated setpoint entry or interfering impulse at analog input can be smoothed. |
| Filter acceleration precontrol | Filter time constant of acceleration precontrol. This constant influences the control response of the speed controller. The differentiator is programmed. |
| P-gain position controller | Setting value for the P controller of the position control loop. |
| Amplification acceleration precontrol | Amplification factor of acceleration precontrol. This parameter improves the control response of the speed controller. |
| Amplification speed precontrol | Amplification factor of velocity precontrol. This parameter improves the control response of the position controller. |

Axis configuration




Figure 88: Axis configuration menu

11812aen

MOVIAXIS® offers four user-specified units for the following variables:

- Travel distance,
- Velocity,
- Acceleration,
- Torque (not in motor startup → parameter tree).

A numerator, denominator and the decimal places for each variable are loaded to the axis module. The decimal places are only needed for display in the MotionStudio. They are neither used for converting user-defined units nor for bus communication.



"Basic configuration" button

- Travel distance

Unit: Rotations (of the motor), 4 decimal positions

Example:

| Setpoint | Traveled distance | Display in MotionStudio |
|----------|-----------------------|-------------------------|
| 10000 | 1 motor revolution | 1.0000 |
| 15000 | 1.5 motor revolutions | 1.5000 |

Once motor startup has been executed, the following values are written to the axis module (conversion 16-bit increments / rotation):

- User-defined unit position numerator = 4096
- User-defined unit position denominator = 625
- User-defined unit position resolution = 1E-04

- Velocity

Unit: 1/min, 3 decimal places

Example:

| Setpoint | Velocity | Display in MotionStudio |
|----------|------------|-------------------------|
| 1000000 | 1000 1/min | 1000.000 |
| 2345000 | 2345 1/min | 2.345 |

Once motor startup has been executed, the following values are written to the axis module:

- User-specified unit velocity numerator = 1
- User-specified unit velocity denominator = 1
- User-specified unit velocity resolution = 1E-03

- Acceleration

Unit: 1/(min × s) speed change per second, 2 decimal places

Example:

| Setpoint | Acceleration | Display in MotionStudio |
|----------|-------------------|-------------------------|
| 6500000 | 65000 1/(min × s) | 65000.00 |
| 300000 | 3000 1/(min × s) | 3000.00 |

Once motor startup has been executed, the following values are written to the axis module:

- User-specified unit acceleration numerator = 100
- User-specified unit acceleration denominator = 1
- User-specified unit acceleration resolution = 1E-02

- Torque: in preparation, currently only available via parameter tree.
- Jerk: is fixed.



Startup MOVIAXIS® startup - Single-motor operation

Example

Proceed as follows to set user-defined units other than the basic configuration.

Specification

- Position in (mm \times 1E-01)
- Velocity in 1/min
- Acceleration in (m/s² \times 1E-02)

The rotary motion is turned into a linear motion with a spindle (pitch = 5 mm).





Figure 89: Example for setting user-defined units

62492aen



Application and system limits



11813aen

Figure 90: Application and system limits menu

The application and machine limit values refer to the set user-specified units, see figure 89. The user-specified units selected previously are shown in the illustration and cannot be altered.

The fields on the right refer to the download value in the axis, converted to the user-specified unit. The fields on the left are calculated default values.

The following values are the basis for the basic configuration and the delivery status:

| Variables | Limit values |
|---|--|
| System limit values (machine limit values) | |
| VmaxSys | 10000 1/min, corresponds to the maximum speed possible in the axis module |
| a_maxSys | 3000 1/(min × s) acceleration ramp |
| b_maxSys | 3000 1/(min × s) deceleration ramp |
| Application limit values | |
| VmaxApp | 10000 1/min, corresponds to the maximum speed possible in the axis module |
| a_maxApp | 3000 1/(min × s) acceleration ramp |
| b_maxApp | 3000 1/(min × s) deceleration ramp |
| Emergency stop deceleration | |
| b_maxAppNotStop | 3000 1/(min × s) deceleration ramp, emergency stop ramp is mainly used for error response. |



Download





Figure 91: Download menu

11814aen

- Press the "Finish" button to download the settings to the axis module.
- Close the window to finish startup.



Pxxx controller parameters

Pxxx speed control Speed control only parameter set 1.

The setting of all parameters important for speed control is supported by the startup functions of the startup manager. Direct alterations to individual controller parameters are reserved for optimization by specialists.




Figure 92: Basic structure of the speed control loop

06728AEN

P-gain speed controller Gain factor of the P-component of the speed controller.

Time constant speed controller Integration time constant of the speed controller. The I-component reacts inversely proportionate to the time constant. A large numerical value results in a small I-component, although 0 = no I-component.

Filter speed actual value Filter time constant of the actual speed value filter.

Speed setpoint filter Speed ramp will be filtered, graduated setpoint entry or interfering impulse at analog output can be smoothed.

Filter acceleration precontrol Filter time constant of acceleration precontrol. This constant influences the control response of the speed controller. The differentiator is programmed.


P-gain position controller Setting value for the P controller of the position control loop.

Amplification acceleration pre-control Amplification factor of acceleration precontrol. This factor improves the control response of the speed controller.

PWM frequency Setting the PWM frequency.



5.10 MOVIAXIS® startup - Multi-motor operation

| | NOTES |
|---|--|
|  | <p>In this section, the startup menus are described which require special settings for multi-motor operation.</p> <p>The overall startup is performed as described in sec. "MOVIAXIS® startup - Single-motor operation", page 116.</p> |

For multi-motor operation, one or two multi-encoder cards are required.

Multi-encoder cards expand the MOVIAXIS® system for evaluation of additional encoders. Two different multi-encoder cards are available. They have to be selected according to the encoder that is to be evaluated. An analog, differential input (± 10 V) is also available on the multi-encoder cards.

Areas of application


The multi-encoder card can be used for the following areas of application:

- Positioning, either directly using the external encoder or with the motor encoder.
- Multi-motor operation (max. 3 motors).
- SSI absolute encoder evaluation.
- Operation of non-SEW motors that are equipped with EnDat encoders.
- Systems with slip.
- Compensation of rope and belt elongation.
- Reading in of master values for cam and synchronous operation systems.
- Analog setpoint specification and encoder simulation of the actual position to the controller
- General use of the differential analog input ± 10 V, for example, for torque setpoint or torque setpoint specification.



Current settings

The figure below shows the current settings.



11815aen

Figure 93: Overview of current settings


The card types of option cards inserted into the card slots are shown in this menu.

In this example:

- Slot 1: Multi-encoder card XGS
- Slot 2: Not assigned
- Slot 3: Multi-encoder card XGS



Encoder management



11818aen

Figure 94: Encoder management

Encoder management allows you to assign the yellow-marked encoders offered in the encoder pool to the individual parameter records or motors. If several motors are to be operated on one axis module, you need additional multi-encoder cards (option).

- Click on the required encoder and hold the left mouse button down to drag the encoder to the intended parameter record. In the example above, encoder 1 of the type AS1H is defined as motor encoder and encoder 2 of the type AV1H as external distance encoder.

Encoder selection

The encoder pool represents the maximum three physical MOVIAXIS® encoder inputs. Encoder 1 is the encoder input of the basic unit. Encoders 2 and 3 can be expanded with multi-encoder cards.


- Use each encoder only once.
- **Tachometer:**
Encoders in the "Motor encoder" column are always the "Actual speed sources" and thus tachometers.
- **Position encoder:**
Encoders in the two "Distance encoder" columns are position encoders.
Encoders in the "Motor encoder" column can also be position encoders. For this purpose, the "Source actual pos." checkbox must be ticked.
- Several encoders can be prepared as position encoders.
- But only one encoder can be the "Actual position source."



Encoder signal processing when using encoder emulation

Encoder emulation can be used to make encoder signals available to a higher-level controller via the emulation output terminals.

Encoder emulation is independent of the connected encoder type.



11817aen

Figure 95: Encoder signal processing

- [1] Emulation source direct is without delay.
- [2] Emulation source with signal fan-out: 100 µs

Click on the button **[Settings encoder card slot 1]** or **[Settings encoder card slot 2]** in the menu item "Option cards" to set the emulation source or to assign the encoder that is to be used for incremental encoder simulation. In the example above, this is encoder 2.

The signal processing of the connected encoder can be set as follows:

- Emulation source direct: Encoder 1 / 2
- Emulation source encoder 1 / 2: With signal fan-out, increments per motor revolution.



Emulation source direct

The signals of the connected encoder are looped through to emulation directly.

| | NOTES |
|--|--|
| | <p>If a resolver is connected to the encoder input of the basic unit, this cannot be used as "emulation source direct". This is possible in connection with software emulation only.</p> |

With signal fan-out, increments per motor revolution

This selection uses software emulation.

The following settings are possible in "increments per motor revolution":
64 / 128 / 256 / 512 / 1024 / 2048 / 4096.


The output increments per motor revolution at the emulation terminal are independent of the resolution of the connected encoder.

5.11 Application examples


Example 1: Rotatory encoder as distance encoder

Applications: E.g. non-linear transmission elements, such as crank arms, flying saws, master value axes, such as electronic cams.


In this example, the position actual value of the absolute encoder designated as encoder 2 is used directly for position control. The encoder ratios for motor encoder (encoder 1) and distance encoder (encoder 2) must be set during startup. In this example, the encoder ratio between encoder 1 and encoder 2 is "1:5". The encoder ratio between encoder 1 and encoder 2 is automatically determined by moving the system. It can also be calculated and entered manually.




Settings:



Encoder 2 must be set as "Source actual position".



Selection and settings of the encoder type.




Setting the ratio between encoder revolutions and motor revolutions directly, i.e. by calculation or moving the system.

Example 2: Linear encoder as position encoder

Applications: E.g. storage and retrieval units (because of the slip of the carrying wheels), for systems with backlash.


The travel distance of the linear distance encoder must be entered for one motor revolution. The travel distance for one motor revolution is determined automatically, but it can also be calculated and entered manually.






Settings:


Selection and settings of the encoder type using the example of the linear encoder AL1H.



Encoder 2 must be set as "Source actual position".




Selection and settings of the used AL1H encoder.




"Travel distance on encoder per motor revolution" can be entered here directly after calculating it manually, or be determined by moving the system.

"Determined automatically" can only be selected under the menu item "Axis configuration", see next figure.



Configuration of the axis.




Double-click on encoder 2 "AL1H" to enter the "Travel distance on encoder per motor revolution". It is possible to enter the travel distance by clicking on the "Direct entry" button after calculating it manually, or to determine it by clicking on "Move the system" or by selecting "Determined automatically". In this example, the "Travel distance on encoder per motor revolution" = 3141µm.





Example 3: Multi-motor operation

Application: In applications with several axes, which have the same output torque and which are **not** operated at the same time.

Up to 3 motors can be connected to one axis module. For this purpose, 2 additional multi-encoder cards must be inserted into the axis module, see following figure. The axis module switches the power for the motors to the currently active motor.



- [1] Motor encoder 1, multi-encoder card 1
- [2] Motor encoder 2, multi-encoder card 2
- [3] Motor encoder 3 on basic unit



Encoder 1 must be set as "Actual position source" for parameter record 1.

Encoder 2 must be set as "Actual position source" for parameter record 2.

Encoder 3 must be set as "Actual position source" for parameter record 3.

The individual parameter records can only be started up one after another and only once the startup process has been completed.

The individual parameter records can be selected via parameters, please refer to the parameter description in the "MOVIAXIS® MX Multi-Axis Servo Inverter" project planning manual.




5.12 PDO Editor

Structure and data flow

Use the PDO Editor to set the process data.

You can write setpoints, such as velocity or position, as 16-bit process data into the PD-IN buffer of MOVIAXIS® via a bus system, e.g. a fieldbus. You can specify these setpoints in freely definable user-specific units, e.g.

- [m/s],
- [mm],
- [cycles/min]



57601aen

Figure 96: PDO process data flow

This process data is further processed as double word depending on how the subsequent PD-IN channel is configured. The user-specified units are converted into system units and transferred to the relevant FCBs, see figure 96. MOVIAXIS® offers 16 PD-IN channels.


Depending on the process data configuration, actual values such as speed and position can be converted into user-specified units via 16 32-bit wide PD-OUT channels and are transferred to the connected bus system via 16 process data buffers.

Information on the status of the axis, such as

- "Ready for operation",
- "Motor standstill",
- "Brake released"

can also be written to a process data word of the PD-OUT buffer via a status word. The information can also be processed by a higher-level controller via the connected bus.

Four configurable status words are available, see figure 96.

**Parameter setting example**

This example shows how to set the parameters of a PROFIBUS connection for speed control.

Setting the fieldbus interface parameters

A mouse-click on an IN buffer opens its configuration interface. The communication option is selected as data source for a PROFIBUS connection.

The following three process data words are used in the example:

- FCB activation,
- Ramp,
- Speed

To being able to test the example without PROFIBUS, the update function is first set to off. The configuration interface for these settings looks as follows:

Settings IN buffer 0

Basic settings

Data source: Communication option

Data block start: 0

Number of data words: 4

Time-out interval [ms]: 20.000

Update: Off

Configuration error: No fault

PDO never received before: ☐

CAN

Message-ID: 0

Data acceptance with Sync: No

Endianness: Big Endian

Communication option

PDO-ID: 0

Sender address: 0

11828aen

Figure 97: Settings IN buffer 0



Setting the parameters of the control word and the IN process data

A single click on one of the control words, in the example control word 1, opens the configuration interface and selects the FCB / instance layout. The IN process data channel 0 is assigned the system variable "velocity", and channel 1 the system variable "acceleration."




Figure 98: Settings control word and IN process data


11829aen



Assigning the input buffer to the system variables

Next, the words of the IN buffer must be assigned to the control word 1 and the IN process data.

In the example, the first word of the IN buffer is assigned the FCB number, the second word is assigned the speed, and the third word the ramp. You can assign the associated words using drag & drop.




11830aen

Figure 99: IN process data interface, conversion of internal system variable

Setting the FCB parameters

Clicking "FCB" opens the configuration interface of the FCBs. To be able to control the speed controller via fieldbus, the setpoint sources for velocity and acceleration values are set to process data buffer channel 0 or channel 1 in the FCB05.



11831aen

Figure 100: Overview of FCBs



Testing the
configurations

The configuration is now complete and can be tested. You can change the words in the detail view using the keyboard as long as IN buffer update is disabled.




Figure 101: Testing the configuration

Once buffer update is enabled, see figure 97, the words are automatically updated with the values of the bus.

| | NOTES |
|--|--|
| | The update function is automatically enabled when the unit is restarted and has to be disabled, if required. |




5.13 Parameter list

You find a parameter list with descriptions in the "MOVIAXIS® MX Multi-Axis Servo Inverter" project planning manual.



6 Operation


6.1 General information

| | |
|---|--|
|  | <p>HAZARD</p> <p>Dangerous voltages at cables and motor terminals Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> • When the unit switch is in the ON position, dangerous voltages are present at the output terminals as well as any connected cables and motor terminals. This also applies even when the unit is inhibited and the motor is at standstill. • The fact that the operation LED is no longer illuminated does not indicate that the MOVIAXIS® MX multi-axis servo drive is no longer connected to the mains and is de-energized. • Before you touch the power terminals, check to see that the MOVIAXIS® MX multi-axis servo drive has been disconnected from the mains. • Observe the general safety notes in section 2 and the notes in sec. "Electrical Installation" on page 74. |
|  | <p>HAZARD</p> <p>Risk of crushing if the motor starts up unintentionally. Severe or fatal injuries.</p> <p>Mechanical blocking or internal safety functions of the unit can cause a motor standstill. Removing the cause of the problem or performing a reset can result in the drive re-starting on its own.</p> <ul style="list-style-type: none"> • Ensure that the motor cannot start inadvertently, for example, by removing the electronics terminal block X10. • Additional safety precautions must be taken depending on the application to avoid injury to people and damage to machinery. |
|  | <p>STOP</p> <p>The motor output of the multi-axis servo inverter may only be switched or disconnected when the output stage is inhibited.</p> |



6.2 Displays of the supply and axis modules

Operating display of the 7-segment display



- The two 7-segment displays indicate the operating status of the supply modules and axis modules.
- All settings and functions relating to startup of the axis system are located in the axis module. That is the reason for more operating displays in the axis module than in the supply module. The supply module is not equipped with any programmable intelligence.
- Responses to detected errors and warnings take place in the axis module only. The error and warnings are, however, displayed in the axis module and to some extent in the supply module. For some events, other numbers may be displayed in the axis module than in the supply module. These events are marked in the operating display table of the supply module.
- The displays for the axis modules and the supply modules are therefore described separately.


Error display of the 7-segment display

The MOVIAXIS® MX multi-axis servo drive detects any errors that occur and displays them as error code. Each error is clearly defined by its error code and corresponding attributes, such as

- the error response,
- the final status after executing the error response,
- the type of reset response.

Error message with two 7-segment displays

The error codes are indicated as flashing numeric values in the axis and supply module. The error code is displayed in the following display sequence:



53052AXX

Figure 102: Example: Error display of error 07 at the axis module

In addition to the error code, a "sub-error code" has been defined to further localize the reason for the error. The "sub-error code" can be read by the operator via the communication connection.

The display can jump back to the statistical operation display depending on the type of error and the response programmed for an error.

Error in the supply module

Errors in the supply module are reported to the axis and processed by the axis.

You execute a reset by interrupting the 24 V electronics supply or via the software.



Error list

Explanation of terms in the error lists

| Terms and abbreviations | Meaning |
|-------------------------|---|
| P | Programmable error response |
| D | Default error response set at the factory |
| VM | Power supply module |
| AM | Axis module |
| ZK | DC link |
| HW | Hardware |
| SW | Software |
| AWE | User-defined unit |

The final error status determines which reset type will be executed in case of an error reset, see following table.

| Final error status | Response to error confirmation, also see page 160 |
|--------------------|---|
| Display error only | Warm start (delete error code) |
| System is waiting | Warm start (delete error code) |
| System is blocked | System restart (execute soft reset) |
| System is blocked | CPU reset (execute CPU reset) |



Operation

Displays of the supply and axis modules

Responses to error acknowledgement

CPU reset

A true restart of the microcontroller and the firmware will take place in case of a CPU reset. The firmware system is started as though a new axis module has been connected to the network.

Restart of the system has the following results:

- The bootstrap loader will be activated, "b0" will appear in the display,
- Reference positions of incremental encoder systems will be lost,
- Any existing fieldbus interfaces will be reset,
- Any existing control options will be reset,
- Fieldbus communication will be interrupted,
- The interface between options and firmware system is initialized again. A new boot synchronization to the fieldbus or control option takes place.
- Communication via CAN interfaces of the system will be interrupted,
- Connection to the supply module will be synchronized again (hardware information system),
- The existing "error message" will be reset [binary output = 1, system status = 0].

The ready signal will be reset by the system status control after the reset by the system status control.

System restart

There will be **no** true reset of the microcontroller with a system restart.

The system restart has the following results:

- The firmware will be restarted, without the boot loader becoming active (no display "b0" !)
- Reference positions of incremental encoder systems will be lost,
- Any existing fieldbus cards are not affected,
- Any existing control options are not affected,
- The interface between options and firmware system is initialized again. A new boot synchronization to the fieldbus or control option takes place.
- Communication via CAN interfaces of the system will be interrupted,
- Connection to the supply module will be synchronized again (hardware information system),
- The existing "error message" will be reset [binary output = 1, system status = 0].

The ready signal will be reset by the system status control after the reset by the system status control.

Warm start

A warm start only resets the error code.

The warm start has the following results:

- The firmware system is not rebooted
- All reference positions will be maintained
- Communication is not interrupted
- The existing "error message" will be reset [binary output = 1, system status = 0].



6.3 Operating displays and errors of the MXP supply module

Table of displays

| | Description | State | Comment / action | Display on the axis module |
|---|---|---|---|----------------------------|
| Displays during standard operation | | | | |
| | Ready for operation (ready) | No error/Warning. $U_z = > 100 \text{ V}$. | Status display only. | - |
| Displays of diverse unit states | | | | |
| | DC link voltage missing or less than 100 V. | No error/Warning. $U_z = > 100 \text{ V}$. | Check mains. | X |
| Displays in case of warnings | | | | |
| | I^2_{xt} prewarning. | Utilization of the VM has reached the prewarning level. | Check application regarding utilization. | P |
| | Temperature prewarning. | The temperature of the VM is approaching the cut-off threshold. | Check application regarding utilization, check ambient temperature. | P |

Table of errors

| | Description | State | Comment / action | Display on the axis module |
|-------------------------------------|---|--|---|----------------------------|
| Displays in case of an error | | | | |
| | Error brake chopper. | Brake chopper is not ready for operation. | See error list of axis modules. | X |
| | Error excessive ZK voltage U_z . | Error message by SM via signaling bus when DC link voltage is too high. | Check application design and braking resistor. | X |
| | Error excessive ZK current. | The DC link current in the SM has exceeded the maximum limit of $250 \% I_{rated}$. | Check application regarding utilization. | X |
| | Error I^2_{xt} monitoring. | Utilization of the VM has reached the limit value. | Check application regarding utilization. | X |
| | Error temperature monitoring. | Temperature of the VM has reached the switch-off threshold. | Check application regarding utilization, check ambient temperature. | X |
| | Error voltage supply (switched-mode power supply module inside unit). | A supply voltage inside the unit is defective. | Check connected loads for overcurrent or unit for defects. | - |
| | Error voltage supply (switched-mode power supply module inside unit). | A supply voltage inside the unit is defective. | Check connected loads for overcurrent or unit for defects. | - |



6.4 Operating displays and errors of MXA axis module

Table of displays


| | Description | State | Comment / action |
|---|--|--|--|
| Displays during boot process | | | |
| | Unit passes through several states when loading the firm-ware (boot) to get ready for operation. | <ul style="list-style-type: none">Status: not ready.Output stage is blocked.No communication possible. | <ul style="list-style-type: none">Waiting for boot process to finish.Unit stays in this condition: Unit defective. |
| | | | |
| | | | |
| | | | |
| | | | |
| Displays of diverse unit statuses | | | |
| | No DC link voltage. | <ul style="list-style-type: none">Status: not ready.Output stage is blocked.Communication is possible. | Check mains. |
| | Supply module not ready for operation. | | Check supply module. |
| | Axis module 24 V or internal switched-mode power supply module of axis not ready for operation. | | 24 V check or unit defective. |
| Flashing | Axis module in safe stop. | | Safety function activated. |
| | Synchronization with bus is incorrect. Process data processing not available. | | <ul style="list-style-type: none">Check bus connection.Check synchronization setting at unit and control.Check process data settings at unit and control.Check missing of a PDO. |
| Flashing | The encoder evaluation is not ready. | | <ul style="list-style-type: none">Encoders are initialized.Unit stays in this condition:<ul style="list-style-type: none">No encoder selected."Source of actual speed" parameter shows an encoder that does not exist. |
| Displays during initialization processes (parameters will be reset to default values) | | | |
| | Basic initialization. | <ul style="list-style-type: none">Status: not ready.Output stage is blocked.Communication is possible. | Waiting for initialization to finish. |
| | Initialization delivery status. | | |
| | Initialization factory setting. | | |
| | Initialization customer-specific set 1. | | |
| | Initialization customer-specific set 2. | | |



| | Description | State | Comment / action |
|---|---|--|---|
| Displays during standard operation | | | |
| | Output stage inhibit | • Output stage is blocked. | The drive is not actuated by the output stage. The brake is applied; without brake the motor coasts to a halt. This FCB is permanently selected with terminal DI00. But it can be additionally selected by other sources. |
| | Unassigned | For more information, refer to the chapter parameter description in the project planning manual. | |
| | Unassigned | | |
| | Unassigned | | |
| | n-control (speed control) | | Speed control with internal ramp generator. |
| | Interpolated n-control | | Speed control with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller. |
| | M-control (torque control) | | Torque control |
| | Interpolated M-control | | Torque control with setpoints cyclically via bus. |
| | Position control | | Positioning mode with internal ramp generator. |
| | Interpolated position control | | Positioning mode with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller. |
| | Limit switch (HW & SW) enable or approach | | This FCB is activated by the firmware when the limit switch is hit. |
| | Reference travel | | The drive performs reference travel. |
| | Stop | | Deceleration at application limit. This FCB also becomes active if no other FCB is selected as default FCB. |
| | Emergency stop | | Deceleration at emergency stop limit. |
| | Stop at system limit | | Deceleration at system limit. |
| | Electronic cam | | Electronic cam active. |
| | Synchronous operation | | Synchronous operation active. |
| | Calibrate encoder | | Encoder commutation for synchronous motors. |
| | Hold control | | Position control at current position. |
| | Jog mode | | Jog mode active. |
| | Brake test | | Brake is tested by applying torque while brake is closed. |



Table of errors

|  | NOTES |
|---|--|
| | Errors or sub-error codes, which are not included in the following list, can be displayed within the framework of displayed error codes. In this case, contact SEW-EURO-DRIVE. |

A "P" in the column "Error response" indicates that the response is programmable. The factory set error response appears in the "Error response" column.

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|--|----------------|---|---|-------------------------------------|-----------------|---|
| 00 | No error (this display is actually an operation display -> see operation displays) | --- | --- | --- | --- | | Ready = 1 (depending on system status) Malfunction = 1 |
| 01 | Error "Overcurrent" | | <ul style="list-style-type: none"> Short-circuit output Motor too large Defective output stage | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| 02 | Error "UCE monitoring" | | The error is an additional kind of overcurrent, measured at the collector-emitter voltage of the output stage. The possible reason behind this error is identical to error 01. The distinction is important for internal purposes only. | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| 03 | Error "Ground fault" | | Ground fault <ul style="list-style-type: none"> in the motor lead in the inverter in the motor | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| 04 | Error "Brake chopper" | | Error message by SM via signal bus. <ul style="list-style-type: none"> Too much regenerative power Braking resistor circuit interrupted Short circuit in the braking resistor circuit Brake resistor has too high resistance Brake chopper defective | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| 05 | Error "Timeout signaling bus" | | The connection between supply module and axis module via signaling bus has been interrupted | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Connection to signaling bus interrupted | | | | |
| | | 02 | Timeout flag signaling bus cannot be reset | | | | |
| 06 | Error "Mains phase failure" | | Error message by SM via signal bus. It was detected that a mains phase is missing. | Display only (D), (P) | ----- | Yes | Ready = 0 Malfunction = 0 |
| 07 | Error "U DC link" | | Error message by SM via signaling bus when DC link voltage is too high | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|-------------------------------------|----------------|---|---|----------------------------------|-----------------|---|
| 08 | Error "Speed monitoring" | | Active speed monitoring has detected an unacceptable deviation between setpoint and actual speed | Output stage inhibit (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Motor speed monitoring | | | | |
| | | 02 | Regenerative speed monitoring | | | | |
| | | 03 | System limit actual speed exceeded | | | | |
| 11 | Error "Overtemperature" axis module | | The temperature of the AM has reached or exceeded the shutdown limit. Possible reasons: <ul style="list-style-type: none"> Ambient temperature too high Unfavorable air convection - defective fan Medium utilization too high | Shutdown with emergency stop delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Limit heat sink temperature exceeded. | | | | |
| 12 | Error "Brake output" | | <ul style="list-style-type: none"> No brake connected Brake line separated in 'on' status Overload through overcurrent > 2A (F13 has priority) Overload due to excessive connection (approx. > 0.5 Hz) Monitoring is only active with parameter settings "Brake installed" and "Brake applied". | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Brake output | | | | |
| 13 | Error "Brake supply" | | Brake supply voltage not within permitted range of +10/- 0%. Monitoring works with parameter setting "Brake installed" and "Brake applied" as well as with CMP and DS motors only. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Brake supply voltage | | | | |
| 14 | Error "Resolver" | | Error with resolver or resolver evaluation. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Open circuit detection resolver | | | | |
| | | 02 | Emulation error resolver (excessive speed) | | | | |
| | | 19 | Non-permissible angle during calibration | | | | |
| 15 | Error "Hiperface Compare Check" | | An error has occurred in the checksum of the Hiperface signals. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Comparison of the absolute encoder position (via Hiperface parameter channel) with the incremental position of the axis every second. | | | | |
| | | 02 | Encoder type unknown | | | | |
| | | 32 | Encoder signals internal error. The error code is displayed as follows: [Displayed value] - 32. You can inquire about this error code at the encoder manufacturer. | | | | |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|-----------------|----------------|---|---|-------------------------------------|-----------------|---|
| 16 | "Startup" error | | Error during startup | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Denominator of pole pair number of resolver not equal to 1 | | | | |
| | | 02 | Numerator of pole pair number of resolver too great | | | | |
| | | 03 | Numerator of pole pair number of resolver too small, that means zero | | | | |
| | | 04 | Denominator of emulation PPR count for resolver not equal to 1 | | | | |
| | | 05 | Numerator of emulation PPR count for resolver too small | | | | |
| | | 06 | Numerator of emulation PPR count for resolver too great | | | | |
| | | 07 | Numerator of emulation PPR count for resolver is not a power of two | | | | |
| | | 08 | Denominator of emulation PPR count for sine encoder not equal to 1 | | | | |
| | | 09 | Numerator of emulation PPR count for sine encoder too small | | | | |
| | | 10 | Numerator of emulation PPR count for sine encoder too great | | | | |
| | | 11 | Numerator of emulation PPR count for sine encoder is not a power of two | | | | |
| | | 512 | Startup for invalid motor type | | | | |
| | | 513 | Set current limit exceeds maximum current of axis | | | | |
| | | 514 | Set current limit is less than rated magnetizing current of the motor | | | | |
| | | 515 | CFC: Factor for calculation of q-current cannot be displayed | | | | |
| | | 516 | Non-permitted PWM frequency configured | | | | |
| | | 517 | Parameter "Final speed flux table" not within permitted range | | | | |
| | | 518 | Parameter "Final flux Id table" not within permitted range | | | | |
| | | 519 | Output stage enable requested without valid motor startup | | | | |
| | | 520 | Motor startup not possible with enabled output stage | | | | |
| | | 521 | Factor for torque limit cannot be displayed (A) | | | | |
| | | 522 | Factor for torque limit cannot be displayed (B) | | | | |
| | | 530 | Max. motor current configured incorrectly | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|---------------------------------|----------------|--|---|-------------------------------------|-----------------|---|
| | | 1024 | NV memory parameter of rated unit current is greater than NV memory parameter of current measuring range | | | | |
| | | 1025 | NV memory parameter of current measuring range is zero | | | | |
| | | 1026 | NV memory parameter of current measuring range is zero | | | | |
| | | 1027 | NV memory parameter of current measuring range is too large | | | | |
| | | 1028 | System limits for speed are greater than max. possible speed | | | | |
| | | 1029 | Application limits for speed are greater than max. possible speed | | | | |
| | | 1032 | CFC: No absolute encoder used as motor encoder in synchronous motors | | | | |
| | | 1033 | Position range in position detection mode "without overflow counter" exceeded | | | | |
| | | 1034 | FCB dual drive: Setpoint deviation window may not be smaller than "standard" setpoint deviation window | | | | |
| | | 1035 | FCB dual drive: Setpoint deviation window may not be smaller than conditioning threshold | | | | |
| | | 1036 | Modulo reference offset is not within Modulo limit | | | | |
| | | 1037 | Position values of software limit switch reversed, positive < negative | | | | |
| 17 | Internal computer error (traps) | | CPU has detected an internal error | Output stage inhibit | System locked / CPU reset | Yes | Ready = 0 Malfunction = 0 |
| 18 | Internal software error | | The software has detected a non-permissible status. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 66 | FCB position control: Target preset in user-defined unit not within range permitted by user-defined unit | | | | |
| | | 67 | FCB position control: Target preset in user-defined unit results in target overflow in system units | | | | |
| | | 68 | FCB position control: ModuloMin ≥ ModuloMax | | | | |
| | | 69 | Time violation in task system | | | | |
| | | 70-78 | Error in Knet driver | | | | |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|-----------------------------------|----------------|---|---|-------------------------------------|-----------------|---|
| 19 | Process data error | | Process data are not valid | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Process data: Negative maximum torque indicated | | | | |
| | | 02 | Process data: Positive minimum torque indicated | | | | |
| | | 03 | Process data: Negative motor torque limit indicated | | | | |
| | | 04 | Process data: Negative regenerative torque limit indicated | | | | |
| | | 05 | Process data: Torque limit for quadrant 1 is negative | | | | |
| | | 06 | Process data: Torque limit for quadrant 2 is negative | | | | |
| | | 07 | Process data: Torque limit for quadrant 3 is negative | | | | |
| | | 08 | Process data: Torque limit for quadrant 4 is negative | | | | |
| | | 09 | Torque control: Maximum speed < minimum speed | | | | |
| | | 10 | Position control: Maximum speed value < 0 | | | | |
| | | 11 | Position control: Maximum speed < 0 | | | | |
| | | 12 | Position control: Minimum speed > 0 | | | | |
| | | 13 | Process data: Enter negative acceleration | | | | |
| | | 14 | Process data: Enter negative delay | | | | |
| | | 15 | Process data: Enter negative jerk | | | | |
| | | 16 | Combination of FCB number and FCB instance does not exist | | | | |
| | | 17 | Target position outside limit switch range | | | | |
| 20 | Setpoint deviation electronic cam | | The preset setpoint deviation limit in electronic cam mode was exceeded | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | CAM: Setpoint deviation electronic cam | | | | |
| 21 | Setpoint deviation dual drive | | The preset setpoint deviation limit in dual drive mode "Engel" was exceeded | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | FCB dual drive: Setpoint deviation in conditioning phase | | | | |
| | | 02 | FCB dual drive: Setpoint deviation in standard operation | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|--|----------------|---|---|-------------------------------------|-----------------|---|
| 25 | Error "Non-volatile parameter memory" | | An error was detected during access to non-volatile parameter memory. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 03 | Error during read-in of data from non-volatile memory. The data cannot be used due to a corrupt identification or checksum. | | | | |
| | | 04 | Initialization error of memory system. | | | | |
| | | 05 | The read-only memory contains invalid data. | | | | |
| | | 06 | The read-only memory contains incompatible data of another device (in case of exchangeable data memories) | | | | |
| 26 | Error "External terminal" | | An error has been reported by a binary input terminal. | Shutdown with emergency stop delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Error external terminal | | | | |
| 27 | Error "Limit switch" | | One or both limit switches cannot be detected at the programmed input terminals or in the control word. | Shutdown with emergency stop delay | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Both limit switches missing or open circuit | | | | |
| | | 02 | Limit switch reversed | | | | |
| 28 | Process data timeout error | | Process data communication is interrupted. | Shutdown with application delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Error fieldbus timeout | | | | |
| 29 | Error "Approach hardware limit switch" | | Travel to hardware limit switch during positioning | Shutdown with emergency stop delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Travel to right limit switch | | | | |
| | | 02 | Travel to left limit switch | | | | |
| 30 | Error "Delay timeout" | | The drive did not come to a standstill within the preset delay time | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Stop ramp time violation | | | | |
| | | 02 | Time violation stop at application limit | | | | |
| | | 03 | Time violation stop at system limit | | | | |
| | | 04 | Emergency stop ramp time violation | | | | |
| 31 | Error "Thermal protection motor" | | Overtemperature sensor (KTY/TF/TH) of the drive was triggered for motor protection | "No response" (D), (P) | No response | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | Open circuit motor temperature sensor detected | | | | |
| | | 02 | Short circuit motor temperature sensor detected | | | | |
| | | 03 | Motor overtemperature KTY | | | | |
| | | 04 | Motor overtemperature (synchronous motor model) | | | | |
| | | 05 | Motor overtemperature (TF/TH) | | | | |
| | | 06 | Motor overtemperature I2t model | | | | |
| | | 07 | AD conversion has not taken place | | | | |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|---|----------------|---|---|-------------------------------------|-----------------|---|
| 32 | Unassigned | | | | | | |
| 33 | Error "SM Boot Timeout" | | The supply module (SM) is not or no longer ready for operation. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| 34 | Unassigned | | | | | | |
| 35 | Unassigned | | | | | | |
| 36 | Error "Following error synchronous operation" | | A preset, maximum permitted following error was exceeded during synchronous operation | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | FCB synchronous operation: Lag error | | | | |
| 37 | Error "System Watchdog" | | Internal watchdog timer setting has been exceeded | Output stage inhibit | System locked / CPU reset | Yes | Ready = 0 Malfunction = 0 |
| 38 | Error "Technology functions" | | Error in one technology function | Shutdown with application limits, programmable | System is waiting Warm start | | Ready = 1 Malfunction = 0 |
| | | 01 | Cam function: Trip point with negative edge < positive edge has been entered | | | Yes | |
| | | 02 | Cam function: Command overflow trip-point processing | | | Yes | |
| 39 | Error "Reference travel" | | An error has occurred during reference travel | Output stage inhibit (D), (P) | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | FCB reference travel: Timeout error during search for zero pulse | | | | |
| | | 02 | FCB reference travel: Hardware limit switch before reference cam | | | | |
| | | 03 | FCB reference travel: Hardware limit switch and reference cam not flush | | | | |
| | | 04 | FCB reference travel: Referencing for type0 must be set to TP | | | | |
| | | 99 | FCB reference travel: Reference type was changed during travel | | | | |
| 40 | Error "Boot synchronization" | | Synchronization with an option card could not be executed appropriately | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| 41 | Error "Watchdog timer to option" | | Connection between main computer and option card computer no longer exists | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 02 | Too many options in total or too many options of one kind | | | | |
| | | 07 | Two options with the same address selection switch detected | | | | |
| | | 08 | CRC error XIA11A | | | | |
| | | 09 | Watchdog triggered at XIA11A | | | | |
| | | 13 | Watchdog error at CP923X | | | | |
| | | 14 | Timeout during option bus access | | | | |
| | | 15 | Error interrupt for which no cause could be determined | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|-------------------------------------|----------------|---|---|----------------------------------|-------------------------|---|
| 42 | Error "Following error positioning" | | A preset, maximum permitted following error was exceeded during positioning <ul style="list-style-type: none"> Encoder connected incorrectly Acceleration ramps too short P component of positioning controller too small Incorrectly set speed controller parameters Value of lag error tolerance too small | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | FCB Positioning: Lag error | | | | |
| 43 | Error "Remote timeout" | | An interruption has occurred during control via a serial interface | Shutdown with application limits | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | FCB Jog mode: Communication timeout at direction control | | | | |
| 44 | Error "Ixt utilization" | | Overload in inverter | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Ixt current limit less than required d-current | | | | |
| | | 02 | Limit chip temperature difference exceeded | | | | |
| | | 03 | Limit chip temperature exceeded | | | | |
| | | 04 | Limit electromechanical utilization exceeded | | | | |
| | | 05 | Short circuit of sensor detected | | | | |
| | | 06 | Motor current limit exceeded | | | | |
| | | 07 | AD conversion has not taken place | | | | |
| 45 | Error "System initialization" | | Error during initialization of the system | Output stage inhibit | System locked / CPU reset | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | The measured current offsets are outside the permitted limit values | | | | |
| | | 02 | An error occurred during CRC generation for the firmware | | | | |
| | | 03 | Data bus error during RAM test | | | | |
| | | 04 | Address bus error during RAM test | | | | |
| | | 05 | Memory cell error during RAM test | | | | |
| 46 | Error "Timeout SBUS#2" | | Communication via SBUS #2 is interrupted | Shutdown with application limits [P] | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Timeout CANopen CAN2 | | | | |
| 50 | Error 24V supply voltage | | Error in 24V supply voltage | Output stage inhibit | System is blocked System restart | yes, if system is ready | Ready = 0 Malfunction = 0 |
| | | 01 | 24V signals incorrect or switched-mode power supply defective | | | | |
| 51 | Error "Software limit switch" | | A software limit switch was approached during positioning | Shutdown with emergency stop delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | The right software limit switch was approached | | | | |
| | | 02 | The left software limit switch was approached | | | | |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|-----------------------------|----------------|---|---|-------------------------------------|-----------------|---|
| 53 | Error "CRC Flash" | | A CRC error occurred during check of the program code by Flash in Code RAM or Resolver DSP. | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | CRC error in Flash EEPROM section "Initial Boot Loader" | | | | |
| 54 | Unassigned | | | | | | |
| 55 | Error "FPGA Configuration" | | Internal error in logic component block (FPGA) | Output stage inhibit | System locked / CPU reset | Yes | Ready = 0 Malfunction = 0 |
| 56 | Error "External RAM" | | Internal error in external RAM block | Output stage inhibit | System locked / CPU reset | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Asynchronous DRAM read&write check error | | | | |
| 57 | Error "TTL encoder" | | Error in TTL encoder | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | TTL sensor: Open circuit | | | | |
| | | 02 | TTL sensor: Emulation error (excessive speed) | | | | |
| | | 19 | TTL sensor: Non-permissible angle during calibration | | | | |
| | | 512 | TTL sensor: Amplitude control has failed | | | | |
| | | 513 | TTL sensor: EPLD reports error | | | | |
| 58 | Error "Sine/cosine encoder" | | Error in sine/cosine encoder evaluation | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Sin/cos encoder: Open circuit detection | | | | |
| | | 02 | Sin/cos encoder: Emulation error (excessive speed) | | | | |
| | | 19 | Sin/cos encoder: Non-permissible angle during calibration | | | | |
| | | 512 | Sin/cos encoder: Amplitude control has failed | | | | |
| | | 514 | Sin/cos encoder: Quadrant control has failed | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|----------------------------------|----------------|---|---|----------------------------------|-----------------|---|
| 59 | Error "Hiperface encoder" | | Error of Hiperface encoder or in Hiperface evaluation | Shutdown with emergency stop delay | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Hiperface encoder: Quadrant control has failed | | | | |
| | | 02 | Hiperface encoder: Track angle offset is incorrect | | | | |
| | | 16 | Hiperface encoder: Encoder does not respond during communication | | | | |
| | | 64 | Hiperface encoder: Communication error with type read | | | | |
| | | 128 | Hiperface encoder: Communication error with status read | | | | |
| | | 192 | Hiperface encoder: Communication error with serial number read | | | | |
| | | 256 | Hiperface encoder: Communication error during initialization absolute position | | | | |
| | | 320 | Hiperface encoder: Communication error during re-initialization absolute position | | | | |
| | | 384 | Hiperface encoder: Communication error during check of absolute position | | | | |
| | | 448 | Hiperface encoder: Communication error during writing of position | | | | |
| 60 | Error "DSP Communication" | | Error during flash of the DSP | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Error DSP JTAG Comm: No JTAG connection | | | | |
| 66 | Error process data configuration | | Error process data configuration | Shutdown with emergency stop delay | System is blocked System restart | 1 | Ready = 0 Malfunction = 0 |
| | | 1 | The process data configuration has been changed. The entire process data subsystem has to be restarted by means of an inverter reset. | | | | |
| | | 10001 | A PDO configured to CAN has an ID located in the area (0x200-0x3ff and 0x600-0x7ff) used for parameter setting by the SBUS. | | | | |
| | | 10002 | A PDO configured to CAN has an ID located in the area (0x580-0x67f) used for parameter setting by CANopen. | | | | |
| | | 10003 | A PDO configured to CAN is to transmit more than 4 PD. Only 0..4 PD are possible for CAN. | | | | |
| | | 10004 | Two or more PDOs configured to the same CAN bus use the same ID. | | | | |
| | | 10005 | Two PDOs configured to the same CAN bus use the same ID. | | | | |
| | | 10008 | An invalid transmission mode was entered for a PDO configured to CAN. | | | | |
| | | 20001 | Configuration conflict with the master | | | | |
| 67 | Error "PDO timeout" | | An input PDO whose timeout interval is not 0, that has not been set to „Offline“ and that has already been received once has exceeded its timeout interval. | Shutdown with application delay (D), (P) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|----------------------------------|----------------|---|---|---------------------------------|-----------------|---|
| | | 0 | PDO 0 | | | | |
| | | 1 | PDO 1 | | | | |
| | | 2 | PDO 2 | | | | |
| | | 3 | PDO 3 | | | | |
| | | 4 | PDO 4 | | | | |
| | | 5 | PDO 5 | | | | |
| | | 6 | PDO 6 | | | | |
| | | 7 | PDO 7 | | | | |
| | | 8 | PDO 8 | | | | |
| | | 9 | PDO 9 | | | | |
| | | 10 | PDO 10 | | | | |
| | | 11 | PDO 11 | | | | |
| | | 12 | PDO 12 | | | | |
| | | 13 | PDO 13 | | | | |
| | | 14 | PDO 14 | | | | |
| | | 15 | PDO 15 | | | | |
| 68 | Error "External synchronization" | | | Shutdown with emergency stop delay | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Time limit for expected synchronization signal has been exceeded | | | | |
| | | 02 | Synchronization lost, synchronization period outside tolerance range | | | | |
| | | 03 | Synchronization to synchronization signal not possible | | | | |
| | | 04 | Duration of sync. signal is not a integer multiple of the PDO system duration | | | | |
| | | 05 | Time limit for synchronization signal exceeded | | | | |
| | | 06 | Synchronization lost, period of synchronization signal invalid | | | | |
| | | 07 | No synchronization of the synchronization signal possible | | | | |
| | | 08 | Duration of system interval too short | | | | |
| | | 09 | Duration of system interval too long | | | | |
| | | 10 | Duration of system interval is not a multiple of the base interval | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|--|----------------|---|---|---------------------------------|-----------------|---|
| 69 | Error "Prewarning motor over-temperature" | | Motor temperature has exceeded the adjustable prewarning threshold | No response, display only | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | Thermal motor protection: Prewarning triggered by KTY temperature | | | | |
| | | 02 | Thermal motor protection: Prewarning triggered by synchronous motor model temperature | | | | |
| | | 03 | Thermal motor protection: Warning threshold I _{2t} model exceeded | | | | |
| 70 | Error 'Error message word 0' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | Yes | |
| | | 01 | Message error control word 0 | | | | |
| 71 | Error 'Error message word 1' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | Yes | |
| | | 01 | Message error control word 1 | | | | |
| 72 | Error 'Error message word 2' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | Yes | |
| | | 01 | Message error control word 2 | | | | |
| 73 | Error 'Error message word 3' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | Yes | |
| | | 01 | Message error control word 3 | | | | |
| 74 | Error 'Error message word 4' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | | |
| | | 01 | Message error control word 4 | | | | |
| 75 | Error 'Error message word 5' | | The error message of an unknown device was detected in the error message word | No response, display only | ----- | Yes | |
| | | 01 | Message error control word 5 | | | | |
| 76 | Error: "Intelligent option" | | MOVI-PLC error | No response, display only | ----- | Yes | |
| 77 | Unassigned | | | | | | |
| 78 | Unassigned | | | | | | |
| 79 | Unassigned | | | | | | |
| 80 | Unassigned | | | | | | |
| 81 | Error "DC link overcurrent SM" | | The DC link current in the SM has exceeded the maximum limit of 250% I _{rated} | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | SM: DC link current too high | | | | |
| 82 | Prewarning "I _{2t} monitoring SM" | | Utilization of the SM has reached the prewarning level | No response (D), (P) | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | SM: Pre-warning I _{2t} utilization | | | | |
| 83 | Error "I _{2t} monitoring SM" | | Utilization of the SM has reached or exceeded the cut-off threshold | Shutdown with emergency stop delay (D) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | SM: Error I _{2t} utilization | | | | |



Operation

Operating displays and errors of MXA axis module

| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|---|----------------|---|---|-------------------------------------|-----------------|---|
| 84 | Error brake chopper at AM | | Error message through supply module via hardware information system. The brake chopper in the supply module is not ready for operation, triggered by BRC short-circuit monitoring or driver voltage monitoring. | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | SM: Error brake chopper | | | | |
| 85 | Prewarning "Temperature monitoring SM" | | The temperature of the SM approaches the cut-off threshold | No response (D), (P) | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | SM: Temperature prewarning | | | | |
| 86 | Error "Overtemperature SM" | | Temperature of the SM has reached or exceeded the cut-off threshold | Shutdown with emergency stop delay (D) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | SM: Temperature error | | | | |
| 87 | Prewarning "Utilization braking resistor in SM" | | The utilization of the braking resistor installed in the SM has reached the prewarning threshold (applies to 10kW version only) | No response (D), (P) | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | SM: Ixt prewarning braking resistor | | | | |
| 88 | Error "Utilization braking resistor in SM" | | The utilization of the braking resistor installed in the SM has reached or exceeded the prewarning threshold (applies to 10kW version only) | Shutdown with emergency stop delay (D) | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Ixt utilization error braking resistor of the SM | | | | |
| 89 | Error "Switched-mode power supply SM" | | Error Switched-mode power supply SM | No response | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | At least one of the supply voltages in the SM is not present | | | | |
| 91 | Warning "SM 24V voltage supply" displayed in supply module only | | 24 V electronics supply less than 17 V -> No error message for the axis !! | No response | ----- | Yes | Ready = 1 Malfunction = 1 |
| | | 01 | 24 V electronics power supply too low | | | | |
| 92 | Unassigned | | | | | | |
| 93 | Unassigned | | | | | | |
| 94 | Error "Unit configuration data" | | An error has occurred in the unit configuration data block during testing in reset phase | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Unit configuration data: checksum error | | | | |
| 95 | Unassigned | | | | | | |
| 96 | Unassigned | | | | | | |
| 97 | Error "Copy parameter set" | | Parameter set could not be copied correctly | Output stage inhibit | System is blocked System restart | Yes | Ready = 0 Malfunction = 0 |
| | | 01 | Cancellation of parameter set download to the unit | | | | |



| Error code | Error message | Sub error code | Possible reason for error | Error response (P = programmable, D = default response) | Final error status / Reset type | Save as History | Message binary outputs (valid for default response) |
|------------|--------------------------|----------------|--|---|---------------------------------|-----------------|---|
| 98 | Unassigned | | | | | | |
| 99 | Unassigned | | | | | | |
| 115 | Error "Safety functions" | | Connections X7:1 (+24 V) / X7:2 (RGND) or X8:1 (+24 V) / X8:2 (RGND) are reversed. Check wiring. | Output stage inhibit | System is waiting Warm start | Yes | Ready = 1 Malfunction = 0 |
| | | 01 | Safety relays: Switching delay between shutdown channels 1 and 2 is too large | | | | |



Operation

Operating displays of MXC capacitor module component

6.5 Operating displays of MXC capacitor module component

The operating statuses are indicated by a two-color LED at the front of the housing, see page 35.

- LED lights up **green**:
 - Capacitor module is ready for operation.
- LED lights up **red**:
 - General error.
- LED **flashes red** (1 Hz):
 - Full utilization of the capacitor module reached.
- LED does not light up:
 - No voltage is supplied to the capacitor module.

6.6 Operating displays of MXB buffer module component

No messages are issued at the buffer module.

6.7 Operating displays of 24 V switched-mode power supply module

The operating status, such as utilization and error of the switched-mode power supply, is indicated by two LEDs on the front of the unit.

- LED State:
 - Normal operation **green**.
 - Error **red**. A malfunction has occurred because of:
 - Overload,
 - Overvoltage,
 - Undervoltage.
- LED Load:
 - Normal operation **green**.
 - With ca. 80 % utilization per output (8 A) **yellow**.




Figure 103: Operating displays 24 V switched-mode power supply module 57910axx

[1] LED State

[2] LED Load



7 Service

7.1 General information

No inspection or maintenance intervals required during active operation.

Send in for repair Please contact **SEW-EURODRIVE electronics service if an error cannot be repaired** (→ "Customer and spare parts service").

When contacting the SEW electronics service, please always quote the production number and order number, so that our service personnel can assist you more effectively. You find the production number on the nameplate, see page 15.

Please provide the following information when sending the unit in for repair:

- Production number (see nameplate),
- Unit designation,
- Unit type,
- Digits of the production number and order number,
- Short application description (drive type, control),
- Connected motor (motor type, motor voltage),
- Type of error,
- Accompanying circumstances,
- Your own assumptions as to what has happened,
- Unusual events preceding the problems.



7.2 Removing / installing a module

This chapter describes how to replace an axis module in the axis system. The master module, capacitor module, buffer module, supply module, DC link discharge module and the 24 V switched mode power supply unit are all installed / removed in the same way.

Safety notes

Always adhere to the following safety instructions.



HAZARD

Dangerous voltages may still be present inside the unit and at the terminal strips up to 10 minutes after the complete axis system has been disconnected from the mains.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- Disconnect the axis system from the mains and wait ten minutes before removing the protective covers.
- After maintenance work, do not operate the axis system unless you have replaced the protective cover because the unit only has degree of protection IP00 without protective cover.



HAZARD

A leakage current $> 3.5 \text{ mA}$ can occur during operation of the MOVIAXIS® MX multi-axis servo inverter.

Severe or fatal injuries from electric shock.

To prevent electric shock:

- With supply system lead $< 10 \text{ mm}^2$, route a second PE conductor with the same cross section as the supply system lead via separate terminals. Alternatively, you can use a PE conductor with a copper cross section $\geq 10 \text{ mm}^2$ or aluminum $\geq 16 \text{ mm}^2$.
- With incoming supply line $\geq 10 \text{ mm}^2$, it is sufficient to install a PE conductor with a cross section copper $\geq 10 \text{ mm}^2$ or aluminum $\geq 16 \text{ mm}^2$.
- If an earth leakage circuit breaker can be used for protection against direct and indirect contact, it must be universal current sensitive (RCD type B).



Removing an axis module

Remove an axis module in the following sequence:

Disconnecting the axis system from the power supply

- Disconnect the entire axis system from the power supply. Follow the safety notes on page 180.

Shield clamps

- Remove electronics shield clamps [2].

Cables


- Remove encoder cable plugs [4] (X13).
- Remove the signal bus cable plug [1] (X9a, X9b).
- Remove CAN2 connection cable plugs [3] (X12), if there are any.

Covers

- Remove covers [5], also those of the units to the left and right of the unit that is to be removed.

Signal lines

- Remove signal lines [6] (X10, X11).





Service

Removing / installing a module

24 V cables

DC link bars

Shield plate


Motor lines

Brake control system

Safety relays

Retaining screws


- Remove 24 V cable plugs **[8]** (electronics and brake supply) (X5a, X5b).
- Remove DC link bars **[13]** of the respective units (X4).
- Remove shield plate on the power terminal **[10]**:
 - Loosen the screw.
 - Remove shield plate in downward direction.
- Remove motor line plug **[12]** (X2).
- Remove brake control plug **[11]** (X6).
- Remove safety relay plugs, if there are any.
- Loosen the two retaining screws **[9]** at the bottom of the axis module.
- Loosen the two retaining screws **[7]** at the top of the axis module.





Removing the axis module

- Slightly raise the axis module, tilt it to the front and remove it in upward direction.






Service

Removing / installing a module

Installing an axis module


Installing an axis module

- Insert the axis module from top into the lower retaining screws, press the axis module backward and then lower it.





- Retaining screws*
 - Tighten upper retaining screws **[7]**.
 - Tighten bottom retaining screws **[9]**.
- Brake control system*
 - Insert brake control plug **[11]** (X6).
- Motor lines*
 - Insert motor line plug **[12]** (X2).
- Shield plate*
 - Insert and secure shield plate on power terminal **[10]**.
- DC link bars*
 - Insert and secure the DC link bars **[13]** (X4).
- 24 V cables*
 - Insert 24 V cable plugs **[8]** (electronics and brake supply) (X5a, X5b).



- Signal lines*
 - Insert signal line plugs **[6]** (X10, X11).
- Covers*
 - Replace the covers **[5]** and secure them.



7.3 *Extended storage*

If the unit is being stored for a long time, connect it to the mains voltage for at least 5 minutes every 2 years. Otherwise, the unit's service life may be reduced.

The 24 V DC voltage supply can be applied without paying attention to any particular notes.

Procedure when maintenance has been neglected:

Electrolytic capacitors are used in the servo inverters. They are subject to aging effects when deenergized. This effect can damage the capacitors if the unit is connected using the rated voltage after a longer period of storage.

If you have not performed maintenance regularly, SEW-EURODRIVE recommends that you increase the supply voltage slowly up to the maximum voltage. This can be done, for example, by using a variable transformer for which the output voltage has been set according to the following overview.

The following stages are recommended:

AC 400/500 V units:

- Stage 1: 0 V to AC 350 V within a few seconds
- Stage 2: AC 350 V for 15 minutes
- Stage 2: AC 420 V for 15 minutes
- Stage 3: AC 500 V for 1 hour


After you have completed the regeneration process, the unit can be used immediately or stored again for an extended period with maintenance.

7.4 *Waste disposal*

Please follow the current national regulations.

Dispose of the following materials separately in accordance with the country-specific regulations in force, as:

- Electronics scrap (printed-circuit boards),
- Plastic,
- Sheet metal,
- Copper,
- Aluminum.



8 Technical Data

8.1 CE marking and approvals

The MOVIAXIS® MX multi-axis servo inverters comply with the following directives and guidelines:

CE marking

- Low voltage directive 2006/95/EC.
- Electromagnetic compatibility directive 89/336/EEC.

The modules of the MOVIAXIS® multi-axis servo inverter are designed for use as components for installation in machinery and systems. They comply with the EMC product standard EN 61800-3 "Variable-speed electrical drives". Provided the installation instructions are complied with, they satisfy the appropriate requirements for CE marking of the entire machine/system in which they are installed, on the basis of the EMC Directive 89/336/EEC.

- Compliance with category "C2" according to EN 61800-3 has been tested on a specified test setup. SEW-EURODRIVE can provide detailed information on request.



The CE mark on the nameplate indicates conformity with the Low Voltage Directive 2006/95/EC and the EMC Directive 89/336/EEC. SEW-EURODRIVE can provide a declaration of conformity on request.

Approvals


The following approvals have been granted for the MOVIAXIS® modules:

| MOVIAXIS® module | UL / cUL | c-Tick | CE conformity |
|--|----------|--------|---------------|
| MXP supply module 10 kW | 1) | x | x |
| MXP supply module 25 kW | 1) | x | x |
| MXP supply module 50 kW | x | x | x |
| MXP supply module 75 kW | x | x | x |
| MXA axis modules | x | x | x |
| MXM master module | x | x | x |
| 24 V switched-mode power supply module | x | x | x |
| MXB buffer module | 1) | 1) | x |
| MXC capacitor module | 1) | 1) | x |
| MXD damping module | 1) | 1) | x |
| DC link discharge module | x | x | x |

1) In preparation

cUL is equivalent to CSA approval.

C-Tick certifies conformity with ACA (Australian Communications Authority) standards.




8.2 General technical data

The technical data in the following tables is valid for all MOVIAXIS® MX multi-axis servo inverters, regardless of type, version, size and performance.

| MOVIAXIS® MX | |
|---|--|
| Interference resistance | Conforms to EN 61800-3 |
| Interference emission with EMC-compliant installation | Category "C2" according to 61800-3 |
| Ambient temperature Climate class ϑ_A | 0 °C...+ 45 °C at $I_D = 100 \% I_N$ and $f_{PWM} = 8 \text{ kHz}$ |
| Storage temperature ϑ_S | – 25 °C...+70 °C (EN 60721-3-3, class 3K3) |
| Storage life | Up to two years without special measures, longer periods see sec. "Service" on page 186. |
| Cooling type (DIN 51751) | Forced cooling and convection cooling, depending on size |
| Enclosure EN 60529 (NEMA1) ¹⁾ | |
| Axis module sizes 1 ... 3 | IP20 |
| Axis module size 4 - 6 | IP10 |
| Supply module size 1 | IP20 |
| Power supply module size 2, 3 | IP10 |
| Master module | IP20 |
| SMPS module | IP10 |
| Capacitor module | IP10 |
| Buffer module | IP10 |
| Duty cycle type | DB (EN 60034-1) |
| Pollution class | 2 according to IEC 60664-1 (VDE 0110-1) |
| Overvoltage category | III according to IEC 60664-1 (VDE 0110-1) |
| Installation altitude h | Up to $h \leq 1000 \text{ m}$ without restrictions. The following restrictions apply at heights $\leq 1000 \text{ m}$: – From 1000 m to max. 2000 m: I_N reduction by 1% per 100 m (330 ft) |

1) - The covers on the left and right end of the unit system must be equipped with touch guard covers. - All cable lugs must be insulated.

Permitted voltage supply systems, see page 76.



8.3 Technical data for the supply module

Power component supply module

| MOVIAXIS® supply module MXP80A-...-503-00 | 1) | 2) | Size | | | |
|--|------------------|-----------------|---|---------------------------------|------------------------|-------|
| | | | 1 | 2 | 3 | |
| Type | | | 010 | 025 ³⁾ | 050 | 075 |
| INPUT | | | | | | |
| Supply voltage AC V _{mains} | U | V | 3 × 380 V ... 3 × 500 V | | | |
| Rated supply current ⁴⁾ AC I _{mains} | I | A | 15 | 36 | 72 | 110 |
| Rated power P _N | P | kW | 10 | 25 | 50 | 75 |
| Mains frequency f _{mains} | f | Hz | 50... 60 ±5% | | | |
| Cross-section and contacts on connections | | mm ² | COMBICON PC4 pluggable, max. 4 | COMBICON PC6 pluggable, max. 16 | Screw bolt M8 max. 50 | |
| Cross-section and contacts on shield clamp | | mm ² | max. 4 × 4 | max. 4 × 10 | max. 4 × 50 shielded | |
| OUTPUT (DC LINK) | | | | | | |
| Rated DC link voltage ⁴⁾ U _{NZK} | U | V | DC 560 | | | |
| Rated DC link current ⁵⁾ DC I _{NZK} | I | A | 18 | 45 | 90 | 135 |
| Max. DC link current DC I _{ZK max} | I _{max} | A | 45 | 112.5 | 225 | 337.5 |
| Overload capacity for max. 1 s | | | 250 % | | | |
| Brake chopper power | | kW | Peak power: 250 % × P _N , continuous power: 0.5 × P _N | | | |
| Mean regenerative power capacity | | kW | 0.5 x P _N | | | |
| Cross section ⁶⁾ and contacts | | mm | CU rails 3 × 14 mm, M6 screw fitting | | | |
| BRAKING RESISTOR | | | | | | |
| Minimum permitted braking resistor value R (4-Q operation) | | Ω | 26 | 10 | 5.3 | 3.5 |
| Cross-section and contacts on connections | | mm ² | COMBICON PC4 pluggable, max. 4 | COMBICON PC6 pluggable, max. 16 | M6 screw bolts max. 16 | |
| Cross-section and contacts on shield clamp | | mm ² | max. 4 × 4 | max. 4 × 6 | max. 4 × 16 | |
| Table continued on next page. Footnotes on next page. | | | | | | |

Table continued on next page. Footnotes on next page.



Technical Data

Technical data for the supply module

| MOVIAXIS® supply module MXP80A-....503-00 | 1) | 2) | Size | | | |
|--|----|-------------------|---------|------|------|------|
| | | | 1 | 2 | 3 | |
| GENERAL INFORMATION | | | | | | |
| Power loss at nominal capacity | | W | 30 | 80 | 160 | 280 |
| No. of times power may be switched on/off | | min ⁻¹ | < 1/min | | | |
| Minimum switch-off time for mains off | | s | > 10 | | | |
| Weight | | kg | 4.2 | 10.2 | 10.7 | 12.1 |
| Dimensions: | W | mm | 90 | 90 | 150 | |
| | H | mm | 300 | 400 | | |
| | D | mm | 254 | | | |

1) Nameplate information

2) Unit

3) In preparation

4) The output currents must be reduced by 20 % from the nominal values for $V_{\text{mains}} = 3 \times \text{AC } 500 \text{ V}$.


5) Decisive value for planning the assignment of supply and axis modules

6) Material strength [mm] × width [mm]

Control section supply module

| MOVIAXIS® MX supply module | General electronics data | |
|---|---|--|
| CAN interface ¹⁾ | CAN: 9-pin sub-D connector | CAN bus to CAN specification 2.0, parts A and B, transmission technology to ISO 11898, max. 64 stations, Terminating resistor (120 Ω) has to be implemented externally, Baud rate can be set from 125 kBaud ... 1 MBaud, expanded MOVILINK protocol, see section 6.4 "Communication via CAN adapter" |
| Cross section and contacts | | |
| DC 24 V voltage supply | DC 24 V ± 25 % (EN 61131) COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² | |
| Decoupling of EtherCAT-based system bus from 9-pin Sub D connector | DIP switch, 4-pole | |
| Shield clamps | Shield clamps for control lines available | |
| Maximum cable cross section that can be connected to the shield clamp | 10 mm (with sheath) | |

1) Only for CAN-based system bus



8.4 Technical data for the axis module

Axis module power section

| MOVIAXIS® axis module MXA80A-...-503-00 | 1) | 2) | Size | | | | | | | | | |
|---|--------------------------------------|-----------------|--|-----|-----|-----|-----|--|-----|------------------------------|-----|---------------|
| Type | | | 1 | | | 2 | | 3 | | 4 | 5 | 6 |
| | | | 002 | 004 | 008 | 012 | 016 | 024 | 032 | 048 | 064 | 100 |
| INPUT (DC link) | | | | | | | | | | | | |
| Rated DC link voltage U _{NZK} | U | V | DC 560 | | | | | | | | | |
| Rated DC link current I _{NZK} ³⁾ | I | A | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 100 |
| Cross section ⁴⁾ and con- tacts | | mm | CU rails 3 × 14 mm, M6 screw fitting | | | | | | | | | |
| OUTPUT | | | | | | | | | | | | |
| Output voltage U | U | V | 0...max. U _{mains} | | | | | | | | | |
| Continuous output current AC I _N PWM = 4 kHz | I | A | 2 | 4 | 8 | 12 | 16 | 32 | 42 | 64 | 85 | 133 |
| Rated output current AC I _N PWM = 8 kHz | I | A | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 100 |
| Rated output current AC I _N PWM = 16 kHz | I | A | 1.5 | 3 | 5 | 8 | 11 | 13 | 18 | - | - | - |
| Max. ⁵⁾ unit output current I _{max} | I _{max} | A | 5 | 10 | 20 | 30 | 40 | 60 | 80 | 120 | 160 | 250 |
| Overload capacity for max. 1 s | | | 250 % | | | | | | | | | |
| Apparent output power P _{Nout} ⁶⁾ | S | kVA | 1.4 | 2.8 | 5.5 | 8.5 | 11 | 17 | 22 | 33 | 44 | 69 |
| PWM frequency f _{PWM} | | kHz | Can be set: 4/8/16; setting on delivery: f _{PWM} =8 kHz | | | | | | | | | |
| Maximum output frequency f _{max} | f | Hz | 600 | | | | | | | | | |
| Motor connection to terminals | | mm ² | COMBICON PC4 pluggable, max. 4 | | | | | ⁷⁾ | | Screw bolts M6 max. 25 | | ⁸⁾ |
| Motor connection to power shield clamp | | mm ² | max. 4 × 4 | | | | | max. 4 × 6 | | max. 4 × 25 | | ⁹⁾ |
| Brake connection | U _{BR} / I _{BR} | V / A | 1 binary output brake control | | | | | Suitable for direct operation of brake, short-circuit proof. External 24 V required. Tolerance depends on installed brake type, see project planning manual. | | | | |
| | | | Signal level: "0" = 0 V "1" = +24 V Important: Do not apply external voltage! | | | | | | | | | |
| | | | Function: fixed assignment with "/Brake" | | | | | | | | | |
| Brake connection contacts | | mm ² | COMBICON 5.08 One conductor per terminal: 0.20...2.5 Two conductors per terminal: 0.25...1 | | | | | | | | | |
| Shield clamps | | | Shield clamps for brake lines available | | | | | | | | | |
| Maximum cable cross sec- tion that can be connected to the shield clamp | | | 10 mm (with sheath) | | | | | | | | | |
| Table continued on next page. Footnotes on next page. | | | | | | | | | | | | |



Technical Data

Technical data for the axis module

| | | | | | | | | | | | | |
|--|-------------|----|------|-----|-----|-----|-----|-----|-----|-----|------|------|
| MOVIAXIS® axis module MXA80A-...-503-00 | 1) | 2) | Size | | | | | | | | | |
| | | | 1 | | | 2 | | 3 | | 4 | 5 | 6 |
| GENERAL INFORMATION | | | | | | | | | | | | |
| Power loss at nominal capacity ⁶⁾ | | W | 30 | 60 | 100 | 150 | 210 | 280 | 380 | 450 | 670 | 1100 |
| Weight | | kg | 4.2 | 4.2 | 4.2 | 5.2 | 5.2 | 9.2 | 9.2 | 9.2 | 15.6 | 15.6 |
| W | Dimensions: | mm | 60 | | | 90 | | 90 | | 120 | 150 | 210 |
| H | | mm | 300 | | | 300 | | 400 | | 400 | 400 | 400 |
| D | | mm | 254 | | | | | | | | | |

1) Nameplate information

2) Unit

3) With simplification: $I_{Nzk} = I_N$ (typical motor application)

4) Material strength [mm] × width [mm]

5) Indicated values apply to motor operation. Motor and regenerative have the same peak performance.

6) Applies to mains voltage 400 V and 50 Hz / PWM = 8 kHz.

7) PC6 pluggable, one conductor per terminal: 0.5...16 mm²; two conductors per terminal: 0.5...6 mm².

8) Max. 4 × 70 mm²


9) Max. 4 × 50 mm², for cross sections > 50 mm², the cable shield must be connected outside the unit, e.g. DIN rail clamp.

Notes on brake control

| | |
|--|--|
| | NOTES |
| | <p>Note on tolerance requirement for the brake voltage!</p> <p>The brake voltage has to be configured. See project planning manual.</p> |


Permitted load of brake control and brake

One complete switching sequence (opening and closing) must not be repeated more often than a maximum of every two seconds. The brake must remain switched off for at least 100 ms before it can be switched on again.



Control section axis module

| MOVIAXIS® MX axis module | General electronics data | |
|---|---|----------------|
| DC 24 V voltage supply | DC 24 V \pm 25 % (EN 61131) COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² | |
| X10:1 and X10:10 binary inputs Internal resistance | Isolated (optocoupler), PLC compatible (EN 61131), sampling interval 1 ms $R_i \approx 3.0 \text{ k}\Omega$, $I_E \approx 10 \text{ mA}$ | |
| Signal level | +13 V...+30 V = "1" = Contact closed -3 V...+5 V = "0" = Contact open | meets EN 61131 |
| Function | DIØØ: With fixed assignment "Output stage enable" DIØ1...DIØ8: Selection option → parameter menu DIØ1 and DIØ2 suitable for touch probe function (latency period < 100 µs) | |
| 4 binary outputs | PLC compatible (EN 61131-2), response time 1 ms, short-circuit proof, $I_{\max} = 50 \text{ mA}$ | |
| Signal level | "0"=0 V, "1"=+24 V, Caution: Do not apply external voltage. | |
| Function | DOØØ ... DOØ3: Selection option → parameter menu | |
| Cross section and contacts | COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² | |
| Shield clamps | Shield clamps for control lines available | |
| Maximum cable cross section that can be connected to the shield clamp | 10 mm (with sheath) | |
| Connection contacts for safety functions | Safety relay integrated in unit as option (→ page 201) Suitable for operation as device of stop category 0 or 1 according to EN 60204-1 with prevention of restart for safety applications in: <ul style="list-style-type: none"> Category 3 according to EN 954-1 Protection type III according to EN 201 | |
| Cross section and contacts | Mini COMBICON 3.5 One conductor per terminal: 0.08 ... 1.5 mm ² Two conductors per terminal: 0.08 ... 0.75 mm ² | |



Technical Data

Technical data for master module component

8.5 Technical data for master module component

| | | | |
|---|---|----|----------------------------|
| MOVIAXIS® MX master module MXM80A-...-000-00 | 1) | 2) | Size 1 |
| Type | | | 000 |
| Supply voltage U | U | V | DC 24 V ± 25 % to EN 61131 |
| Cross section and contacts (X5a) | COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² | | |
| Cross section and contacts (X5b) | COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² Maximum outer diameter of the cable: 3.5 mm. Recommended connector: MSTB 2.5/4-ST-5.08 BK (Phoenix) (COMBICON 5.08 with front-end cable output) | | |
| GENERAL INFORMATION | | | |
| Weight | | kg | 2.3 |
| Dimensions: | W | mm | 60 |
| | H | mm | 300 |
| | D | mm | 254 |
| | | | |
| Shield clamps | Shield clamps for control lines available | | |
| Maximum cable cross section that can be connected to the shield clamp | 10 mm (with sheath) | | |

1) Nameplate information


2) Unit

| | |
|--|--|
| | NOTES |
| | For other technical data, refer to the manual <ul style="list-style-type: none"> • MOVI-PLC® basic DHP11B Controller • MOVI-PLC® advanced DH.41B Controller |

MOVIAXIS® MXM electronics data

Power consumption MOVIAXIS® MXM master module

| Master module | |
|---------------|--|
| Power | See technical data of the integrated card. Due to the efficiency of 85 % of the integrated switched-mode power supply unit, the power consumption of the integrated card must be multiplied by factor 1.2. |



8.6 Technical data for capacitor module component

| MOVIAXIS® capacitor module MXC80A-050-503-00 | 1) | 2) | |
|--|----|----|--------------------------------------|
| Type | | | 050 |
| INPUT | | | |
| Rated DC link voltage ³⁾ U_{Nzk} | U | V | DC 560 |
| Storable energy ³⁾ | W | Ws | 1000 |
| Peak power capacity | | kW | 50 |
| Cross section and contacts | | mm | CU rails 3 × 14 mm, M6 screw fitting |
| GENERAL INFORMATION | | | |
| Capacity | C | μF | 4920 |
| Time from switching the unit on until it is ready for operation | | s | 10 |
| Weight | | kg | 12.6 |
| Dimensions: W | | mm | 150 |
| H | | mm | 400 |
| D | | mm | 254 |


1) Nameplate information

2) Unit

3) At $U_{mains} = 3 \times AC\ 400\ V$

Capacitor module control section

| MOVIAXIS® MXC capacitor module | General electronics data |
|--------------------------------|---|
| DC 24 V voltage supply | DC 24 V ± 25 % (EN 61131) COMBICON 5.08 One conductor per terminal: 0.20...2.5 mm ² Two conductors per terminal: 0.25...1 mm ² |



Technical Data

Technical data for buffer module component


8.7 Technical data for buffer module component

| | | | |
|--|----------|----|--------------------------------------|
| MOVIAXIS® buffer module MXB80A-050-503-00 | 1) | 2) | |
| Type | | | 050 |
| INPUT | | | |
| Rated DC link voltage³⁾ U_{NZK} | U | V | DC 560 |
| Cross section and contacts | | mm | CU rails 3 × 14 mm, M6 screw fitting |
| GENERAL INFORMATION | | | |
| Capacity | C | μF | 4920 |
| Time from switching the unit on until it is ready for operation | | s | 10 |
| Weight | | kg | 11 |
| Dimensions: | W | mm | 150 |
| | H | mm | 400 |
| | D | mm | 254 |

1) Nameplate information

2) Unit

3) At U_{mains} = 3 × AC 400 V



8.8 Technical data for 24 V switched-mode power supply module component

| | | | | |
|---|---|-----------------|----|--|
| MOVIAXIS® 24 V switched-mode power supply module MXS80A-...-503-00 | | 1) | 2) | |
| Type | | | | 060 |
| INPUT via DC link | | | | |
| Rated DC link voltage U_{NZK} | U | V | | DC 560 |
| Cross section ³⁾ and contacts | | | | CU rails 3 × 14 mm, M6 screw fitting |
| INPUT via external 24 V | | | | |
| Rated input voltage U_N • With direct control of brakes for CMP and DS motors • Otherwise | U | V | | DC-24 -0 % / +10 % DC-24 ±25 % (EN 61131) |
| Cross section and contacts | | mm ² | | PC6 One conductor per terminal: 0.5...6 Two conductors per terminal: 0.5...6 |
| OUTPUT | | | | |
| Rated output voltage V | U | V | | DC 3 × 24 (shared ground). Tolerance for supply via DC link: DC 24 0 % / +10 %. Tolerance for supply via external 24 V: According to input voltage |
| Rated output current I | I | A | | 3 × 10 ⁴⁾ |
| Rated output power P | P | W | | 600 |
| Cross section and contacts | | mm ² | | COMBICON 5.08 One conductor per terminal: 0.20...2.5 Two conductors per terminal: 0.25...1 |
| GENERAL INFORMATION | | | | |
| Bridging resistance for U_Z drop ⁵⁾ | t | s | | Rated power for 10 ms |
| Efficiency | | | | ca. 80 % |
| Weight | | kg | | 4.3 |
| Dimensions | W | mm | | 60 |
| | H | mm | | 300 |
| | D | mm | | 254 |

1) Nameplate information

2) Unit

3) Material strength [mm] × width [mm]

4) Not possible at the same time because total power is limited to 600 W

5) Applies to the following measuring point: 10 ms are guaranteed for an edge steepness of the falling DC link voltage of $(dU_{ZK} / dt) > (200 \text{ V} / 1 \text{ ms})$. Applies for a power supply voltage U_{ZK} of 3 × AC 380 V.



Technical Data

Technical data for the DC link discharge module component

8.9 Technical data for the DC link discharge module component

Power section of DC link discharge module

| | | | |
|--|----|-----------------|---|
| MOVIAXIS® MX DC link discharge module MXZ80A-...-503-00 | 1) | 2) | Size 1 |
| Type | | | 050 |
| INPUT (DC link) | | | |
| Rated DC link voltage ³⁾ U_{Nzk} | U | V | DC 560 |
| Cross section ⁴⁾ and contacts | | | CU rails 3 × 14 mm, M6 screw fitting |
| Convertible energy E | E | J | 5000 |
| OUTPUT | | | |
| Braking resistor R | R | Ω | 1 |
| Discharge connection | | | Specific screw fitting by SEW |
| Cross section and contacts | | mm ² | M6 screw bolts, max. 4 × 16 |
| Connection to power shield clamp | | mm ² | max. 4 × 16 |
| GENERAL INFORMATION | | | |
| Ready for operation once mains and 24V have been switched on | | s | ≤ 10 |
| Ready for operation after short circuit | | s | Depending on application, see section "Startup" on page 101 |
| Repeatability of quick discharge | | s | 60 |
| Duration of quick discharge | | s | ≤ 1 |
| Shutdown temperature | | ° C | 70 |
| Weight | | kg | 3.8 |
| Dimensions: | W | mm | 120 |
| | H | mm | 235 |
| | D | mm | 254 |

1) Nameplate information

2) Unit


3) The system and output currents must be reduced by 20 % from the nominal values for $U_{mains} = 3 \times AC\ 500\ V$.

4) Material strength [mm] x width [mm]

Control section of DC link discharge module

| | | |
|---------------------------------------|-----------------|--|
| MOVIAXIS® MX DC link discharge module | 1) | General electronics data |
| Inhibit | | Control signal for discharge process |
| DC 24 V voltage supply | V | DC 24 ± 25 % (EN 61131-2) |
| Cross section and contacts | mm ² | COMBICON 5.08 One conductor per terminal: 0.20...2.5 Two conductors per terminal: 0.25...1 |

1) Unit



8.10 Technical data for 24 V current consumption

The current consumption of the MOVIAXIS® units and their options depends on the switch-on time. It is therefore not possible to specify the current consumption explicitly, but it must be projected in relation to the switch-on time.

For more information on this, refer to the "MOVIAXIS® MX Multi-Axis Servo Inverter" project planning manual.

8.11 Technical data for the braking resistors

UL and cUL approval

Type BW... braking resistors are UL and cUL approved in conjunction with the MOVIAXIS® multi-axis servo inverter. SEW-EURODRIVE will provide a certificate upon request.

The following braking resistors have cRUus approval independent of the MOVIAXIS® multi-axis servo inverter:


- BW012-015-01.
- BW006-025-01,
- BW006-050-01,
- BW004-050-01,

Technical Data

| Braking resistor type | 1) | BW027-006 | BW027-012 | BW247 | BW347 | BW039-050 |
|--|------------------|-----------------------|-----------|-----------|-----------|-----------|
| Part number | | 822 422 6 | 822 423 4 | 820 714 3 | 820 798 4 | 821 691 6 |
| Power class of the supply module | kW | 10, 25, 50, 75 | | | | |
| Load capacity at 100 % cdf ²⁾ | kW | 0.6 | 1.2 | 2 | 4 | 5 |
| Resistance value R _{BW} | Ω | 27 ±10 % | | 47 ±10 % | | 39 ±10 % |
| Trip current (of F16) I _F | A _{RMS} | 4.7 | 6.7 | 6.5 | 9.2 | 11.3 |
| Design | | Wire-wound resistor | | | | |
| Connections | mm ² | Ceramic terminals 2.5 | | | | |
| Permitted electric loading of the terminals at 100 % cdf ²⁾ | A | DC 20 | | | | |
| Permitted electric loading of the terminals at 40 % cdf ²⁾ | A | DC 25 | | | | |
| Degree of protection | | IP20 (when installed) | | | | |
| Ambient temperature ϑ _U | ° C | -20 ... +45 | | | | |
| Type of cooling | | KS = Self-cooling | | | | |

1) Unit

2) cdf = Cyclic duration factor of the braking resistor in relation to a cycle duration T_D ≤ 120 s.



Technical Data

Technical data for the braking resistors

| Braking resistor type | 1) | BW012-015 | BW012-015-01 ²⁾ | BW012-025 | BW012-050 | BW012-100 | BW915 |
|--|------------------|-----------------------|----------------------------|-----------|-----------|-----------|-----------|
| Part number | | 821 679 7 | 1 820 010 9 | 821 680 0 | 821 681 9 | 821 682 7 | 821 260 0 |
| Power class of the supply module | kW | 25, 50, 75 | | | | | |
| Load capacity at 100 % cdf ³⁾ | kW | 1.5 | 1.5 | 2.5 | 5.0 | 10 | 16 |
| Resistance value R _{BW} | Ω | 12 ±10 % | | | | | 15 ±10 % |
| Trip current (of F16) I _F | A _{RMS} | 11.2 | 11.2 | 14.4 | 20.4 | 28.9 | 31.6 |
| Design | | Steel-grid resistor | | | | | |
| Connections | mm ² | Ceramic terminals 2.5 | | | | | |
| Permitted electric loading of the terminals at 100 % cdf ³⁾ | A | DC 20 | | | | | |
| Permitted electric loading of the terminals at 40 % cdf ³⁾ | A | DC 25 | | | | | |
| Degree of protection | | IP20 (when installed) | | | | | |
| Ambient temperature θ _U | ° C | -20 ... +45 | | | | | |
| Type of cooling | | KS = Self-cooling | | | | | |

1) Unit

2) Braking resistors show a tapping of 1 Ω


3) cdf = Cyclic duration factor of the braking resistor in relation to a cycle duration T_D ≤ 120 s.

| Braking resistor type | 1) | BW006-025-01 ²⁾ | BW006-050-01 ²⁾ | BW106 | BW206 | BW004-050-01 ²⁾ |
|--|------------------|----------------------------|----------------------------|-----------|-----------|----------------------------|
| Part number | | 1 820 011 7 | 1 820 012 5 | 821 050 0 | 821 051 9 | 1 820 013 3 |
| Power class of the supply module | kW | 50, 75 | | | | 75 |
| Load capacity at 100 % cdf ³⁾ | kW | 2.5 | 5.0 | 13 | 18 | 5.0 |
| Resistance value R _{BW} | Ω | 5.8 ±10 % | | 6 ±10 % | | 3.6 ±10 % |
| Trip current (of F16) I _F | A _{RMS} | 20.8 | 29.4 | 46.5 | 54.7 | 37.3 |
| Design | | Steel-grid resistor | | | | |
| Connections | | M8 stud | | | | |
| Permitted electric loading of the terminal stud at 100 % cdf ³⁾ | A | DC 115 | | | | |
| Permitted electric loading of the terminal stud at 40 % cdf ³⁾ | A | DC 143 | | | | |
| Degree of protection | | IP20 (when installed) | | | | |
| Ambient temperature θ _U | ° C | -20 ... +45 | | | | |
| Type of cooling | | KS = Self-cooling | | | | |

1) Unit

2) Braking resistors show a tapping of 1 Ω

3) cdf = Cyclic duration factor of the braking resistor in relation to a cycle duration T_D ≤ 120 s.



8.12 Technical data for line filter and line chokes

Line filter

| Line filter type | 1) | NF018-503 | NF048-503 | NF085-503 | NF150-503 |
|-------------------------------------|-----------------|-------------------------|------------------|-----------|-----------|
| Part number | | 827 413 4 | 827 117 8 | 827 415 0 | 827 417 7 |
| Power supply module | | Size 1 | Size 2 | BG3 | BG3 |
| Rated voltage U_N | V_{AC} | 3 x 500 +10 %, 50/60 Hz | | | |
| Rated current I_N | A_{AC} | 18 | 48 | 85 | 150 |
| Power loss at I_N P_V | W | 12 | 22 | 35 | 90 |
| Earth-leakage current at U_N | mA | < 25 | < 40 | < 30 | < 30 |
| Ambient temperature ϑ_U | ° C | -25 ... +40 | | | |
| Degree of protection | | IP20 (EN 60529) | | | |
| Connections L1-L3/L1'-L3' PE | mm ² | 4 M5 stud | 10 M5/M6 stud | 35 M8 | 50 M10 |
| NF...type line filter ²⁾ | | | | | |

1) Unit

2) SEW-EURODRIVE will provide a certificate upon request.

Line choke

| Line choke type | 1) | ND020-013 | ND045-013 | ND085-013 | ND150-013 |
|-----------------------------------|-----------------|-------------------------|-----------------------|-----------------------|-------------------------|
| Part number | | 826 012 5 | 826 013 3 | 826 014 1 | 825 548 2 |
| Power supply module | | Size 1 | Size 2 | BG3 | BG3 |
| Rated voltage U_N | V_{AC} | 3 x 500 +10 %, 50/60 Hz | | | |
| Rated current I_N | A_{AC} | 20 | 45 | 85 | 150 |
| Power loss at I_N P_V | W | 10 | 15 | 25 | 62 |
| Inductance L_N | mH | 0.1 | -- | -- | -- |
| Ambient temperature ϑ_U | ° C | -25 ... +40 | | | |
| Degree of protection | | IP00 (EN 60529) | | | |
| Connections L1-L3/L1'-L3' PE | mm ² | 4 Terminal strips | 10 Terminal strips | 35 Terminal strips | M10 stud PE: M8 stud |

1) Unit

8.13 Safety technology (safe stop)

| | NOTES |
|--|---|
| | <p>It is essential to observe the information on this topic in the following publications:</p> <ul style="list-style-type: none"> "Safe Disconnection for MOVIAXIS® – Conditions". "Safe Disconnection for MOVIAXIS® – Applications". |




9 Appendix

9.1 Cable dimensions to AWG

AWG stands for **A**merican **W**ire **G**auge and refers to the size of the wires. This number specifies the diameter or cross section of a wire in code. This type of cable designation is usually only used in the USA. However, the designations can also be seen in catalogs or data sheets in Europe.

| AWG designation | Cross section in mm ² |
|-----------------|----------------------------------|
| 000000 (6/0) | 185 |
| 00000 (5/0) | 150 |
| 0000 (4/0) | 120 |
| 000 (3/0) | 90 |
| 00 (2/0) | 70 |
| 0 (1/0) | 50 |
| 1 | 50 |
| 2 | 35 |
| 3 | 25 |
| 4 | 25 |
| 5 | 16 |
| 6 | 16 |
| 7 | 10 |
| 8 | 10 |
| 9 | 6 |
| 10 | 6 |
| 11 | 4 |
| 12 | 4 |
| 13 | 2.5 |
| 14 | 2.5 |
| 15 | 2.5 |
| 16 | 1.5 |
| 16 | 1 |
| 18 | 1 |
| 19 | 0.75 |
| 20 | 0.5 |
| 21 | 0.5 |
| 22 | 0.34 |
| 23 | 0.25 |
| 24 | 0.2 |

9.2 List of abbreviations

| Abbreviation | Definition | Meaning |
|---|---|--|
| CAN | Controller Area Network | |
| DI | Digital In | |
| DIN | Deutsches Institut für Normung e.V. (German institute for standardization) | |
| DIN EN | EN European Standard whose German version has the status of a German standard. | |
| DIN EN ISO | ISO standard that has been made a European standard and has been adopted into the German book of standards. | |
| DIN IEC | International standard that has been adopted without changes into the German standard. | |
| DO | Digital Out | |
| EN | Europäische Norm (European standard) | |
| GND | Ground | |
| IP | International Protection = international type of enclosure | |
| ISO | International Organization for Standardization | The ISO creates ISO standards that should be adopted unrevised by the member states. |
| PDO | Process data object, process data | |
| PE | Protected Earth: "Protective earth" | Ground connection |
| PELV | Protective Extra Low Voltage | Protection low voltage |
| PWM | Pulse Width Modulation | |
| SELV | Safety Extra Low Voltage | |
| TH/TF | Thermostat / Temperature sensor | |
|  | Underwriters' Laboratories Inc. | Certification issued in North America |
| ZK | DC link | |



9.3 Definition of terms

| | |
|-----------------------|--|
| CAN bus system | Serial bus system for the automotive industry and industrial control devices. The bus medium is a twisted conductor pair with excellent transmission characteristics in the short-distance range of less than 40 m. |
| PROFIBUS | PROFIBUS (Process Field Bus) is a standard for fieldbus communication used in automation engineering. |
| K-Net | The XFA (K-Net) communication module is a slave module for connection to a serial bus system for high-speed data transfer. |
| EtherCAT | The XFE24A communication component is a slave module for connection to EtherCAT networks. |
| Multi-encoder card | The multi-encoder card enables evaluation of additional encoders. |
| EMC compliant housing | EMC compliant housings form a shield against electrical, magnetic or electromagnetic fields. These interference fields are generated by electrostatic discharges occurring during switching sequences, during rapid current or voltage changes, during operation of motors or high-frequency generators and similar situations. These EMC compliant housings are usually equipped with an EMC cable gland. |
| EMC cable gland | Seal of cable entry with option to apply a cable shield or contacting. |
| IP code | A coding system to indicate the degrees of protection offered by a housing against access to dangerous parts, ingress of solid foreign objects and the ingress of water. |
| Insulation resistance | Insulating property of a material to separate two neighboring contacts or one grounded contact at a relatively high resistance value. |
| Insulating materials | Insulation in plug connectors is ensured by using thermoplastics and thermosetting plastic. The selected material depends on the required thermal and mechanical properties. |
| Cable | Lines can consist of one or more cores, come equipped with insulating sleeves, shields and a sheath for the protection of structural elements. Lines connected to plug connectors are mainly flexible lines, flat lines, sheathed lines, shielded lines and coaxial lines. |
| Firmware | Software provided by the manufacturer that cannot be changed by the user. |



| | |
|--|----------|
| A | |
| Accessory assignment table | 20, 21 |
| Axis module nameplate | 15 |
| B | |
| Bending space note | 66 |
| Binary inputs / binary outputs | 76 |
| Brake rectifier in the control cabinet | 78 |
| Braking resistors | |
| <i>Connection</i> | 76 |
| <i>Operation</i> | 76 |
| Bus termination | 54 |
| C | |
| CAN1 settings | |
| <i>Bus terminating resistors for CAN /</i> | |
| <i>signal bus connection</i> | 107 |
| <i>Cable length and cable specification</i> | 105 |
| <i>Connecting CAN1 cables to the supply</i> | |
| <i>module</i> | 106 |
| <i>Setting the axis address</i> | 103 |
| <i>Setting the CAN1 baud rate</i> | 103 |
| CAN2 settings | |
| <i>Bus terminating resistors for CAN2</i> | 110 |
| <i>CAN2 axis address</i> | 108 |
| <i>Connecting CAN2 cables to the axis</i> | |
| <i>modules</i> | 109 |
| CE marking | 187 |
| Communication via CAN adapter | |
| <i>Connection assignment of connection</i> | |
| <i>and extension cables</i> | 106, 109 |
| <i>Connection assignment of X12 (pin)</i> | |
| <i>on the axis module</i> | 109 |
| <i>Connection assignment of X12 (pin)</i> | |
| <i>on the supply module</i> | 106 |
| Connecting cables, operating switches - Note .. | 101 |
| Connecting encoders to the basic unit | |
| <i>General installation notes</i> | 96 |
| <i>Prefabricated cables</i> | 96 |
| <i>Shielding</i> | 96 |
| Connection technology | 54 |
| Controller parameter | |
| <i>PWM frequency</i> | 139 |
| <i>Speed setpoint filter</i> | 139 |
| Controller parameters | |
| <i>Amplification acceleration precontrol</i> | 139 |
| <i>Filter speed actual value</i> | 139 |
| <i>P-gain position controller</i> | 139 |
| <i>P-gain speed controller</i> | 139 |
| <i>Speed control</i> | 139 |
| <i>Time constant speed controller</i> | 139 |
| Covers of the modules | 73 |
| E | |
| Electrical Installation | 77 |
| Electromagnetic compatibility | |
| <i>Interference emission</i> | 98 |
| <i>Interference emission categories</i> | 98 |
| <i>Line filter</i> | 97 |
| <i>Separate cable ducts</i> | 97 |
| <i>Shielding and grounding</i> | 97 |
| Error display of the 7-segment display | 158 |
| <i>Error in the supply module</i> | 158 |
| <i>Error message with two 7-segment</i> | |
| <i>displays</i> | 158 |
| Error list | |
| <i>Explanation of terms</i> | 159 |
| F | |
| Fault list | 159 |
| H | |
| Hoist applications - Note | 101 |
| M | |
| Mains connection of axis system | 101 |
| Minimum clearance and mounting position | 66 |
| MOVIAXIS® MX optional communication | |
| components | 18 |
| Multi-encoder card XGH11A, XGS11A option | |
| <i>Connection and terminal description</i> | 45 |
| <i>Overview of functions</i> | 43 |
| <i>PIN assignment X61</i> | 45 |
| <i>PIN assignment X62</i> | 47 |
| <i>PIN assignment X63 XGH with EnDat 2.1</i> ... | 49 |
| <i>PIN assignment X63 XGH with Hiperface</i> | |
| <i>encoder</i> | 48 |
| <i>PIN assignment X63 XGH with TTL</i> | |
| <i>encoder, sin/cos encoder</i> | 48 |
| <i>PIN assignment X64 XGS with SSI</i> | 49 |
| <i>PIN assignment X64 XGS with SSI</i> | |
| <i>(AV1Y)</i> | 50 |
| <i>Suitable encoders</i> | 44 |
| N | |
| Nameplate of the 24 V switched mode | |
| power supply additional module | 16 |
| Nameplate of the DC link discharge | |
| additional module | 16 |
| O | |
| Operating display and errors of the axis module | |
| <i>Table of displays</i> | 162 |
| <i>Table of errors</i> | 164 |
| Operating display and errors of the supply module | |
| <i>Table of displays</i> | 161 |
| <i>Table of errors</i> | 161 |
| Operating display of the 7-segment display | 158 |
| Operating displays of 24 V switched-mode | |
| power supply module | 178 |
| Operating displays of MXB buffer module | |
| component | 178 |
| Operating displays of MXC capacitor module | |
| component | 178 |
| Option combinations on delivery | |
| <i>Axis modules in EtherCAT version</i> | 39 |



Index

| | |
|---|----------|
| <i>Axis modules in XGH version</i> | 41 |
| <i>Axis modules in XGS version</i> | 41 |
| <i>Axis modules in XIA version</i> | 41 |
| <i>Axis modules in XIO version</i> | 40 |
| P | |
| PDO Editor | |
| <i>Assigning the input buffer to the system variables</i> | 155 |
| <i>Parameter setting example</i> | 153 |
| <i>Setting the FCB parameters</i> | 155 |
| <i>Setting the fieldbus interface parameters</i> .. | 153 |
| <i>Setting the parameters of the control word and the IN process data</i> | 154 |
| <i>Structure and data flow</i> | 152 |
| <i>Testing the configurations</i> | 156 |
| Permitted tightening torque | |
| <i>DC link connection</i> | 99 |
| Permitted tightening torques | |
| <i>Power terminals</i> | 99 |
| <i>Signal relay</i> | 99 |
| <i>Signal terminals</i> | 99 |
| Permitted voltage supply systems | 76 |
| PROFIBUS XFP11A module option | |
| <i>Baud rates larger than 1.5 MBaud</i> | 52 |
| <i>MOVIAXIS® / PROFIBUS connection</i> | 51 |
| <i>Pin assignment</i> | 51 |
| <i>Setting the station address</i> | 52 |
| <i>Terminal assignment</i> | 51 |
| R | |
| Rear view of MOVIAXIS® MX axis and supply module housing | 64 |
| Rear view of MOVIAXIS® MX DC link discharge module housing | 65 |
| Reference potentials - Notes | 89 |
| Reference potentials inside the unit - Notes | 89 |
| Removing / installing a module | |
| <i>Installing an axis module</i> | 184 |
| <i>Removing an axis module</i> | 181 |
| <i>Safety notes</i> | 180 |
| Repair | 179 |
| Responses to error acknowledgement | 160 |
| <i>CPU reset</i> | 160 |
| <i>System restart</i> | 160 |
| <i>Warm start</i> | 160 |
| S | |
| Safety functions | 8 |
| Signal bus cables for several axis systems | |
| <i>EtherCAT based system bus</i> | 71 |
| Signal bus cables to other | |
| SEW units or non-SEW units | |
| <i>EtherCAT-based</i> | 72 |
| Startup of MOVIAXIS® MX | |
| <i>Application and system limits</i> | 137 |
| <i>Approved encoders</i> | 123 |
| <i>Axis configuration</i> | 134 |
| <i>Block diagram speed controller</i> | 133 |
| <i>Controller parameters</i> | 139 |
| <i>Current settings</i> | 118, 141 |
| <i>Download</i> | 138 |
| <i>Encoder data</i> | 122 |
| <i>Encoder management</i> | 120, 142 |
| <i>Encoder management for non-SEW encoders</i> | 124 |
| <i>Encoder management of SEW encoders</i> .. | 119 |
| <i>Encoder selection</i> | 120, 142 |
| <i>Encoder signal processing when using encoder emulation</i> | 143 |
| <i>Example 1 Rotatory encoder as distance encoder</i> | 144 |
| <i>Example 2 Linear encoder as position encoder</i> | 146 |
| <i>Example 3 Multi-motor operation</i> | 150 |
| <i>Monitoring</i> | 131 |
| <i>Motor selection</i> | 128 |
| <i>Nameplate</i> | 129 |
| <i>Selection menu</i> | 126 |
| <i>Sequence of a complete startup</i> | 128 |
| <i>SEW designation of encoders</i> | 121 |
| <i>Speed control parameters</i> | 133 |
| <i>Speed controller setting</i> | 132 |
| <i>System configuration</i> | 127 |
| <i>User-defined units Example</i> | 136 |
| Startup software and its parameters | |
| <i>MOVITOOLS® MotionStudio startup software</i> | 113 |
| <i>Sequence in case of new startup</i> | 115 |
| Station address | 54 |
| Supply module nameplate | 15 |
| Supply system and brake contactors | 75 |
| T | |
| Technical data | |
| <i>Master module - Electronics data</i> | 194 |
| Technical data | |
| <i>DFE24B option for MOVIDRIVE® MDX61B</i> .. | 54 |
| Technical data for 24 V switched-mode power supply module component | 197 |
| Technical data for braking resistors and filters | |
| <i>Line chokes</i> | 201 |
| <i>Line filters</i> | 201 |
| <i>UL and cUL approval</i> | 199 |
| Technical data for buffer module component ... | 196 |
| Technical data for capacitor module component | 195 |
| <i>Control section</i> | 195 |
| Technical data for master module component . | 194 |
| Technical data for the axis module | |
| <i>Control section</i> | 193 |
| <i>Notes on brake control</i> | 192 |
| <i>Permitted load of brake control and brake</i> . | 192 |
| <i>Power section</i> | 191 |



| | |
|--|-----|
| Technical data for the DC link discharge module component | |
| <i>Control section</i> | 198 |
| <i>Power section</i> | 198 |
| Technical data for the supply module | |
| <i>Control section</i> | 190 |
| <i>Power section</i> | 189 |
| Technical data of the multi-encoder card XGH11A, XGS11A option | 42 |
| Technical data of the XFA11A K-net option | 53 |
| Temperature sensor in the motor | 75 |
| Terminal assignment | |
| <i>MXA axis modules</i> | 91 |
| <i>MXB buffer module</i> | 94 |
| <i>MXC capacitor module</i> | 94 |
| <i>MXM master module</i> | 93 |
| <i>MXP supply modules</i> | 90 |
| <i>MXS 24 V switched-mode power supply module</i> | 94 |
| Tightening torque for the cover bolts | 73 |
| Touch guard cover | 73 |
| U | |
| UL approvals | 187 |
| Unit design | |
| <i>24 V switched-mode power supply module</i> | 37 |
| <i>Axis module size 1</i> | 26 |
| <i>Axis module size 2</i> | 27 |
| <i>Axis module size 3</i> | 28 |
| <i>Axis module size 4</i> | 29 |
| <i>Axis module size 5</i> | 30 |
| <i>Axis module size 6</i> | 31 |
| <i>Buffer module</i> | 36 |
| <i>Capacitor module</i> | 35 |
| <i>DC link discharge module</i> | 38 |
| <i>EtherCAT-based version of the axis modules</i> | 32 |
| <i>MOVI-PLC advanced master module</i> | 34 |
| <i>MOVI-PLC basic master module</i> | 33 |
| <i>Supply module size 1</i> | 23 |
| <i>Supply module size 2</i> | 24 |
| <i>Supply module size 3</i> | 25 |
| Unit designation for MOVIAXIS® basic units | 17 |
| Unit output - Permitted connection | 75 |
| W | |
| Wiring diagram | |
| <i>Supply, capacitor / buffer, axis module, brake and 24 V switched-mode power supply module</i> | 80 |
| Wiring diagrams | |
| <i>24 V switched-mode power supply module - Wiring</i> | 88 |
| <i>Axis modules - Connection diagram of binary inputs and outputs</i> | 84 |
| <i>Axis modules - Wiring of control electronics</i> | 83 |
| <i>Brake control</i> | 81 |
| <i>Buffer module - Wiring of control electronics</i> | 87 |
| <i>Capacitor module - Wiring of control electronics</i> | 86 |
| <i>General notes</i> | 78 |
| <i>Master module - Wiring</i> | 85 |
| <i>Supply module - Wiring of control electronics</i> | 82 |
| <i>Supply, axis, capacitor / buffer module</i> | 79 |
| X | |
| XFA11A (K-Net) communication module option | |
| <i>Technical data</i> | 53 |
| <i>Terminal assignment</i> | 53 |
| XIA11A analog / binary hybrid module option | |
| <i>Connection diagram</i> | 61 |
| <i>Module response</i> | 59 |
| <i>Parallel connection of binary outputs</i> | 60 |
| <i>Short circuit</i> | 59 |
| <i>Supply</i> | 59 |
| <i>Switching inductive loads</i> | 59 |
| <i>Terminal assignment</i> | 60 |
| XIO11A binary hybrid module option | |
| <i>Connection diagram</i> | 58 |
| <i>Module response</i> | 56 |
| <i>Parallel connection of binary outputs</i> | 57 |
| <i>Short circuit</i> | 56 |
| <i>Supply</i> | 56 |
| <i>Switching inductive loads</i> | 56 |
| <i>Terminal assignment</i> | 57 |





Address List

| Germany | | | |
|--|--|---|---|
| Headquarters Production Sales | Bruchsal | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 • D-76642 Bruchsal | Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de |
| Service Competence Center | Central Gear units / Motors | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf | Tel. +49 7251 75-1710 Fax +49 7251 75-1711 sc-mitte-gm@sew-eurodrive.de |
| | Central Electronics | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal | Tel. +49 7251 75-1780 Fax +49 7251 75-1769 sc-mitte-e@sew-eurodrive.de |
| | North | SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover) | Tel. +49 5137 8798-30 Fax +49 5137 8798-55 sc-nord@sew-eurodrive.de |
| | East | SEW-EURODRIVE GmbH & Co KG Dänkritzter Weg 1 D-08393 Meerane (near Zwickau) | Tel. +49 3764 7606-0 Fax +49 3764 7606-30 sc-ost@sew-eurodrive.de |
| | South | SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München) | Tel. +49 89 909552-10 Fax +49 89 909552-50 sc-sued@sew-eurodrive.de |
| | West | SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf) | Tel. +49 2173 8507-30 Fax +49 2173 8507-55 sc-west@sew-eurodrive.de |
| | Drive Service Hotline / 24 Hour Service | | +49 180 5 SEWHELP +49 180 5 7394357 |
| | Additional addresses for service in Germany provided on request! | | |
| France | | | |
| Production Sales Service | Haguenau | SEW-USOCOME 48-54, route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex | Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocomme.com sew@usocomme.com |
| Assembly Sales Service | Bordeaux | SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex | Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09 |
| | Lyon | SEW-USOCOME Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin | Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15 |
| | Paris | SEW-USOCOME Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang | Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88 |
| | Additional addresses for service in France provided on request! | | |
| Austria | | | |
| Assembly Sales Service | Wien | SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien | Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://sew-eurodrive.at sew@sew-eurodrive.at |
| Belgium | | | |
| Assembly Sales Service | Brüssel | SEW Caron-Vector S.A. Avenue Eiffel 5 B-1300 Wavre | Tel. +32 10 231-311 Fax +32 10 231-336 http://www.caron-vector.be info@caron-vector.be |
| Italy | | | |
| Assembly Sales Service | Milano | SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano) | Tel. +39 02 96 9801 Fax +39 02 96 799781 sewit@sew-eurodrive.it |



| Netherlands | | | |
|---------------------------------------|------------------|---|--|
| Assembly Sales Service | Rotterdam | VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam | Tel. +31 10 4463-700 Fax +31 10 4155-552 http://www.vector.nu info@vector.nu |
| Switzerland | | | |
| Assembly Sales Service | Basel | Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel | Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch |





How we're driving the world

With people who think fast and develop the future with you.

With a worldwide service network that is always close at hand.

With drives and controls that automatically improve your productivity.

With comprehensive knowledge in virtually every branch of industry today.

With uncompromising quality that reduces the cost and complexity of daily operations.





SEW-EURODRIVE
Driving the world

With a global presence that offers responsive and reliable solutions. Anywhere.

With innovative technology that solves tomorrow's problems today.

With online information and software updates, via the Internet, available around the clock.



SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023 · D-76642 Bruchsal / Germany
Phone +49 7251 75-0 · Fax +49 7251 75-1970
sew@sew-eurodrive.com

→ www.sew-eurodrive.com